

ERP机型: PLA3544Q-GL-SMT00030A-V1

ERP P/N:

描述: 安装操作说明 : PLA3544Q/PGA300RF, STM000, REV.B, 160x80mm, 80G 书纸,  
双面单黑印刷, 十字折, ROHS2.0, REACH, POPs, PAHS, PROP65,

成型尺寸 : 80x40mm

K

Die Line

Designed : Walter


Date : 2022-05-07

**LOCKLY GUARD™**

WWW.LOCCKLYPRO.COM

Lockly Guard Wireless Transceiver is built with F433.92MHz and Lockly 2.0 proprietary encryption to provide stable wireless connectivity, security and reliability. It operates on 12V DC from the Access Control power supply and supports high-level or low-level of PUSH and monitors door open/closed status of the electromagnetic lock\*. It is very quick and easy to install anywhere.

**1. To remove cover, slide the bottom hole and connect to the case as shown.**



### WIRELESS TRANSCEIVER (PGA300RF)

Installation &amp; User Manual

The NC port is used to detect the opening and closing status of the door. Only the Lockly Guard Electromagnetic Lock supports this function. If you use a third-party Electromagnetic Lock other than the Lockly Guard Electromagnetic Lock, you do not need to connect this NC cable.  
\*Works ONLY with Lockly Electromagnetic Lock. Connection to NC of the LOCK NC cable is required.

**3. Pair Wireless Transceiver to the Lockly Guard Ingress or Ingress Vision**

Access Control power supply will activate the Wireless Transceiver. Wireless Transceiver Blue light indicator will be ON once connected to Ingress or Ingress Vision. Refer to the Ingress/Ingress Vision Manual for pairing instructions.

Short Press the wireless transceiver pairing button to start connecting with Ingress/Vision, Blue light indicator flashes when pairing starts. It will automatically exit pairing mode if pairing is successful. If pairing is unsuccessful, it will continue to flash and automatically exits in 3 minutes.



Short press the wireless transceiver pairing button again to re-enter pairing mode.

**4. How Wireless Transceiver and Ingress/Ingress Vision Works**

- 1) When wireless transceiver is activated through the smart access control power supply, the Blue light indicator turns ON when the door locks or unlocks.
- 2) When the electromagnetic lock (LOCK NC) is triggered, the Blue light indicator turns ON.

#### FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE 1:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC Radiation Exposure Statement

The Secure Link Wi-Fi Hub complies with FCC radiation exposure limits set forth for an uncontrolled environment. It should be installed and operated with minimum distance 20cm between the radiator & your body.

#### IC WARNING

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### IC Radiation Exposure Statement

This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102. It should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102. Il doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et toute partie de votre corps.

**⚠ WARNING:** This product can expose you to chemicals including Lead, which is known to the State of California to cause cancer. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).