Manual of JJ-RC-SM24-LT

Description:

Frequency: 310mhz、315mhz、318mhz、372mhz、390mhz etc.

Working current: 13ma±2ma

Operation:

Open the sliding cover, you will see the program button and Dip Switch.



How to select the brand?

- Press the program button, release the button until LED lights.
- Select a button to program. According follows table to select brand.
- Press button__ times ensuring LED stops flashing after each press. Then
 press another button to confirm.
- LED flashes, select brand is successfully.

NOTE: Button 1 and Button 2 is independly. It can select different brand and frequency.

	and noquoney.			
#of times to	Brand	Type/Color of Smart/Learn	Frequency	
press button				
1	Linear	Mega code	318M	
2	Chamberlain	Orange	390M	
3	Chamberlain	Purple	315M	
4	Chamberlain	Green	390M	
5	Genie Overhead door	Intelli code	315M	
6	Genie Overhead door	Intelli code	390M	
7	Stanley	Secure Code	310M	
8	Liftmaster	Frequency hopping	310/315/390	
		to avoid Frequency		
		interference		
9	Wayne Dalton	Rolling code	372.5M	
10	Chamberlain	9 Position	390M	
11	Chamberlain	9 Position	315M	
12	Genie	12 Position	390M	

13	Linear Multicode	10 Position	300M
14	Chamberlain	8 Position	390M
15	Stanley/Multicode	10 Position	310M
16	Genie	9 Position	390M
17	Linear Moore-O-Matic	8 Position	310M
18	Chamberlain	7 Position	390M

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device,

pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.