
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. Such modifications could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement.


This equipment complies with FCC's RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or in conjunction with any other antenna or transmitter.

REMOTE CONTROL OPERATING INSTRUCTIONS

Install a 12V battery into the remote control. To prevent damage to the remote control, remove the battery if not used for long periods of time.



WARNING: Do not short-circuit, disassemble, heat up, connect improperly, or dispose of used batteries in fire. Do not recharge or mix batteries with used or other battery types. Immediately remove used batteries.



Remote Control Operation Instructions

Install a 12V battery into the remote control. Fasten the battery cover screw after installation. To prevent damage to the remote control, remove the battery if not used for long periods of time.

WARNING: Do not short-circuit, disassemble, heat up, connect improperly, or dispose of used batteries in fire. Do not recharge or mix batteries with used or other battery types. Immediately remove used batteries.

WARNING: a) The cells shall be disposed of properly, including keeping them away from children; and b) Even used cells may cause injury.



01

Learning Process

NOTE: Should you desire to install more than one fan in your home, please install it one by one by following the steps below to ensure each fan can be operated individually:


Step 1: Turn off the AC power to all fans to begin the learning process on any single fan.

Step 2: Restore power to only one fan at a time for pairing, the rest remain off by use of your wallmounted power switch.

Step 3: After the AC power is on, do not press any other button on the remote control before pressing the  (FAN ON/OFF) button. Doing so will cause the procedure to fail. Within 30 seconds of turning the fan's AC power ON, press and hold the  button for 5 seconds to enter the learning function.



Once the receiver has detected the set frequency, a beeping sound is emitted when the pairing is complete.

Step 4: Repeat steps 1, 2, and 3 with each fan to ensure each fan can be operated by the paired remote only, and without interfering with each other.



NOTE: On start up your ceiling fan will oscillate back and forth. This is NORMAL OPERATION for DC ceiling fan as it goes through its calibration cycle. The fan is NOT DEFECTIVE.

02


1. Fan  button.-Press and release the  button to turn the fan on or off.

- Fan on/off. The fan memory function will store the current setting for the next time the fan is in use.



2. 1,2,3,4,5,6 buttons:


- These six buttons are used to set the fan speed as follows:

1=low speed 2=medium low speed
3=medium speed 4=medium high speed
5=high speed 6=Extra high speed



3. Light functions

- Press and release  button one time will turn the light on or off.
- Press **+** to increase the desired light level.
- Press **-** to decrease the desired light level.
-  button:
Select the desired color temperature.



4. Fan reverse button  (Must be Pushed when the fan is in operation)

- (Counterclockwise Direction) A downward air flow creates a cooling effect. This allows you to set your air conditioner on a higher setting without affecting your comfort.
- (Clockwise Direction) An upward air flow moves warm air off the ceiling. This allows you to set your heating unit on a lower setting without affecting your comfort.