

JAWBONE®
www.jawbone.com


©Jawbone. All rights reserved. Jawbone® and Jambuds™ are trademarks of Jawbone Products, LLC. Bluetooth SIG, Inc. owns the Bluetooth® word mark and logos, and any use of such marks by Jawbone is under license. Other trademarks and trade names are those of their respective owners. Reproduction in whole or in part is prohibited. The illustrated product and specifications may differ slightly from those supplied. Distributed by Jawbone Products, LLC., Edison, NJ, 08817.

JAWBONE®

JAMBUDS™

QUICK START GUIDE

INCLUDED IN THE BOX





BLUETOOTH® PAIRING

To pair your device, keep the earbuds in the case with the lid open. Press and hold the case button (7) on the side of the case for three seconds until the green LED (6) starts to flash, then let go of the button. Turn on Bluetooth® on your smartphone and select "Jambuds TWS ANC" in your wireless connection settings to pair.

Repeat this process to pair your Jambuds™ to a different device.

If something goes wrong, or you want to erase the earbuds from your smartphone, please reset them to their factory settings.


- 1- Output Microphone
- 2- Touch Area
- 3- Air Vent
- 4- Ear Tip
- 5- Input Microphone
- 6- LED
- 7- Case Button
- 8- Charging Port




CHARGING / FACTORY RESET

To reset the Jambuds™ back to their factory settings, place them in the case with the lid open and press and hold the button on the side for 10 seconds. The battery status light will start flashing, and the earbuds will reset.


- LIGHT INDICATOR
- Green 100%
- White 80%
- Orange 30%



PERFECT FIT
The Jambuds™ come equipped with medium-sized ear tips and two extra pairs. Choose the size that provides the best fit for optimal sound quality and comfort. Adjust as needed.



TOUCH CONTROLS



Active Noise Cancellation (ANC) reduces environmental noise. It is the default mode of the Jambuds™ when they power up. **Ambient Mode** allows you to hear everything around you. Use it when you need to listen to your surroundings.

To cycle between ANC and Ambient Mode, touch and hold either earbud for 2 seconds.

TECHNICAL SPECS & BATTERY CARE/DISPOSAL

TECHNICAL SPECS

Bluetooth® Versions: V5.3
Case Charging Time: About 2 Hours
Earbuds Charging Time: About 1.5 Hrs.
Driver: 10mm Dynamic Driver
Frequency Response Range: 20Hz-20kHz
Noise Cancellation: Hybrid ANC/ENC
Codec Support: AAC, SBC
Waterproof Grade: IPX4 (Earbuds only)
FCC ID: 2ATQETWE

ATTENTION
Avoid prolonged listening to music at high volumes, as this can cause permanent hearing loss. Do not use in temperatures greater than 104° F (40° C). Do not use the ANC mode while driving, biking, or any other activity where you must be aware of your surroundings.

BATTERY CARE AND DISPOSAL

Each earbud and the case contains a battery. Batteries store electrical energy and can cause fires and explosions if cut, crushed, or burned. Batteries can leak flammable fluids and gases when they get hot, so don't leave them in direct sunlight, inside a hot vehicle, or near a fire. Please dispose of the earbuds and case responsibly at an electronics disposal site.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INSTRUCTIONS FOR A CLASS B DIGITAL DEVICE OR PERIPHERAL

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, according to part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used following the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

WARRANTY (1 OF 4)

The condition of this warranty and our responsibilities are as follows: Supplier's warranty is non-transferable. This warranty is limited to the original purchaser only.

- You must be able to prove the date of the original purchase of the unit with a dated receipt
- The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification, or repair by an unauthorized third party
- The responsibility for the supplier's products shall be limited to the repair or replacement of the product at its sole discretion
- Specifically exempt from any warranty are limited-life consumable components such as batteries, decorations, and other accessories, which are subject to normal wear and tear
- A supplier will not take any responsibility if the unit's failure has resulted from accident, abuse, misuse, or any unauthorized repair, modification, or disassembly
- Modification and repair of the unit should be done by authorized and qualified service personnel, center, or returned to the manufacturer
- This warranty gives you specific legal rights; you may also have other rights that vary under local laws

WARRANTY (2 OF 4)

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual obligations. We offer a warranty on our products by the following conditions:

- 1) A three-month warranty covers Jawbone® products. We will resolve damages or defects on Jawbone® products free of charge within three months of the purchase date under the following warranty conditions. For any damage or defect determined later than three months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.
- 2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily, such as glass or plastic, or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and artistry, provided these have a negligible effect on the product's fitness for use in the event of damage caused by chemical or electrochemical effects by water or generally from abnormal conditions.
- 3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or replace them with working parts free of charge. Jawbone® reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on-site. Parts that have been replaced or exchanged become our property.

WARRANTY (3 OF 4)

4) The warranty claim only applies if unauthorized persons carry out repairs or other work or if our products are equipped with additional parts or accessories that are not approved for our product.

5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We, therefore, accept no liability for accidental, indirect, or other consequential damage of any kind that leads to usage restrictions, data loss, and loss of earnings or interruption to business.

ASSERTING A WARRANTY CLAIM

To make use of the warranty service for hardware issues, you must contact the Jawbone Service Center by email at support@jawbone.

Jawbone® will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization), and you will be asked to send the product to a Jawbone Service Center.

IMPORTANT

Jawbone® will only accept parcels that have an RMA number. Please observe the following when sending the product:

WARRANTY (4 OF 4)

1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Jawbone Service Center specifies otherwise.

2) Mark the RMA number on the outside of the package to be visible and legible.

3) You must enclose a copy of the sales slip as proof of purchase.

4) Once the Jawbone Service Center receives the product, it will meet its warranty obligations by the conditions. It will return the product to the sender with carriage and insurance paid.

SERVICE OUTSIDE OF THE WARRANTY

Jawbone® can refuse any service claim made because the warranty does not cover that. If Jawbone® agrees to provide a service outside the contract, the customer will be invoiced for all repair and transport costs. The company will not accept any packages not approved by Jawbone® using an RMA (Return Material Authorization). Contact us with questions at support@jawbone.

RF WARNING STATEMENT

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.