

Tire pressure activator operating instructions

The main function of TPMS activator is to make the sensor send data signal quickly, because the sensor is in sleep state for a long time, the activator can wake up the sensor quickly, which is convenient for users to learn and other operations.



The main components of the exciter are single chip microcomputer, battery, 125kHz low frequency antenna and two No.7 batteries. There are 6 buttons and 1 red indicator light on the surface of the activator. Long press any key to send 125kHz low frequency signal, which can wake up the sensor within 20cm distance. When the sensor receives the low frequency signal, it will immediately transmit the data signal. Users can read sensor information through TPMS display.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm

between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.