

# User manual

## Introduction

Congratulations on receiving your SR-3. As part of our Green Initiative, we do not include printed user documentation with our product packaging. This policy saves paper, lowers shipping costs, reduces carbon emissions and results in a cleaner environment.

## Documentation

All product and accessory documentation can be found at the GLI Support Centre: <http://www.gl-inet.com/docs> On this site you will gain access to GLI technical resources and information about GLI products. To use your new GLI Mini Router you will need to follow the simple steps which you can see from <http://www.gl-inet.com/docs/wiki/#!mini/index.md>

## Default System Settings

| Product               | LAN Default IP Address | LAN Fall-back IP Address |
|-----------------------|------------------------|--------------------------|
| 750M Travel AC Router | DHCP                   | 192.168.8.1              |
|                       |                        |                          |

## Initial Set-up

Interfaces described as followed:

Power to the GLI Mini Router is provided by connect the power lead (supplied) to the power adaptor (buy separately) and then to the power interface on the GLI Mini Router.

Once power is provided to the GLI Mini Router the LED's will provide status on its operation based on the following:

| LED                     | Indicator   | Description   |
|-------------------------|-------------|---|
| LED 1 (Power)           | Green solid | Power is applied  |
| LED 2 (Customized)      | Customized  | This is customized LED.                                     |
| LED 3 (WiFi connection) | Red         | Indicates WiFi signal (solid) and data transfer (flashing). |

## Button Definition

- Press the Reset button to toggle the WiFi signal ON or OFF.
- Press and hold the Reset button for at least 8 seconds, then release your finger to reset the router to factory default state. Wait until the router reboots, which could take about 3 minutes.

- The function of “switch” is configurable by user.

### *FCC Statement*

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the users' authority to operate the equipment.

### *FCC Caution*

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### *IC WARNING*

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic

Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**WARNING:** *The minimum separation generally be used is at least 20 cm, even if the calculations indicate that the MPE distance would be lesser. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance 20cm between the radiator & your body.*