Ice Cooling Car Charger User Guide



Thank you for purchasing and using this product!

Please read this operation instruction carefully before using this product.

Product Specification

Input: 5V = 3A / 9V = 3A / 12V = 2.5AOuput: 15W (Max)

Applicable Devices

Compatible with MagSafe iPhone.



↑ The LED light turns red during wireless charging to indicate a charging failure.

The following situation can cause failures, like charging slowly, stop charging, over-temperature for charging position.


- 1. The adapter is not run up to standard.
- 2. The charging cable is not up to standard.
- 3. The phone case is too thick (within 2mm thickness phone case recommended).
- 4. The built-in wireless charging receiver position is not coincided with wireless charger coil position.
- 5. There is metal/magnet on the back of cell phone or phone case.
- 6. Smartphone does not support wireless charging function.

⚠ Attention


- Please keep the charger away from water or other liquid.
- 2. If you need to clean the charger, please make sure it is not connected to power supply.
- 3. Operating temperature: -20~45 °C.

Step to install air vent

1. Follow the arrows to install 3 parts.



2. Adjust the screw cap to the best active status.



3. Turn the pulley to the left to adjust the hook to the longest.




4. Rotate the pulley to the right to make the hooks to clamp the air vent blades.



LED control switch

Switch

Can turn off lights and change other light colors



LED indicator light:

Ice blue always on: normal charging Red flashing: abnormal charging



Case Usage



Non-case







Apple MagSafe case Mag

Other MagSafe case









Thick case

Credit cards

Metal

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.