

LED WallLight Assembly And Instructions

Please read these instructions carefully before installing this product.


Suggest you keep these instructions in a safe places for future reference.

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar quali-ed person.


All inside wires of this luminaire cannot be replaced; if the wires are damaged, the luminaire shall be destroyed.

IF IN DOUBT, CONSULT A QUALIFIED ELECTRICIAN

Specification

Watt	Lumen	Leds	Voltage	Frequency	CCT	
10W	≥650	60	AC 120V	60Hz	3000K	1.5


Dimension




Installation

Step 1. Turn off the power switch before installing.


Step 2. Use 2-8# -32 screws lock the mounting bracket to the junction box or make 2-Φ8 holes in the wall, drive in the plastic tube expanding and use 2-ST6.2 screws lock the mounting bracket to the wall.




Step 3. Hang the hook on the mounting bracket and use the terminals connect the wires as show as drawing.




Step 4. Use 4 M4*L10MM screws thread the wall base to the mounting bracket, and check that the rubber washers is installed correctly to ensure that the installation is waterproof.




Step 5. Select the desired No. sticker and stick it on the No. plate.



Step 6. Fasten the No. plate into the wall base.



Step 7. Put waterproof glue around the base to make sure it's waterproof.



Step 8. Turn on power switch after installation completed.

FCC WARNING:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.