WIRELESS MICROPHONE

INSTRUCTION

A. Display Screen B. On/Off Switch

C. Battery Compartment
D. Channel Adjustment Button

Wireless microphone battery installation and on/off:

 Take down the tail tube(C) of mic. 2. Put two AA batteries into the battery

compartment of the microphone according to the positive and negative poles.

3. Press the power button (B) to turn on the

microphone.

Operating instructions for wireless microphone bindina:

The 5 frequencies of Mic A: CH01-CH15 The 5 frequencies of Mic B: CH16-CH30

Press the "D" button to switch channel in sequence.

(A) (C) (D

B

Cautions:

The operating distance of the wireless microphone is within 100ft. In order not to affect performance, please do not exceed this range. When the battery power is low or the environmental interference source is too strong, the operating distance will be shortened.

Do not use wireless microphones of the same channel simultaneously in a short distance, as this will cause silence or interference.

If you have purchased two or more sets of this product and plan to use them together within a short distance, please switch the wireless microphone to different channel. During use, please do not place the machine near devices with high interference frequencies (such as VCD/CD/DVD), so as to avoid interference between the machine and the VCD /CD/DVD of the same frequency.

WIRELESS MICROPHONE PAIRING STEPS

- 1. Please turn off the receiver and the microphone first.
- Unscrew the microphone tail tube and install the battery into the mic's battery compartment.
- 3.Long press button 2 under shutdown state, do not release it, simultaneously press the power button 1 until the screen flashes quickly, then release the buttons synchronously (the HI/LO button and the power button are released synchronously).
- 4.Turn on the receiver power switch, after 5 seconds, press the HI/LO button② on the microphone. If the screen of the microphone is not flashing, and the frequency is not only displayed on the microphone scree, but also the receiver, which means the pairing is successful.
- 5. Turn off the microphone, then tighten the microphone tail tube. The microphone pairing is completed.



WIRELESS MICROPHONE

TECHNICAL PARAMETERS

Wireless microphone:

Frequency Response: 50Hz-15kHz

Operating Distance: 100ft RF Carrier Stability: ±0.003%

S/N Ratio: 96dB T.H.D.: ≤0.5%@1kHz

Microphone Input Sensitivity: -52dB

RF Sensitivity: -95dBm

Working temperature: 0°C to +55°C

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.