

# AVA

INDOOR CAMERA




## Quick Start Guide



POWERED BY  
 SecureNet




## Getting to know the camera




### STATUS INDICATOR

- + **Flashing blue:** the camera is on and ready for Wi-Fi connection
- + **Steady blue:** the camera is running properly
- + **Steady red:** the camera is starting
- + **Flashing red:** there is a network connection issue




## What's in the box?

### 1 INDOOR CAMERA





### 2 POWER ADAPTER AND MICRO USB CABLE



### 3 SCREWS & ANCHORS




## Installing a MicroSD card (optional)



Open the side cover to insert a MicroSD card.

The card will be formatted during the add camera process.

## Powering the camera



Connect the Micro USB end of the power cable to the camera and the USB end to the power adapter.

If mounting, place the camera back onto the magnetic disc.

Connect the power adapter to an AC power outlet to power up the camera.

## Connecting to the camera

In the app, go to the **Video** or **Settings > Video** settings page and tap the circular “+” button to launch the camera installation wizard.

Follow the instructions in the app to connect the camera to your account and configure the network settings.

## Resetting the camera

If you change your Wi-Fi network or for some other reason you cannot connect to the camera, you will need to reset it. Press and hold the Reset button on the back of the camera for 10 seconds.

In the app, go to the **Settings > Video** settings page and select the camera. Update the Wi-Fi settings to re-establish a connection to the camera.

Do not place the camera in extremely hot, cold, dusty, or damp locations, and do not expose it to electromagnetic radiation. The operating temperature is 14° F to 104° F (-10° C to +40° C).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause interference, and

(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radioexemptés de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut

fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

CAN ICES-3 (B)/NMB-3(B)

This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

ce matériel est conforme aux limites de dose d'exposition aux rayonnements, FCC / CNR-102 énoncée dans un autre environnement.cette equipment devrait être installé et exploité avec distance minimale de 20 entre le radiateur et votre corps.