

Contents

- I. Introduction
- II. Safety Precautions
- III. Buttons and Ports
- IV. Specification
- V. Laptop Interface
- VI. Setting up a Microsoft Account
- VII. Start Menu and the Windows Store
- VIII. Action Center and OneDrive
- IX. Task View, Start Screen and Restoring Windows
- X. Tips & Tricks

1. Introduction

Thank you for purchasing the **TAGITOP-PLUS II** which comes with the newest Intel 10th gen Core I7 Quad Core CPU technology, 8GB DDR4 RAM for quick multi-tasking, 128GB SSD and 500GB HDD of internal storage, a clear and sharp 15.6 inch screen, and the latest Windows 10 software.

This user manual will help you understand the features and functions of your new laptop. Please read this user manual carefully before using this device. It is recommended to charge the device for a full charge before the first use.

2. Safety Precautions

- 1) This device is suitable for use in non-tropic areas below 2,000 meters.
- 2) Do not drop the device or apply strong force.
- 3) Avoid extended use in extreme cold, hot, humid or dusty environments. Avoid exposing the device

to direct sunlight for extended periods of time.

- 4) Avoid using the device near strong magnetic fields and in static environments.
- 5) Keep the device away from water and other liquids. In the event that water or other liquids get on or into the device, power off the device immediately and ensure the device remains off and unplugged until fully dry.
- 6) Do not clean the device with any chemical or other liquid to avoid causing damage due to corrosion and moisture. Clean with a dry soft cloth only.
- 7) We are not responsible for loss of data due to malfunction, misuse, modification, or other accident.
- 8) Please back up your important data regularly to avoid loss.
- 9) Please do not attempt to disassemble or repair the product on your own, as it will void the warranty.
- 10) Do not attempt to change the battery on your own. Using an incompatible battery may cause explosion.
- 11) To reduce the risk of fire or electric shock, do not expose this device to rain or moisture. The device should not be exposed to dripping or splashing. Never place objects filled with liquids, such as vases, on the device.
- 12) Windows Software receives updates directly from Microsoft. The device will update automatically, or you may manually check to see if there are updates available from Microsoft.
- 13) Remember your passwords – Manufacturers and resell outlets cannot assist in unlocking your device due to forgotten passwords. Setting up a Microsoft account vs. local account is best if requesting any assistance from Microsoft for any issue.
- 14) Handle your device with care – any misuse or abuse which causes malfunction of the unit, voids all warranty. This includes cracked display screens.
- 15) We reserve the right to change the contents of this manu

3. Buttons and Ports

1. **DC port:** Used to connect the power supply and recharge the device.
2. **USB port:** Used to connect USB accessories such as a keyboard, mouse, USB drive or other portable storage.
3. **HDMI port:** HDMI out used to connect the device to a TV or other HDMI input.
4. **Type C:** Full function with Power delivery, Display, Data Transmit;
5. **Headphone port:** Audio out used to connect headphones or portable speaker using a 3.5mm connection.
6. **Micro SD card slot:** Used to insert a Micro SD (TF) card to expand the memory. Supports Micro SD cards up to 128GB
7. **Camera:** For taking photos or videos.
8. **Display Screen:** 15.6 inch 1920x1080 FHD IPS LCD
9. **Power Button :** To power on/off the device, long press the power button for about 2-3 seconds.
10. **Touch Pad:** Translates the motion and position of a user's fingers to navigate and request functions on the device.

4. Laptop Interface



1. Windows (Start) Icon	7. Battery
2. Search Bar	8. Wi-Fi
3. View all open windows	9. Volume
4. Browser	10. Action Center
5. File Explorer	11. Keyboard Settings
6. Windows Store	12. Date and Time Setting

6. Setting up a Microsoft Account

NOTE: We highly recommend using a Microsoft Account instead of a local account. If you use a local account and forget your password you will be locked out of the device.

Setting up a **Microsoft account** allows you to sign in and use the various features provided on your tablet, including: **OneDrive, Outlook.com, Xbox Live, Office 365, Skype** and more. Setting up a **Microsoft account** makes using your device easier. If you do not already have a **Microsoft account**, you can create one for free.

Some of the benefits include:

- You only have to sign in once. If you use a **Microsoft Account** to sign into Windows, you do not need to sign in again to use Microsoft related apps and services such as **Skype, Outlook.com, OneDrive** and more.
You are connected and synced across all your Windows-based devices you sign in under.

You will be prompted to sign into your existing Microsoft Account when accessing Windows. You can click "**Sign up**" to create one if needed.

- To create a **Microsoft Account**, select **Sign Up** on the log in page.
- You can also go to **Microsoft.com/account**

NOTE: You can use your existing email address to sign up, even if it is not a Microsoft provided address. If you do not have an existing email address, you can click "get a new email address" to sign up for one.

If you just choose a Local Account, you will not get the benefits of only having to sign in once and having your settings synced across devices. Create a Microsoft Account to use these features.

Switching from a Local Account to a Microsoft Account

If you do sign in with a local account, you can choose to switch to a Microsoft account at any time.


- Click on the **Windows (Start) Icon**
- Click on **Settings**
- Click on **Accounts**
- Click **Sign in with a Microsoft Account** instead

7. Start Menu

The **Start Menu** is accessed by clicking the **Windows icon** in the lower left corner of the screen.

The **Start Menu** provides access to the **Apps** you have installed, system **Settings**, and other **important features**.

You can use **All Apps** to view all installed apps in a list. You can pin frequently used apps to the **Start menu** by holding your finger on the app icon for a few seconds and then choosing "**Pin to Start**" or "**Pin to Task bar**."



The Windows Store


The **Windows Store** is where you can install new apps for your device. To access the **Windows Store**, choose **Store** from the **Start Menu** or click the **shopping bag icon** in the toolbar at the bottom.

- Search for the app you wish to download
 - Click the app to view more information
 - Click **Install** if it is a free app, or **Buy** to purchase the app and install it.
- NOTE: You need to be signed in to your Microsoft Account to install apps from the Windows Store.

8. Action Center

The **Action Center** is accessed by tapping the **notification icon** on the lower right.

The Action Center provides quick access to important notifications, and allows you to change some common settings.



From the **Action Center**, you can turn **Airplane Mode** on or off. When **Airplane Mode** is on, all Wi-Fi and other connections are disabled.

One Drive

OneDrive is online cloud storage provided by **Microsoft**. When you create a Microsoft Account, you get some online storage free through **OneDrive**.

You can access **OneDrive** through the **Microsoft Edge** browser by going to <https://onedrive.com>

Sign in with your **Microsoft Account** if prompted.

By default, a local folder is also created for **OneDrive**.

You can find the **OneDrive** folder under **C:\Users\[ACCOUNT_NAME]\OneDrive** (where [ACCOUNT_NAME] is your username).

9. Task View

Task View allows you to quickly switch between and close open apps. To launch **Task View**, click the icon shown below on the bottom toolbar.



Start Screen

If you prefer using the full **Windows Start Screen** instead of the **Desktop View**, you can switch by using the steps below:

- Click on the **Windows (Start) Icon**.
- Click **Settings**
- Click **Personalization**
- Choose **Start** on the left
- To the right, turn the setting that says "**Use Start full screen**" to on.

You can also switch back the full **Windows Start Screen** to **Desktop View** by turning the option off.

NOTE: You may need to sign out and back in for these changes to take effect.

Restoring Windows

If your device is encountering errors which you have been unable to resolve, you can restore Windows to the original state.

- Click on the **Windows (Start) Icon**.
- Click **Settings**
- Click **Update and Security**
- **Click Recovery**
- **Under Reset this PC, click Get Started**

NOTE: If you want to keep any files, select Keep my files. If you do not wish to keep your files, or you have backed them using an external method, click Remove Everything.

10. Tips and Tricks

10-1. Creating a Recovery Drive

It is recommended you create a recovery drive when you first get your tablet. A recovery drive can help you troubleshoot and fix problems with your PC, even if it won't start. To create one, all you need is a USB drive.

- From the task bar, search for **Create a recovery drive** and then select it. You might be asked to enter an admin password or confirm your choice.
- When the tool opens, make sure **Back up system files to the recovery drive** is selected and then select **Next**.
- Connect a USB drive to your PC, select it, and then select **Next > Create**. A lot of files need to be copied to the recovery drive, so this might take a while.
- When it's done, you might see a **Delete the recovery partition from your PC** link on the final screen. If you want to free up drive space on your PC, select the link and then select **Delete**. If not, select **Finish**.

10-2. Using Bluetooth to Send and Receive files:

- Click on the **Windows (Start) Icon**
- Click on **Settings**
- Click on **Devices**
- Click on **Bluetooth** and turn **Bluetooth ON**

After **Bluetooth** is turned **ON**, your tablet will begin to search for **nearby Bluetooth devices**.

NOTE: You will need to ensure that the device you wish to pair also has Bluetooth enabled and is visible to nearby devices.

Once the search is complete, it will display available nearby devices. You can pair your tablet with another device by selecting it from the list.

NOTE: You may need to confirm a pass key on both devices to finish pairing.

Settings

DEVICES

Printers & scanners

Connected devices

Bluetooth

Mouse & touchpad

Typing

AutoPlay

Manage Bluetooth devices

Bluetooth On

Your PC is searching for and can be discovered by Bluetooth devices.

- dazen X7
Ready to pair

Related settings

[More Bluetooth options](#)

Search the web and Windows

1:40 AM
8/5/2015

- After pairing the devices click on the **Bluetooth icon** on the task bar, at the bottom right.
- To transfer a file to your tablet, click on "**receive a file.**" You will see a "**waiting for connection**" window.
- Go to your other device, select the file you wish to send and use the option to share or send via Bluetooth.
- Select the tablet from the list of paired devices to send.
- The tablet will begin downloading the file and will provide an option to save.

NOTE: The same process can be used to send files from tablet to other device.

10-3. Resizing Icons and Fonts in Desktop View:

- Click on the **Windows (Start) Icon**
- Click on **Settings**
- Click on **System**
- Choose **Display**
- Here you can choose from 100%, 125%, 150% or click "custom sizing options".

NOTE: If you go over 150%, some menu options may no longer be accessible. It is recommended you use the magnifier tool instead if you need the font to be larger.

10-4. Shutting Down and Powering On:

When you shut down the PC, allow the PC to shut down completely. It is recommended to wait five minutes before turning it back on to ensure all internal hardware has completed the shutdown cycle.

10-5. Power Saver:

This device has a built-in rechargeable battery. We recommend you keep the screen brightness on medium and only turn it up when needed to conserve battery power.

To access the Power Saving options:

- Click the **battery icon** in the task bar on the lower right
- Select "**Additional Power Settings**"
- Here you can "**Choose or Customize a Power Plan**"

10-6. Changing the Language and Keyboard Input Method:

- Click on the **Windows (Start) Icon**
- Click on **Settings**
- Click on **Time & Language**
- Choose **Region & Language**
- Choose **Add a language and select the language you want to use.**

After this, you will see the selected language in the list. Choose options to download the language pack if needed and to assign it as an input method for the keyboard.

10-7. Date and Time:

The correct date and time is required for many applications to function properly. Generally the date and time is set automatically when connected to the Internet. However, if this is not working properly or you are offline, you can set the time and date manually.

- Click on the **Windows (Start) Icon**
- Click on **Settings**
- Choose **Time and Language**

Here you can choose your time zone and, if needed, turn off automatic time and manually set it by clicking "change".

SAR Information Statement

The product is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted with the product transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the product while operating can be well below the maximum value. This is because the product is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a product model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model product when tested for use worn on the body, as described in this user guide, use at the ear is 0.521W/kg .

(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various product and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model product with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model product is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on.

FCC ID: 2AVTH-L13WA1S Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0mm is used between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.