

## DOOR SENSOR



## DESCRIPTION




**KRG door sensor** will detect every door opening and closing.

It is composed of **2 parts** : one **sensor** and one **magnet**.

It is an advanced magnetic contact sensor with integrated sigfox transceiver designed to be a fully supervised **low-current device**.

## SENSOR PREPARATION

1. Clean the door/wall surface.
2. **Remove the slice** at the bottom of the sensor to **activate** the detector. This will start the sensor by activating batteries already installed.



## SET UP

The sensor connects automatically to the network.


1. **Red** LED on the sensor flashes every second during one minute.
2. **Green or red** (depending on the configuration) LED lights on during 5 seconds.
3. The light turns off. The configuration is set up.

**After every battery replacement or software reset, the sensor will perform the set up operation.**

The device shall keep at least 20cm separated from the humans.

## INSTALLATION


1. **Double-sided tapes** are given to stick the sensor in the proper position on the door.
2. Put the **sensor on the doorframe** and the **magnet on the door**. Make sure the **LINE** on both part matches. The two parts have to be the **closest possible** without touching each other (<20mm).



## INSTALLATION

### Specific situations

1. You can **reverse** the sensor if the door frame is too small. Put the **sensor on the door** and the **magnet on the doorframe**. Make sure both parts are close and aligned.




2. You can also put sensors on the **top of the door**. Both part will be horizontal.


## BATTERY CHANGE

When the battery is low, **red** LED flashes every 10 seconds.

1. **No need to remove the sensor from the wall.** Press on the front of the sensor to open it.
2. Take out old batteries. Use the tongue to remove batteries.
3. Install new batteries according to polarity marking.
4. Sensor will initialize itself (see red LED flashing for 1 minute).



## DIMENSIONS



## SPECIFICATIONS

<b>Sigfox Zone</b>	RCZ2
<b>Model Name</b>	DS-0923ST-00
<b>RF Specification</b>	Sigfox Class 0
<b>Magnet spec</b>	Active range >= 20mm
<b>LED</b>	Dual color LED green and red
<b>Installation</b>	Double-sided tapes
<b>Battery</b>	Alkaline battery
<b>Battery life</b>	>24 months
<b>Operation environment</b>	-10 / +50c, 0-90% RH non-condensing
<b>Storage Environment</b>	-20 / +70c, 0-90% RH non-condensing

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### IMPORTANT NOTE:

#### Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/  
CANADA

Operation of this device is restricted to indoor use only

Industry Canada statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference

(2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme Canada limites d'exposition aux radiations dans un environnement non contrôlé. Cet équipement doit être installé et utilisé à distance minimum de 20cm entre le radiateur et votre corps.

**KRG**  
CORPORATE