

Install the datalogger

COM port of the inverter, A Solis 5K inverter is used here as an example.





Match the joint

Version: 3.1



Quick Installation Manua

Delivery Content ■1 WiFi stick

1 WiFi Antenna

1 Quick Installation Manual

Connect the datalogger to the corresponding 4-pin

Please follow the instructions below:



Install the datalogger:	
-------------------------	--

1. Install the antenna to the datalogger 2. Insert the datalogger to the inverter COM port

3. Rotate the black circle clockwise



Only rotate the black circle, not the sliver cover.

1. The device must be installed away from the strong magnetic field produced by large electrical appliances such as microwave oven, refrigerator. telephone, metal walls, etc. Otherwise, the communication quality may be affected. It may also be affected by lighting storm. 2. The [RESET] button on the back is used for

- connection. ·Short press will send the data immediately.
- Long press for 5 seconds will reset the connection.
- The three constantly ON LED lights indicate the datalogger is working normally.

	indicators	Booonption	Status	Wicamingo	
	Internet Indicators • (NET)	Shows the connection status between the datalogger and the server.	Flashing	Trying to connect with server	
			ON	Successfully connected	
			OFF	Abnormal connection	
	Inverter COM Indicators •(COM)	Shows the connection status between datalogger and the inverter.	Flashing	Trying to connect with inverter	
			ON	Successfully connected	
			OFF	Abnormal connection	
	Power Indicator •(PWR)	Shows the power supply status of the datalogger.	ON	Datalogger is powered up normally	Step 3: the SN
			OFF	Datalogger is powered up abnormally	

download and register the Solis Cloud APP Or directly download from APP Store or Google Play Store by searching "SolisCloud".



Step 2: If it is a new datalogger, please configure it first, then click the "WiFi configre".

Fill in the datalogger SN

Please fill in the datalogger sn

LED Lights Status

escription	LED Status	Meanings	Hello Welcome to ginlong		
ows the nection lus between datalogger	Flashing	Trying to connect with server	Username/Phone Number/Email		
	ON	Successfully connected	Password 🖎		
the server.	OFF	Abnormal connection	☐ Remember Forget password		
	Flashing	Trying to connect with inverter	Log in		
ows the nection tus between	ON	Successfully connected	.anguage setting WiFi configure Data migration		
alogger and inverter	OFF	Abnormal connection	Please click "WiFi configure"		
nws the	ON	Datalogger is powered up	Step 3: Manually fill in the datalogger SN or S the SN on the datalogger.		



	Description	Status	Meanings		V
s	Shows the	Flashing	Trying to connect with server		
	connection status between the datalogger	ON	Successfully connected		Р
	and the server.	OFF	Abnormal connection		
si d		Flashing	Trying to connect with inverter		
	Shows the connection status between	ON	Successfully connected	.20	nguaç
	datalogger and the inverter.	OFF	Abnormal connection		
	Shows the	ON	Datalogger is powered up normally	Step 3: M the SN on	

∠WiFi Configuration Step 1: Use you phone to scan the QR code to Step 4: Click "o,", make sure the phone is connected to router WiFi and switch back to the page to fill in

WLAN

configuration completed, click "OK" and back to the the WiFi password, then move to next step. main page. If failed, re-do the configuration process Connect to route or contact the after-sale engineers.



Step 6: Wait for around 10 seconds, After the

Configuring...

Unconfigure(58)s

Configuration succeeded

Configuration succeeded


Datalogger SN:5011981679800A70

Router:WLAN

Step 5: Long press the "Reset" button for 5 seconds until the yellow and green LEDs are quickly flashing. Then click the "It's flashing".




Create the Soliscloud Accoun Step1: Select Owner or Installer for email address






4 Create Plant

Step 1: Enter the main page of Soliscloud APP, click the "Add plant" at the bottom.



Step 2: Input the information of the plant as required. Then click "Done". Click "Create a plant".



Plant picture Only upload jog/png files, and no more th

Step 3: Confirm the plant information.




Step 4: Click "View plant" to enter the plant homepage, then add the datalogger.

0. Cancel



Step 5: Scan the SN number of the datalogger or manually input it.



Can't find barcode?

Note: Scan the datalogger SN, NOT the inverter SN.



"Continu...atalogger" to check the monitoring data. If

the plant has multiple dataloggers, please click

Step 6: Plant creation succeeds Click

FCC warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation.
- Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device. pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and
- - -Connect the equipment into an outlet on a circuit different from that to which the receiver is

technician for help.

- -Consult the dealer or an experienced radio/TV
- This equipment complies with FCC radiation

exposure limits set forth for an uncontrolled environment. This equipment should be installed anoperated with minimum distance 20cm between the radiator & your body.

Please contact us if you have any technical

problems in terms of the product. Please provide the following information as well:

- ♦ Inverter SN
- ◆ Datalogger SN
- ◆ Problem Description

Ginlong Technologies Co., Ltd. No. 57 Jintong Road, Binhai Industrial Park,

Xiangshan, Ningbo, Zhejiang, 315712, P.R.China.

Tel: +86 (0)574 6578 1806 Fax: +86 (0)574 6578 1606

Email: info@ginlong.com Web: www.ginlong.com