



## QUICK START GUIDE

## TABLE OF CONTENTS

QUICK START GUIDE	1
CONNECTING TO YOUR INTERNET	2-3
SETTING UP YOUR REMOTE CONTROL	4
HOW TO RESET YOUR STREAMTV DEVICE	5
LIMITED WARRANTY	6
EXTENDED WARRANTY POLICY	7-8

## QUICK START GUIDE

StreamTV is an innovative media device which allows users to watch Movies, Sports, TV Shows and Live TV via the Internet.

Your StreamTV includes a Remote Control, HDMI Cable and Power Adaptor. **Note that batteries are not included** with your remote control. The Ethernet and Audio Cable are optional and are also not included. **Please Keep This Document.** It illustrates how to 1) connect StreamTV to your home devices, 2) set up your remote control and 3) connect StreamTV to the Internet via Ethernet and Wi-Fi.

### CONNECTING YOUR STREAMTV (FIG.1)

1. Plug your StreamTV into a power socket, then connect it to your television using the HDMI cable. The HDMI cable provides both the audio and video signals from your StreamTV to your television.
2. You may access the Internet by connecting your StreamTV directly to your router via an Ethernet cable or Wi-Fi during system set up (see page 3 for details).
3. Turn on your StreamTV and television, then select the correct HDMI input on your television to which your StreamTV is connected.




FIG. 1: HARDWARE CONNECTION OVERVIEW

## CONNECTING TO YOUR INTERNET

StreamTV allows you to access the Internet via direct Ethernet connection or Wi-Fi

### CONNECTION VIA ETHERNET

We recommend you bring your StreamTV online by directly connecting the StreamTV to your Router via an Ethernet cable. Once physically connected, there is no need to carry out the Wi-Fi Connection steps.

### FIRST TIME CONNECTION TO WI-FI

1. Ensure all Hardware Connection steps have been carried out (Page 1, Fig. 1)
2. Select the Network Tab and press OK (Fig. 2).



FIG. 2: NETWORKING TAB SELECTION

## CONNECTING TO YOUR INTERNET

3. Once Wi-Fi is turned on, your StreamTV will take a few seconds to display available Wi-Fi Networks.




FIG. 3: ACTIVATING WI-FI

4. Select your Wi-Fi Router Name and input your password (Fig. 4). The password can be entered via the number pad on your remote control or via the virtual keyboard on the screen.



FIG. 4: INPUT PASSWORD

For StreamTV support and to view other products and offerings, go to [www.streamtvpro.com](http://www.streamtvpro.com) or call us toll-free at 1-650-200-3242

## SETTING UP YOUR REMOTE CONTROL

1. Insert two (2) AAA batteries into your StreamTV remote control.
2. Place your StreamTV remote control head-to-head with your TV remote (Fig. 5).



FIG. 5: REMOTE CONTROL POSITIONING

3. Press the 'Set' button for 3 seconds on your StreamTV remote. The LED should glow bright red, indicating that the remote control is in programming mode.

4. Select the button on your StreamTV remote control (Pwr, TV IN, VOL+, VOL-) that you wish to copy from your TV remote control. Your LED should flash indicating your remote is in learning mode.

5. Press the corresponding button on your TV remote. Your StreamTV remote LED will flicker quickly confirming the new function has been added.

6. Press the 'Set' button to exit programming mode.

4

### START WATCHING STREAMTV

1. Use your StreamTV remote to navigate through the Menu Tab options (i.e. Movies, TV Shows, Live TV etc.), then select your desired category.
2. Scan and select your desired viewing content and press 'OK'.

### CHILD PROTECTION AND MATURE CONTENT

Adult content is protected on this device with the default passcode '7568'. The default password can be changed at any time by accessing adult section using the default passcode and following the instructions on how to change the passcode.

## HOW TO RESET YOUR STREAMTV DEVICE



1. Turn off and disconnect the power adaptor from the 'DC IN' port.
2. A reset button lives inside the AV port. Press a very thin screw driver into the AV port and you will feel the reset button depress. Press and hold the reset button.
3. Continue pressing the reset button then connect the power adaptor into the 'DC IN' port.
4. Wait a few seconds for your StreamTV to power up.
5. Once your StreamTV has powered up, you will see the android recovery page on your TV monitor. Select 'Wipe Data / Factory Reset'.
6. A confirmation to wipe all your data will display on your TV monitor. Select 'Yes'.
7. Next, select 'Wipe Cache Partition'. A confirmation will display on your TV monitor. Select 'Yes'.
8. Upon completion, select 'Reboot System Now'

5

## LIMITED WARRANTY

NAVAIR warrants the StreamTV device (software and hardware) against defects in materials and workmanship under normal use for a period of 12 months from the date of purchase ("Warranty Period") if used in accordance with the documentation provided with the device. During the warranty period, if a defect arises with the StreamTV device, NAVAIR's sole obligation, and your exclusive remedy, will be to either repair or replace (at our option) your unit free of charge for 12 months from the date of purchase if the product is defective in workmanship or materials. To obtain service under this Warranty, proof of purchase must be provided to NAVAIR. In the absence of a purchase receipt, the warranty period shall be 12 months from the date of manufacture. Contact information for product concern can be found at [www.streamtvpro.com](http://www.streamtvpro.com). In no event shall NAVAIR be liable to replace or repair your unit due to special, incidental, consequential or accidental damages. NAVAIR is not responsible for unit damage caused by accident, misuse, neglect, fire, unauthorized modifications or damage from other external causes, alteration, repair or commercial use. This Warranty does not apply: (a) to consumable parts, such as batteries or protective coatings that are designed to diminish over time, unless failure has occurred due to a defect in materials or workmanship; (b) to cosmetic damage, including but not limited to scratches, dents and broken plastic on parts unless failure has occurred due to a defect in materials or workmanship; (c) to damage caused by use with a third party component or product that does not meet your unit's specifications (NAVAIR Product specifications are available at [www.streamtvpro.com](http://www.streamtvpro.com) and on the unit's package); (d) to damage caused by accident, abuse, misuse, fire, earthquake or other external cause; (e) to damage caused by operating the unit outside published guidelines; (f) to damage caused by service performed by anyone who is not a representative of NAVAIR; (g) to defects caused by normal wear and tear or otherwise due to the normal aging of the unit; (h) if any serial number has been removed or defaced from the unit, or (i) if NAVAIR receives information from relevant public authorities that the unit has been stolen or if you cannot prove in any way that you are the authorized user of the unit.

6

## EXTENDED WARRANTY POLICY

### COVERAGES AND TERMS:

The StreamTV Extended Warranty Plan will cover the StreamTV device (software and hardware) against defects in materials and workmanship under normal use for an additional period of two years after the expiration of the original manufacturer's warranty of one year ("Extended Warranty Period") if used in accordance with the documentation provided with the device. Of importance, the Extended Warranty Plan does not replace the original manufacturer's warranty. The Extended Warranty Plan increases the period of coverage of the original warranty from one year to three years.

During the Extended Warranty period, if a defect arises with the StreamTV device, NAVAIR's sole obligation, and your exclusive remedy, will be to either repair or replace the unit with either a new, rebuilt or refurbish player, at its option. NAVAIR's Extended Warranty for StreamTV does not cover damage caused by accident, misuse, neglect, fire, unauthorized modifications or damage from other external causes, alteration, repair or commercial use. The Extended Warranty provides full coverage for Your Product where the problem is the result of a failure caused by defects in materials and/or workmanship.

### FREE SHIPPING:

This Extended Warranty covers all shipping charges to authorized service centers during the Coverage Term, including shipping to the manufacturer.

7

## EXTENDED WARRANTY POLICY (CON'T)

### WHAT IS NOT COVERED:

- Except as otherwise provided, normal wear and tear;
- Any and all pre-existing conditions that occur prior to the Coverage Start Date of the Extended Warranty
- Natural flaws or inherent design;
- Intentional damage;
- Lost, stolen or irretrievable items;
- Any Product that is fraudulently described or materially misrepresented;
- Secondary or collateral damage;
- Except as otherwise provided, maintenance, service, repair or replacement necessitated by loss or damage resulting from any cause other than normal use, storage and operation of the Product in accordance with the manufacturer's specifications and owner's manual;
- Damage caused by exposure to weather conditions, improper electrical/power supply, improper equipment modifications, add-on products or accessories, attachments or installation or assembly, collision with any other object, vandalism, animal or insect infestation, corrosion, battery leakage, act of nature (any accident caused or produced by any physical cause which cannot be foreseen or prevented, such as storms, perils of the sea, tornadoes, hurricanes, floods and earthquakes) or any other force majeure or peril originating from outside the Product;
- Damage caused by "accumulation", including, without limitation, damage from any repeated use or gradual buildup of dirt, dust, oils or similar, such as hair and body oils, perspiration or darkened bodily contact areas;
- Damage caused by: any improper care, negligence, neglect, intentional acts, misuse or abuse of the Product; any repair, replacement or handling of the Product other than as recommended or authorized by the manufacturer and/or Us; or any failure to comply with the manufacturer's warranty;
- Damage caused by cleaning methods, products or materials.

### WHAT TO DO IF A PRODUCT REQUIRES SERVICE:

File a claim online at [www.streamtvpro.com](http://www.streamtvpro.com) or call us toll-free at 1-650-200-3242 and explain the problem. We will attempt to troubleshoot the problem You are experiencing. If We cannot resolve the problem, We will service Your Product as described in the coverage terms and policy.

### LIMIT OF LIABILITY:

The total amount that We will pay for repairs or replacement made in connection with this EXTENDED WARRANTY will likely exceed Your Coverage Amount. In the event that We make payments for repairs or replacements, which in the aggregate, are equal to the Coverage Amount, or if We provide a cash settlement reflecting the replacement cost of a new item of like kind, quality and functionality or a replacement product of like kind, quality and functionality, then We will have no further obligations under this EXTENDED WARRANTY. WE SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING BUT NOT LIMITED TO, PROPERTY DAMAGE.

### NO LEMON POLICY:

If Your Product has two (2) service repairs completed for the same problem and a third (3rd) repair is needed for the same problem, within any twelve (12) month period, the Product will be replaced with a comparable product or a cash settlement will be provided.

8

## EXTENDED WARRANTY POLICY (CON'T)

### FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

材质:内页128g铜版纸+彩色印刷+骑马钉 (双排) +封面尾页157g铜纸 (不过胶)

尺寸: 165x100mm 公差±1mm

共12P