

Manual

Introduction

The Bluetooth headset uses low-radiation Bluetooth short-range wireless communication technology. When using Bluetooth headsets, you can make and receive hands free calls at will, whether you are traveling, exercising or taking advantage of leisure entertainment. You can connect the headset to a compatible Bluetooth wireless technology such as cell phones and other Bluetooth enabled devices.

Before using the headset, please read this manual carefully. You can also read the manual of your mobile phone or other Bluetooth enabled device to understand how to use/important safety and maintenance information.

With Bluetooth wireless technology, you can connect to compatible communication devices without using cables. Bluetooth connection does not require keeping the mobile phone and earphones facing each other, but the maximum distance between the two should not exceed 10 meters. The Bluetooth connection may experience interference from walls, large physical obstacles or other electronic devices causing the connection distance to be shortened. This headset complies with Bluetooth V5.0+EDR specifications and supports V5.0 Bluetooth headset mode and V5.0 Bluetooth hands-free mode.

1. Charging

- 1) This product uses 110mA polymer batteries. It is recommended to charge for 2 hours before using it for the first time;
- 2) The red light is on when charging, the blue light is on when fully charged, about 2 hours (Don't charge more than 3 hours to avoid overcharging);
- 3) This product **cannot** be used while charging;
- 4) The maximum input voltage of the product is 3.7VDC and 2A maximum current.

2. Pairing: (This product must be paired with the mobile phone/mobile device before use)

- 1) First confirm whether your device has Bluetooth function (check your mobile device's operation manual)
- 2) Press and hold the power button until the red/blue colleague flashes quickly and emits a "power on" sound, about 5 seconds, and enters the pairing state. At this time, press the power button twice to enter the Chinese and English language selection mode according to your choice (Bluetooth The headset defaults to Chinese)
- 3) Use the Bluetooth function of the mobile phone to search for Bluetooth devices, you can find "Newmine", select the device to connect
- 4) When your Bluetooth device is turned on and there is no Bluetooth connection, it will automatically shut down after it is set up (about 5 minutes)

3. Instructions for use:

- 1) **Powering on:** Press the power button for four (4) seconds or until hear you hear a "power on" sound. When the red and blue lights flash quickly to enter the search device

type/device pairing connection is successful, the blue light flashes once continuously for about 5 seconds, and enters the standby working state.

Note: If the paired device is not connected for 5 minutes, the headset will automatically shut down

2) **Answering a call:** After the earphone hears the prompt tone from the mobile device, press the function button once to answer the call, or press the answer button on the phone to answer the call.

3) **Outgoing call:** In the standby mode, quickly press the power button twice to broadcast the last call.

In the standby working state, press the outgoing call mode of the mobile phone and enter the number to make a call

4) **Ending the call:** To end the call, press the power button the headset will emit a prompt tone.

If during a call, the other party hangs up the headset will emit a beep to automatically end the call.

5) **Volume increase/decrease:** Short press the +/- button during music/calls to increase and decrease the volume, long press to continuously increase and decrease the volume to the maximum volume, the headset emits a "maximum volume" prompt.

4. Shutting down

Press and hold the power button for about 4 seconds, the red light flashes twice quickly and the headset emits a beep and will soon turns off.

When the earphone is far away from the receiving range, it will automatically shut down after about 5 minutes of inactivity.

5. Low battery

When working, your device will prompt you that the battery is low. Charge the headset as soon as possible for uninterrupted use.

Common Problems and Troubleshooting

1. When the red indicator light flashes continuously and quickly, the headset emits a rapid tone indicating that the battery of the Bluetooth headset is low, please charge the headset as soon as possible.

2. The device cannot be turned on. For safety reasons, the basic power of the device will be controlled at about 20~50% when it leaves the factory. Perhaps the power of the new device will be exhausted. If you cannot turn on, please charge the headset first and then turn it on.

3. If the headset cannot be turned on after charging for twenty minutes, let charge another 20 minutes. This should fully charge the headset assembly and allow normal function.

4. No prompt when charging

If the headset battery is completely exhausted or is charged for the first time after a long period of non-use, there may be no charging prompt for the first few minutes. After a while, the red indicator light will light up to indicate the concept of charging.

5. No sound in the headset

- Make sure the headset and mobile phone have been paired and connected successfully
- Make sure the headset is turned on
- Make sure that the distance between the headset and the mobile phone is not more than 10m
- Make sure your mobile device is within the range of sufficient signal strength
- Some mobile devices only support one Bluetooth headset. When more than one Bluetooth headset is paired with it, the connection may be interrupted.

Product maintenance

- The original accessories may reduce the performance of the sound device/personal injury/electrical short circuit and the time limit of the warranty.
- Disassembling and disassembling your Bluetooth headset may cause damage to the headset and will void the warranty.
- Do not place the headset in a dusty or dirty environment
- Use a clean/soft/dry cloth to clean your headset
- Keep the headset in the original packaging when not using it
- Don't let children play with the headset, they may hurt themselves or damage the headset
- Do not place the headset in an environment that is too hot or too cold, otherwise the headset may be temporarily unusable.

Battery maintenance

- Please go to a qualified repair center to remove or replace the battery
- If used carefully, the life of the rechargeable battery will be very long
- The charging temperature of the rechargeable battery is between 10°C and 45 °C (50 ° F and 113°)
- Use at room temperature to reach the maximum capacity of the battery.
- Outdoor use at low temperatures will cause the battery capacity to decrease.
- When the headset is not used for a long time, charge at least once every two months.
- The use and standby time of the headset battery is related to the specific use conditions, and the use and standby time are for reference only.

Safety rules

1) Do not dismantle or modify the headset for any reason, otherwise it may cause the headset to malfunction or burn out, which are not covered by the warranty.

- 2) Do not get the equipment wet with liquids, otherwise it will cause serious damage to the equipment. Damage caused by water entering the equipment will not be guaranteed by the manufacturer.
- 3) Do not place the device in an environment where the temperature is too low or too high (below 0°C (32 °) or above 45°C (113° F);
- 4) Please avoid using the indicator light near the eyes of children or animals
- 5) Do not use this equipment when thunderstorms are present. Thunderstorms can cause equipment to malfunction and increase the risk of electric shock.

Packing list

Bluetooth headset
Micro-USB charging cable
Silicone ear tip caps
Certificate of conformity
User's manual

After-sales service and support

1. The company solemnly promises: For all the company's series of products purchased from the company or a dealership, within the effective warranty period, the company will provide normal warranty services for the product. The warranty service period of the product is effective from the date of purchase (subject to the date recorded in the official purchase voucher-invoice or valid receipt). The company's series of product hosts (excluding accessories/accessories) are guaranteed for one month and one year for warranty.
2. Please ask for the purchase voucher when you buy our products and keep it properly, and bring it with you every time you receive service! If you cannot show the purchase invoice or valid receipt and other vouchers, if you cannot confirm the product warranty period, the free maintenance period, the production date on the production label of the product body will be the starting time of the warranty.
3. For all products within the warranty period and under normal use and maintenance, failures caused by the components of the machine can be repaired and replaced free of charge after the company's technicians have checked and confirmed.
4. The company is not responsible for special/accidental or indirect losses of users and distributors.
5. The following conditions are not covered by the warranty
 - Man-made damage
 - Damaged body production label
 - Damage caused by operation not in accordance with the instruction manual or installation error
 - Damage caused by all natural disasters and force majeure factors such as floods/fires
 - Failure and damage caused by repair/modification/modification or disassembly by non-authorized service personnel of the company.
 - Serious damage/scratches/burned circuit board on the casing
 - The time stipulated in the warranty period has expired

- All accessories of the product are not covered by the warranty

6. When replacing the product within the warranty period, please be sure to bring the parts of the faulty device to the dealer's location

7. The repair service and replacement during the warranty period will not be extended or restarted.

8. The above guarantee content is limited to the warranty period written on this warranty card and the services provided by the company's customer service center. If you have any questions, please contact our customer service center within the corresponding time.

9. For related matters, please log on to our company website online or call for consultation

Please take attention that changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.