

WELCOME GUIDE

* For safety issue, the product remains low capacity during shipping. Please read this Guide carefully before using the product.

PACKAGE CONTENTS

BASIC PRODUCT SPECIFICATIONS

Earbuds	
Range	10m
Music play time	Up to 8.5 hrs on a single charge; case provides additional 27 hrs (ANC OFF)
Music play time	Up to 7 hrs on a single charge; case provides additional 22 hrs (ANC ON)
Battery capacity	60mAh(each earbud)
Charging time	Approx. 2 hrs
* oraimo Lab test results	
Charging Case	
Battery capacity	550mAh
Charging time	Approx. 2 hrs
* If the charging case is fully charged, it can recharge the earbuds about 3 times.	

USING YOUR EARBUDS

Charging

USING YOUR EARBUDS

Controls

- 1 beep: Answer the phone call.
- 2 beeps: Long press till you hear 2 beeps. Refuse to answer the phone call.
- X2: Hang up the phone call.

USING YOUR EARBUDS

ANC OFF

Long press till you hear 2 beeps

Transparency Mode

Long press till you hear 2 beeps

ANC ON

Long press till you hear 2 beeps

FAQ

Question 2 Only one earbuds works/sound from only one side.

Reason The left and right earbud are not connected with each other.

Solution Place both earbuds in the charging case (the case light will flash green to indicate successful operation) and close the case, open the case after 5 seconds and take out your earbuds.

FAQ

Question 4 Bad sound quality/Low volume.

Reason The earbud speaker or sound hole is blocked with dirt.

Solution Use a cleaning cloth with alcohol to remove dirt from the speaker or sound hole.

PRODUCT OVERVIEW

USING YOUR EARBUDS

Pairing

Please fully charge the product and remove the protective film before initial use.

Solution 1 Select appropriate eartips in accordance with your ear canal; 2 Follow the correct instructions in wearing your earbuds, rotated ear earbuds forward and backward to fit. (Product performance may vary with the user's ear size, selected ear plugs, ear canal structure, wearing posture, chewing, movement during usage and other conditions.)

USING YOUR EARBUDS

Controls

- X1: Play/Pause
- X2: Next Track
- X3: Previous Track

USING YOUR EARBUDS

Controls

- 4 beeps: Long press till you hear 4 beeps. Switch to game mode.
- 2 beeps: Long press till you hear 2 beeps. Activate voice assistant.

FAQ

Question 1 Earbuds won't power on/work.

Reason Charging case or earbuds has no battery.

Solution Place your earbuds in the charging case and charge for more than 30 minutes.

FAQ

Question 3 Earbuds can not be charged.

Reason The earbuds may be smudged and fail to make contact for charging.

Solution Use a cleaning cloth with alcohol to remove dirt from the pogo pin of earbuds and charging case.

FAQ

Question 5 Bad call quality.

Reason 1 The microphone is blocked with dirt. 2 The microphone is blocked after the earbud comes into contact with water or sweat. 3 The other earbud is not in the case when the other earbud is worn to have a call.

Solution 1 Use a cleaning cloth to remove dirt from the microphone. 2 Use a hair dryer to blow into the microphone hole for 10 seconds. 3 For single-ear use, place the other earbuds in the charging case.

FAQ

Question 6 Phone fails to connect to the earbuds.

Reason 1 Earbuds are already connected to another device; 2 Earbuds have no battery.

Solution 1 Disconnect and "Forget" your earbuds on the other connected device and place the earbuds in the charging case with lid closed. Then open the case to check the indicator. If the earbud is flashing red and green alternately, you can continue to connect your phone with the earbuds again; 2 See solution to Question 1.

FAQ

Question 8 Poor performance with ANC noise cancellation.

Reason Earbuds are worn incorrectly.

Solution 1 Select appropriate eartips in accordance with your ear canal; 2 Follow the correct instructions in wearing your earbuds, rotated ear earbuds forward and backward to fit. (Product performance may vary with the user's ear size, selected ear plugs, ear canal structure, wearing posture, chewing, movement during usage and other conditions.)

FAQ

Question 7 Poor touch control response.

Reason 1 Touching an incorrect position for control; 2 Waited too long between touch control actions; 3 Your hands or the earbuds may be smudged by water or sweat.

Solution 1 Follow the user manual to touch the correct position; 2 Keep the time between touch actions under 0.6 seconds; 3 Wipe off any water and sweat before touch operations.

ATTENTION

Please use the earbuds correctly according to the instructions.

- Use original or certified cables
- Do not expose to liquids
- Do not disassemble
- Avoid dropping
- Avoid extreme temperatures
- Do not use the product outdoors during a thunderstorm
- Do not use any corrosive cleaner/foam to clean

CONSIDERATE HINTS

- Do not turn up the volume to a far high level constantly as this could shorten the service life of this product or impair your hearing.
- When encounter any fault during operation, please cut off the power supply and disconnect the Type-C cable to prevent further damage to the product or other components.
- The wireless transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

CUSTOMER SERVICE

365 DAYS WARRANTY

365 DAYS WARRANTY
Email: service@caricare.com

WARRANTY CERTIFICATE

Name: _____
Address: _____
Tel. No.: _____
Date of purchase: (dd/mm/yy)
Store name: _____
Warranty period: _____

ES CERTIFICADO DE GARANTÍA

Nombre: _____
Dirección: _____
Nº de teléfono: _____
Fecha de compra: (dd/mm/aa)
Nombre del establecimiento: _____
Período de garantía: _____

PT CERTIFICADO DE GARANTIA

Nome: _____
Endereço: _____
Tel.: _____
Data de compra: (dd/mm/aa)
Nome da loja: _____
Período da garantia: _____

ID SERTIFIKAT GARANSI

Nama: _____
Alamat: _____
Alamat: _____
Tanggal pembelian: (dd/mm/yy)
Nama toko: _____
Periode garansi : _____

AR شهادة الضمان

الإسم: _____
العنوان: _____
رقم الهاتف: _____
تاريخ الشراء: (يوم/شهر/عام)
اسم المتجر: _____
فترة الضمان: _____

For more information, please visit:

www.oraimo.com @oraimo_accessories

FreePods 4 | OEB-I105D |