

Milesight

# QUICK START GUIDE

DS3604

IoT E-INK DISPLAY  
FEATURING LoRaWAN®



## 1. Packing List



1 x DS3604 Device



1 x Quick Start Guide




1 x 3M Double-Sided Tape



1 x Warranty Card

## 2. Hardware Introduction



E-Ink Screen

Screen Button

NFC Area

**Screen Button:** tap to receive downlink commands like screen content update, device reboot, etc.

## 3. Power Button and Buzzer Patterns

DS3604 equips with power button inside to switch on/off the device for emergency use. Usually users can use NFC to complete all steps.

Function	Action	Buzzer Status
Power On/Off	Press and hold the power button for more than 3 seconds.	Off→Buzz Slowly
Reset to Factory Default	Press and hold the power button for more than 10 seconds.	Buzz Quickly

## 4. Configuration Guide

1. Download "Milesight ToolBox" App on an NFC-supported smartphone.



Android



iOS

Milesight



Cloud App




Quick Start Guide

All software & files can be downloaded from  
<https://www.milesight-iot.com/documents-download/>

**Better Inside, More in Sight**

Milesight IoT Co., Ltd. | [www.milesight-iot.com](http://www.milesight-iot.com)  
Building C09, Software Park Phase III, Xiamen 361024, Fujian, China


2. Open "Milesight ToolBox" App and attach the smartphone with NFC area to read/write the device until App shows a successful prompt. It's suggested to configure a device password for security. (Default password: 123456)



## 5. Installation


### Fixed by 3M Tape

Paste 3M tape to the back of the device, then tear the other side and place it on a flat surface. Please note the screen direction when installing.




### Fixed by Screws

1. Release the screw on the bottom of device and remove the back cover, mark the installing holes to the wall according to the holes on the back cover.




2. Fix the back cover with two M3 screws and install back the device, then fix the bottom of device to back cover with the fixing screw.



### Installation Note

If the installation location is a metal surface or includes metal materials, please leave the upper part of device 3 to 4 cm away from the surface to avoid the signal problem.



## 6. FCC Statement

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.