


INSTRUCTION MANUAL

Bluetooth Speaker & Work Light

SP81400



Features

1. Durable ABS construction
2. Long range 5.0 Bluetooth capability
3. 2 x Speakers 6W total
4. 4400mAh rechargeable Battery, can also be used as power bank
5. COB LED Light with High, Low, brightness control
6. Carabiner, so unit can be hung for convenience
7. Strong magnetic base and end, for secure positioning.

Scope of delivery

1. Main unit
2. Carabiner (quick release clip)
3. Charge cable
4. Clam shell storage case
5. User Manual

Specifications

1. 10W COB LEDS High: 800 Lumen; Low: 400 Lumen
2. Sound output 6W (2 x 3W Speakers)
3. USB to USB-C Charging cable, 80cm
4. Battery: 3.7V, 4400mAh
5. Lighting run time : 5hours (High Mode); 8hours (Low Mode)
6. Charging Time: 4-5Hours via USB Cable
7. Size: 206mm long x 76mm Diameter
8. Weight: 0.59Kg (Includes battery)

Operating instructions

Charging

Lift the weather proof rubber flap at the magnetic end of the main body.

Connect the USB-C cable end (smallest end) into the main unit, then connect the larger USB cable end to any suitable USB outlet. This could be, your computer, vehicle, phone charger or portable power bank, etc.

Once connected the battery charge indicator lights will illuminate and show the charge level. When fully charged all 4 lights will show solid.

Be sure to reinsert the weather cover before taking the unit into any wet, or dirty environments.

Bluetooth connection

First ensure your phone or other Bluetooth enabled device has its Bluetooth turned on (see Settings).

Then press and hold the center button (for 3 seconds), on end of main body. The unit will respond with the words "Power on, Bluetooth" then shortly afterward "Bluetooth connected". The initial pairing may not occur automatically. In which case open the Bluetooth on your device and manually select the device connection. Once paired it will automatically connect whenever the Speaker is powered on.

On unit the volume can be adjusted by the + or – buttons and track selection made via the forward and reverse buttons.

To turn off press and hold the center button (for 3 seconds), the unit will respond with the words "Power Off"

Light Operation

The ON / OFF button for the light is located adjacent to the COB LED's

Warning: Do not look at the LED's, face the unit away from you and press the button once to turn ON Low lighting, press the button once again for High lighting and a third time to turn the light OFF

Operating temperature: 0°C -35°C

FCC regulatory conformance:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two

conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Limited Warranty Policy

This Limited Warranty applies only to new products. It is a condition of this Limited Warranty Policy that all servicing requirements are completed as listed in the owner's manual, (said servicing is at the owner's expense). We recommend that all servicing is completed by an Authorised Service Agent and that records of said servicing are retained by the purchaser as proof in the event of a warranty claim. The Limited Warranty period commences from the date of purchase.

SP Tools agrees, subject to the conditions of this warranty, SP Tools or its Authorised Service Centre will perform necessary warranty repairs on the product without charge for parts or labour if in the opinion of SP Tools, the product does not perform in accordance with its specifications during the Limited Warranty period, due to any fault in manufacturing, materials and/or workmanship within the specified warranty period. This warranty only applies to items purchased through SP Tools or its Authorised Distributors or Dealers. Warranty cover only applies if valid proof of purchase is presented at the time of making a claim.

The purchaser's attention is drawn to the following

To the extent permitted by law and subject to the Limited Warranty, and as part of the terms of the sale of the equipment or part thereof: SP Tools shall not be liable for any form of loss, damage, cost, injury or harm of any kind (whether direct, indirect, special or consequential) howsoever arising from the use or supply of the equipment to the purchaser.

The Warranty Period

12 months (1 Year)

Exclusions to Limited Warranty Policy

- 1.1 Fails due to an accident (including liquid spillage), abuse, misuse, neglect or normal wear and tear.
- 1.2 Has been used in a manner other than for which it was originally designed.
- 1.3 Has been tampered with or is otherwise than as supplied by SP Tools.
- 1.4 Where any damage, malfunction or other failure of the equipment or any part thereof resulted directly or indirectly from unauthorized persons, adjusting or failing to adjust any part requiring normal maintenance and service. (Examples include tightening of screws, nuts and bolts, the replacement of brushes or the correct storage of batteries).
- 1.5 Malfunctions due to the use of defective or incompatible accessories.
- 1.6 Is damaged by lightning or thunderstorm activity.

Claiming warranty

The Warranty may be claimed on in the following manner:

- 2.1 In order to make a claim under this warranty, the purchaser must deliver the equipment or any part thereof to a repair agent and pay all costs of transportation.
- 2.2 The purchaser must deliver to the repair agent written reasons why the purchaser considers that the purchaser has a claim under the warranty and must provide all necessary details, including:
 - } *The place, date and from whom the unit or part was purchased.*
 - } *The unit or part involved Model and Serial Number.*
 - } *The defect, malfunction or failure in respect of which the claim is being made.*
- 2.3 If the warranty claim is valid, the repair agent will carry out repairs and return the product at no charge to the purchaser. These repairs are limited to the warranty fault identified and as such will not include any other faults due to misuse, abuse, failure to maintain, fair wear and tear or the replacement of serviceable items such as brushes, bearings, batteries and the like.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Note: After inspection units which have failed due to **non-warrantable** causes will be subject to freight, repair and or quote charges.

THE PURCHASE DOCKET (OR SIMILAR PROOF OF PURCHASE) MUST BE RETAINED BY THE CUSTOMER AS IT WILL BE REQUIRED IN THE EVENT OF A CLAIM FOR WARRANTY BEING MADE.