


Quick Installation Guide

PCE-3100/PCE-9260/OKN-AX200-D/PCE-AX200/ PCE-AX210
PCIe Wireless Card

1 Connect to a Computer



- Turn off your computer, unplug the power cable and remove the case panel.
- Locate an available PCIe x1 slot and carefully insert the adapter.
- Connect the antenna to the adapter.
- Replace the case panel, plug in the power cable and turn on your computer.



Bluetooth connection

Connect Bluetooth cable after the **b** step above, the **White** connector to the Adapter socket, the **Black** one to the **USB(F-USB)** socket on the Motherboard.

2 Install Driver

- Insert the CD and run the driver file to finish the driver installation.
- You can also download the driver from the QR code or <https://downloadcenter.intel.com/product/59485/Wireless-Networking>
- Follow the InstallShield Wizard to complete the installation.

Note: There are WiFi driver and Bluetooth driver, both of them should be installed.




3 Join a Wireless Network



- Click the network icon () on the taskbar.
- Select your Wi-Fi network, click **Connect** and enter the password when prompted.

1 ハードウェアのインストール




- 電源を切り、電源コードを抜き、ホストのサイドバージョンを取り外します。
- この NIC を **PCIe x1** スロットに慎重に取り付け、付属のネジで背面パネルに固定します。
- 付属の Bluetooth ケーブルの白い端をこのネットワークカードに接続し、黒い端をマザーボードの USB ソケット (F-USB) に接続します。
- アンテナをネットワークカードにインストールする。
- サイドパネルを取り付け、コンピューターの電源コードを接続し、電源を入れます。

2 ドライバー

- 付属の CD を挿入し、Wi-Fi および Bluetooth ドライバーをインストールします。
- QR コードまたは以下のリンクをスキャンして、最新のドライバーとドキュメントを入手できます。
<https://downloadcenter.intel.com/product/59485/Wireless-Networking>



3 ネットワークに接続する



- タスクバーのワイヤレスアイコンをクリックします ()。
- 適切なワイヤレスネットワークを選択して、インストールとインターネットアクセスを完了します。
- 楽しめ。



MADE IN CHINA

Technical Support: ufon.sales@gmail.com
Add: D1113, Longguang Business Center, Shenzhen, China

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.