



首次快速使用KZ-AZ09耳挂



- ① 打开充电仓盖自动开机,耳挂自动开机并进入TWS配对。
- ② 6秒后打开耳挂蓝牙搜索并连接【AZ09】。
- ③ 以后每次只需将耳挂从充电仓中取出,耳挂与手机自动回连配对。
*请确认手机是否开启蓝牙模式,否则会导致自动回连失败。

正确舒适的佩戴



- ① 正确区分左右耳挂,查看耳挂上的标识,"L"适用于左耳,"R"适用于右耳。
- ② 蓝牙耳挂连接耳机,将耳机头放入耳道口,轻轻一推,平滑的推入耳内。
- ③ 将耳挂置于耳背,轻轻旋转调整耳机的密封度和舒适度,获得最佳的听觉体验。

功能操作指示

左右耳挂多功能按键均可使用,功能可能因设备而异



- 手动开机**
长按触控键3秒开机。
(开机后耳挂红灯亮2秒并有提示音)
- 左右耳挂配对**
开机后耳挂自动进入配对状态。
(配对成功后耳挂红灯交替闪烁,副机蓝灯慢闪,并有提示音)
- 手动关机**
长按功能键6秒耳挂关机。
(关机时耳挂红灯亮2秒熄灭,并有提示音)
- 三方通话**
通话过程中,有新来电,有以下几种操作方式:
(1)无操作,保持当前通话,来电等待
(2)单击任意耳挂多功能按键,接听三方来电,挂断当前通话
(3)长按任意耳挂多功能按键2s,接听三方来电,保持当前通话

功能操作指示




- 暂停/播放音乐**
音乐播放时,单击多功能按键暂停播放,再单击多功能按键继续播放。
- 上一曲/下一曲**
音乐播放时,双击左耳按键,切换到上一曲;双击右耳按键,切换到下一曲。
- 接听/挂断电话**
来电状态下,单击按键接听电话,再单击按键挂断电话。操作端有提示音。
- 拒接来电**
来电状态下,长按多功能键拒接电话。
- 启动Siri (语音助手)**
长按多功能按键2秒后并放开,启动Siri (语音助手),功能可能会因设备而异。

耳机充电指示



- (1) 了解耳挂电量
① 使用耳挂时,当耳挂电量过低,每30秒播报1次低电量提示音,约5分钟后耳挂低电关机。(耳挂提示红灯每30秒闪4次)
- (2) 耳挂充电
耳挂置入充电仓并合上充电仓盖后,耳挂关机进行充电,完全低电量情况下,约1小时左右耳挂机充电

充电仓充电指示



- (1) 了解充电电量
① 置入耳挂或打开/关闭充电仓盖时,舱内LED灯慢闪三次熄灭,显示充电仓当前电量。
● 红灯:0-30%电量 ● 黄灯:30-70%电量 ● 绿灯:70-100%电量
- (2) 充电仓充电
插入充电线,对充电仓进行充电,拔掉充电线,指示灯熄灭。
● 充电中:舱内LED红灯长亮 ● 充满电:舱内LED绿灯长亮。
- ⚠ 充电注意事项
① 为保障设备的使用寿命和安全性,请勿使用快速充电器进行充电。
② 必须选择正规厂家认证的充电器。
③ 重复充电和放电时间推移会导致电池效能下降。

单耳使用指示

左右耳挂均可单独使用



- ① 取出任意耳挂,耳机会自动回连最后连接的设备,耳挂可单耳使用;
 - ② 耳挂提示连接成功,可播放音乐,语音通话;
 - ③ 此时如需双耳使用,请从充电仓取出另一边耳挂即可。
- 注:耳挂与手机连接时,将任意单耳放入充电仓关机,另一边单耳保持原有模式工作;再次取出耳挂时自动回连主机。

清除耳机配对信息



清除耳挂配对信息能解决大部分耳挂连接不成功等问题

- ① 从充电舱内取出任意一只耳挂,长按多功能键6秒,使其耳挂关机。
- ② 长按多功能键,直到耳挂红灯交替闪烁后松手,单击4次多功能按键,此时红灯同时闪烁3次后耳挂关机。
- ③ 再取出另外一只耳挂重复上述操作。
- ④ 左右耳挂分别操作完成后同时放入充电舱内,并合上充电舱盖完成清空配对信息。

安全规则

- ① 请勿以任何理由拆卸或改装产品,否则可能导致产品发生故障或烧毁;
- ② 请勿将产品接触液体、油或其他挥发性液体,否则可能造成设备严重损坏;
- ③ 请着重提防锋利的边缘,不平的金属表面、金属件、配件和包装,以免出现任何可能的伤害;
- ④ 请勿将产品置于温度过低或过高(-5°C以下或45°C以上)的环境;
- ⑤ 请避免靠近儿童或动物的眼睛使用设备指示灯;
- ⑥ 请勿在雷暴天气下使用产品,雷暴可能会导致设备工作不正常并增加触电的危险;
- ⑦ 请勿在有危险的情况下使用产品,如驾车、过马路或从事需要全神贯注的任何活动时,或处在此类环境中。

产品问题解决方案

问题	解决方案
双耳使用时,仅单耳有声音?	原因是双耳挂间未配对成功,建议清除蓝牙配对信息,重新连接
手机(其他设备)搜索不到耳挂?	请将耳挂放回充电舱盖上舱盖再次取出,关闭设备蓝牙并重新连接
耳挂不能开机或自动关机?	耳挂电量不足,请及时充电
耳挂断开连接?	耳挂超出设备有效范围时会断开连接,2分钟内回到蓝牙范围内自动重新连接
耳挂自动回连失败?	请确保手机开启蓝牙模式,否则无法自动回连
连接后无声音?	连接不成功,请重新连接
耳挂充不进电?	耳挂放置不正确,请重新置入充电舱
通话有杂音?	换一个通话环境或将耳挂与设备距离拉近
耳挂信号断续?	将耳挂放在耳机同侧并远离外界干扰信号
与电脑配对不成功?	请确认电脑是否有蓝牙功能,如若没有可自行购买一个蓝牙适配器
无法使用AAC传输	苹果手机默认支持AAC模式传输,安卓机型则需要升级Android 10以上的版本

注:此手册内容仅供参考,如有更改恕不另行通知。

产品保修卡



深圳市原泽电子有限公司 出品

地址:广东省深圳市宝安区新安街道龙井社区宝城2区湖海路东(酒店)数字文化创意园2008B 105号
生产厂:东莞市原泽电子科技有限公司
地址:东莞市原泽电子科技有限公司
邮编:2945269490@qq.com

保修条例

- 一、购买本产品,请仔细阅读以下保修条款,以确保产品得到有效保修。
1. 保修时需同时提供本保修卡;
 2. 产品保修期为一年,保修期内如产品发生故障,原器件品质不良或制作问题,经检验属实,本公司提供免费维修及更换;
 3. 保修卡不得涂改、伪造等。
- 二、下列原因造成产品损坏不能正常使用,不在保修范围内。
1. 未按说明书使用造成的产品损坏;
 2. 一切人为或意外及自然灾害造成的产品损坏;
 3. 未经本公司认可的维修、改装、拆卸等造成的产品损坏;
 4. 产品表面外壳的老化、刮伤、划痕等。
- 三、保修期满后,用户仍可获得本公司的维修服务,但需支付相应费用。
- 四、本公司保留对此保修卡上内容的修改权和解释权。

用户信息

客户姓名 _____

下单ID _____

产品型号 _____

购买日期 _____


联系电话 _____

联系地址 _____

经销商 _____


如产品有任何问题,请及时与我司联系。祝您生活愉快!

First Fast Use Of KZ-AZ09



- ① Open the charging case cover and automatically turn on, the ear-hook automatically turns on and enters TWS pairing.
- ② Opening the mobile phone Bluetooth search and connect to 【AZ09】 after 5 seconds.
- ③ Earphone and mobile phone automatically match after the first time taking out the earphone from the charging module.
*Please confirm whether the phone is in Bluetooth opening mode or not, otherwise it will fail to automatically connect.


Correctly And Comfortably Wearing



- ① correctly distinguish the left and right earphones, and check the logo on the earpiece. "L" is applicable to the left ear, while "R" is applicable to the right ear.
- ② Connect the Bluetooth ear-hook to the earphone, put the earphone head into the ear canal mouth, gently push it, and push it straight into the ear.
- ③ Place the ear-hook on the back of the ear and slightly rotate it to adjust the sealing and comfort of the earphone for a better audio experience.


Function Operation Indication

Left and right earphone touch keys are available, The functions may different depending on the device



- Manual startup**
the left and right earphones press the touch key for 3 seconds to turn on.
(The blue light of the earphone indicator will be on for 2 second and there will be a prompt sound.)
- Pairing left and right earphones**
When the earphone is turned on, it will automatically enter the pairing state.
(After the pairing is successful, the red & blue lights of the main unit alternately flash, the blue light of the auxiliary machine flashes slowly, and there is a prompt tone.)
- Manual shutdown**
Press the control button for 6 seconds, and the earphone will be shut down.
(When the machine is shut down the red light is always on for 2 seconds and with a prompt sound)
- Three-way calling**
During the call, there are new calls. There are the following operation modes:
(1) No operation, keep current call, call waiting.
(2) Click any ear-hook multi-function button to answer three-party calls and hang up the current call.
(3) Long press any ear-hook multi-function button for 2s to reject the three-party call and keep the current call

Function Operation Indication




- Pause/Play Music**
When playing music, click the control button to pause playing, and then click the touch key to continue playing.
- Previous/Next music**
When playing music, double-click the control button of the left ear to switch to the previous song. Double-click the control button of the right ear to switch to the next song.
- Answer/hang up**
during the calling state, click the control button to answer the phone, and then click the touch key to hang-up the phone.
- Reject Call**
during the calling state, press the control button long to reject the call.
- Start Siri (Voice Assistant)**
Press the control button for 2 seconds to start Siri (Voice Assistant). This function may vary from device to device.
- High-performance mode**
Press the multi-function button three times to enter or exit the low-latency high-performance mode.

Earphone Charging Indication



- (1) Understand the earphone's power
① When using the earphone, when the power of the earphone is too low, the low-power tone is broadcast every 30 seconds, and the earphone is powered off after about 5 minutes. (earphones indicate red light flashes 5 times per minute)
- (2) Earphone charging
After the ear-hook is put into the charging case and turn off the charging case cover, the ear-hook is turned off for charging.
When the battery is completely low, the bluetooth ear-hook will be fully charged in about 2 hour


The Charging Cabin's Charge Indication



- (1) Understanding of the electric quantity of the charging cabin
① When putting the earhook into the charging case, or opening/closing the charging case cover, the LED light in the case flashes slowly three times and goes out, indicating the current battery level of the charging case.
● Red light: 0-30% power ● Yellow light: 30-70% power ● Green light: 70-100% power
- (2) Charging of charging cabin
Plug in the charging line to charge the charging cabin. Unplug the charging cable and the indicator light goes out.
● Charging: LED red light in the cabin is always on.
● Fully charged: the LED green light in the cabin is always on.
- ⚠ Charging Considerations
① In order to ensure the service life and safety of the equipment, do not use the fast charger to charge.
② The charger certified by the regular manufacturer must be selected.
③ Repeated charging and discharging will lead to the decrease of battery efficiency as time passes.

Single Ear Using Instruction

Can switch to left and right earphone freely



- ① Take out any earphone, the earphone will automatically connect back to the last connected device, and it can be used as a single ear;
 - ② The ear-hook prompts that the connection is successful, and can play music and voice calls.
 - ③ If you need to use both ears at this time, please take the other side of the earphone from the charging compartment to start using the ear.
- * Note: The earhook has been connected to the mobile phone, put any stand-alone device into the charging case and shut down, and the other stand-alone device keeps working in the original mode; when the earhook is taken out again, it will automatically return to the host.

Clearing Of Earphone Pairing Information



Clearing earphone pairing information can solve problems such as unsuccessful connection of most earphones.

- ① Take out any ear-hook from the charging case, press and hold the multi-function button for 6 seconds to turn off the ear-hook
- ② Press and hold the multi-function button until the red and blue light on the ear-hook flash alternately and then let go. Click the multi-function button 4 times. At this time, the red and blue lights flash 3 times at the same time and the earphone will shut down.
- ③ Take out the other ear hook and repeat the above operation.
- ④ After the left and right ear-hooks are operated separately, put them into the charging case at the same time, and close the charging case cover to complete the clearing of the pairing information.

Safety

- ① Do not disassemble or modify the earphones for any reason, or the earphones may break down or burn out;
- ② Do not touch the equipment with liquid, oil or other volatile liquid, or it may cause serious damage to the equipment;
- ③ Beware of sharp edges, uneven metal surfaces, metal parts, fittings and packaging to avoid any possible damage;
- ④ Do not use the equipment in the environment temperature too low or too high (below -5°C or 45°C above);
- ⑤ Please avoid using the device indicator light close to the eyes of children or animals;
- ⑥ Do not use the equipment in thunderstorms, which may lead to abnormal operation of the equipment and increase the risk of electric shock.
- ⑦ Please do not use this product in dangerous places.

Product Problem Solutions

Problems	Solution
Does only one ear have the sound when using both ears?	It is recommended to clear the Bluetooth pairing information and reconnect because the pair of earphones was not paired successfully.
Can mobile phone (other devices) not find Bluetooth?	Please put the earphone back on the charging hatch cover and take it out from the hatch cover again, close the device Bluetooth and reconnect.
Can earphones not be turned on or off automatically?	The earphone has not enough power. Please charge them in time.
Are earphones disconnected?	When the earphone is out of range, it will be disconnected and automatically reconnect within 3 minutes if return to the scope of Bluetooth.
Does the Earphone fail to auto-reconnect?	Make sure your phone is in Bluetooth mode, or it will not be able to automatically reconnect.
Is there no sound after connection?	Connection is not successful, please reconnect.
Can the earphones not be charged?	The earphones are not placed correctly, please re-posit the charging cabin.
Is there a noise on the phone?	Change the conversation environment or bring the earphone closer to the device.
Is the earphone signal intermittent?	Place the phone on the same side of the earphone and let away from outside interference signals.
Is the connection to the computer not successful?	Please verify that whether your computer has Bluetooth functionally or not, if not, you can install a Bluetooth adapter with a USB interface by yourself.
Unable to use AAC transmission	iOS supports AAC transmission mode by default, and devices with Android system need to be upgraded to Android 10 or above.

note: the contents of this manual are for reference only and are subject to change without notice.

Product Warranty Card



Designed by Shenzhen Yuanze Electronic Co., Ltd

Address: No.105, Room 2008, Digital Cultural Entrepreneurship Park, East of Hubin Road, Baocheng 2 District, Longjing county, Xin'an street, Bao'an District, Shenzhen City, Guangdong Province
Manufacturer: Dongguan Yuan Ze Acoustics Technology, Ltd
Address: B / F Building 1, No.323, Jinneng Road, Laobu Town, Dongguan City
Email: 2945269490@qq.com

Warranty Rules

- (1). Please read the following warranty terms carefully to ensure that the product is effectively repaired when a problem occurs.
 - Please provide this warranty card when a problem occurs.
 - All products sold by KZ Official Store are covered by 12 months warranty. If the product has a problem during the warranty period and confirms that the problem is correct, our company provides free repair and replacement.
 - Warranty card can not be repeated fill and forged.
- (2). The following causes damage to the product can not be used normally, not within the warranty.
 - Failure to follow the instructions for use of the product that result in damage to the product.
 - Damage caused by human or accidental and natural disasters.
 - Without Our company's approved maintenance, modification, demolition and other issues caused by product damage.
 - Product surface shell damage such as aging, scratches, scratches and so on.
- (3). After the warranty period, the user will still be able to get our company's maintenance service, but need pay for the corresponding fee.
- (4). Our company reserves the right to modify and interpret the contents of this warranty card.

User Info

Customer Name _____

Order ID _____

Product Type _____

Date of purchase _____

Phone Number _____

Address _____

Dealer _____

If you have any questions, please contact me. We can't control the delay in the logistics, but if there is a problem with the product, I will provide free repair and replacement for you. Wish you have a nice day.

FCC ID: 2AYZ9-AZ09