




VIVITAR
ISING
LIGHT-UP KARAOKE
MACHINE WITH DUAL MICS

www.ising.com
ISING KARAOKE
SING • VIDEO • STREAM • PARTY

User Manual ISK207


- Features**
- Built-In Media Controls
 - 2 Wireless Microphones
 - DC 5V Micro-USB Charging Port
 - TF and Micro SD Memory Card Support (up to 32GB)

- Contents**
- Speaker
 - Microphones (2)
 - USB Charging Cable
 - AUX-In Cable
 - User Manual with Warranty Information



- Charging the Speaker & Microphones**
- To charge both microphones and speaker, attach the small end of the Micro-USB charging cable (included) to the unit's charging port.
 - Attach the other end to a USB power port on a computer or USB charging adapter. **CAUTION:** Do not play music while units are charging.
 - For Speaker: A RED light will turn ON while the units are charging, and become blue once charging is complete.
 - For Microphone: A RED light will turn ON while the units are charging, and turn OFF once charging is complete.
 - Mic Battery Capacity: 3.7V/500mAh, Working time: 15-20 hours, Standby time: 3 months.

- Pairing the Speaker**
- Bluetooth Pairing**
- Push the power switch on the speaker to the ON position to turn ON the speaker. Once the device is ON you will hear "It's Karaoke Time!".
 - Open your smartphone's Bluetooth menu to enable Bluetooth and search for Bluetooth devices. Select "ISK207 Karaoke Speaker" from the list of devices.
 - After successfully pairing, you will hear "Let's Sing!" from the speaker.
- Note: If a previously paired device is in range while the speaker is ON, the speaker will connect to it automatically.



- Pairing the Microphones to the Speaker**
- To pair the two microphones to the speaker, press and hold the Power button on each microphone after connecting the speaker to Bluetooth. The indicator lights on the microphone will flash blue and red before pairing. After successfully pairing, the light indicator will stay red.

- Using the Speaker & Microphones**
- Power On/Off**
Push the power switch on the speaker to the ON position to turn ON. Push to the OFF position to turn OFF. Press and hold the Power button on the microphone to turn ON. Press and hold the Power button to turn OFF.
- Pause/Play**
Press the Pause/Play button to pause the music. Press again to play.
- Adjusting Volume**
Press the Volume - button to decrease the volume.
Press the Volume + button to increase the volume.
- Echo, Mute and Magic sound mode**
Short press the Power button on the microphone to switch between Echo and Mute mode.
Double click the microphone key to come into magic sound mode.
- Light Button**
Press the light button to switch the color light mode and turn off the front light. Double click the light button to turn ON/OFF the disco ball light.
- Switching Modes**
To enter memory card mode, insert an SD card into the TF memory card slot. You will hear "Memory Card Mode". To enter USB mode, insert a USB into the USB port. You will hear "USB Mode".

- Using the USB Port and Memory Card Slot**
- Your speaker comes with a USB Port and a TF/Micro SD Memory Card Slot.
- When a USB thumb drive or jump drive is inserted into the USB Port, your speaker will play any .MP3, .WMA, or .WAV music file stored on the drive.
 - When a TF or Micro SD memory card is inserted into the TF Card Slot, your speaker will play any .MP3 music file stored on the card.

- Specifications**
- USB/Memory Card Support: MAX 32GB
 - Horn Speaker Power Output: 15W
 - Battery Capacity: 7.4V/1200mAh
 - Power Input: 5V
 - Charging Cable: Micro-USB
 - Horn Speaker Frequency: 100HZ--18KHZ
 - Driver Unit: 1x3 inches
 - Power Supply: Built-in Li-battery

- Safety Precautions**
- When using your Karaoke Speaker, basic safety precautions should always be followed including:
1. READ ALL INSTRUCTIONS BEFORE USING YOUR SPEAKER AND MICROPHONES.
 2. Do not submerge the speaker and microphones in water. Do not place the speaker and microphones on wet surfaces.
 3. Only clean using a clean, soft cloth.
 4. Products may contain small pieces that can be a choking hazard. Parental supervision is advised.
 5. Do not expose the speaker and microphones to excessive heat or fire.
 6. Do not expose the speaker and microphones to extreme cold or hot temperatures to avoid battery damage.
 7. Do not attempt to repair the speaker and microphones yourself. Contact a qualified service center if the product is in need of service.
 8. Do not drop, crush, or expose the speaker and microphones to excessive physical force.
 9. Do not charge while the speaker and microphones are in contact with water, as electric shock may occur.
 10. Unplug charging cable when not in use or during thunderstorms.
 11. Do not play music while the speaker and microphones are charging.
 12. Do not point the microphones toward the speaker while turned ON.

- FCC Statement**
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

- One Year Warranty**
- This warranty covers the original consumer purchaser only and is not transferable.**
- This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.
- What is Not Covered by Warranty**
Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.
- To Obtain Warranty Service and Troubleshooting Information:
Call 1-800-592-9541 or visit our website at www.vivitar.com.
- To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.
- For Consumers in Australia Only**
Faulty product should be returned to point of sale, requiring proof of purchase for a refund or exchange.
Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.
You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
- For all Technical Support in Australia please dial 1-800-006-614



VIVITAR
ISING

© 2023 Sakar International
195 Carter Drive
Edison, NJ 08817
Support: 800 592 9541
www.vivitar.com