



Features
<ul style="list-style-type: none"> Bluetooth Version 5.0 Range: 331' (10m) Bluetooth Frequency: 2.4GHz Charging Base Battery Capacity: 200mAh Play Time: Around 12 Hours (Based on 50% ear volume) 1% Volume per 10dB after 30min, auto volume change provided by the charging case Charging Time: 1.5 Hours Charging Input: Micro USB 5V/1.0A Power Supply: 5V/1.0A Operating Temperature: 0°C~40°C
Contents
<ul style="list-style-type: none"> Pair of True Wireless Earbuds Charging Case Micro USB Charging Cable Instruction Manual
A Quick Look
Key components:
<ul style="list-style-type: none"> 1 Charging Case 1 USB Indicator 1 Charging Cable

How To Use:
<ol style="list-style-type: none"> 1. Turn on the earbuds from the charging case. 2. The earbuds will automatically power on and pair to each other when removed from the charging case. 3. The earbuds will power on if they don't connect to any device within 5 minutes. To turn the earbuds back off, if they have connected, please put the earbuds back into the charging case and take them out again, or press the power button for 5 seconds. 4. To pair your phone, please refer to the pairing instructions below. 5. To pair your phone with the earbuds, please turn on the Bluetooth function on the phone. When the LED light turns blue, the earbuds are paired successfully, and you will hear a beep tone.
<ol style="list-style-type: none"> 6. To answer a call, short press the earbud power button once. 7. To reject a call, long press the earbud power button for 5 seconds. 8. Short press the earbud power button to use the music, answer a call, answer a call, short press the earbud power button to play the music. 9. Press the power button to play the play music. 10. When using the earbud touch sensor for Tap and other LED features, then the Bluetooth® device has to be turned on. The earbuds can be automatically paired with the earbuds on any phone with the Bluetooth® device for a distance of over 10 meters, but on the earbuds, press the earbud power button to Tap and the LED light flashes.

How to Charge
<ol style="list-style-type: none"> 1. Charging power source: <ul style="list-style-type: none"> • Plug into charging case using the USB-C cable included. • Utilize the battery case as being charged, the case LED indicator will be flashing red. • When the case is fully charged, the light will change to solid red. 2. Charging power methods: <ul style="list-style-type: none"> • Place the earbuds into the charging case and the earbuds will automatically start charging. • A solid light on the earbuds will indicate that the earbuds are charging. Once fully charged, the red light will turn off. 3. The earbuds and case can be charged simultaneously but the earbuds will only charge if there is power in the case. The case needs to have at least a minimum charge for longer the earbuds. For more charging the case and earbuds, the case can be used for more than 5 minutes.
FAQ:
<p>Q: Why can't I start my earbuds?</p> <p>A: Answer: Please ensure that the earbuds is fully charged for your first use.</p> <p>Q: Why can't I connect one of the earbuds?</p> <p>A: Answer: Check whether the playback device and/or the earbuds are successfully synchronized. If the audio device is not properly synchronized, please reconnect. Please also adjust your mobile phone or volume to a suitable volume level.</p> <p>Q: Why can't I find the earbuds in my Bluetooth® system?</p> <p>A: Answer: Make sure the Bluetooth is on "visible mode". If you pairing success, the Bluetooth device will automatically shut off. Please request Bluetooth to be "visible mode". If there is a program error, please reboot your phone, and if a program error is caused by the earbuds, please reset the earbuds.</p>

Safety Precautions
<p>When using your Product, basic safety precautions should be followed including:</p> <ol style="list-style-type: none"> 1. READ ALL INSTRUCTIONS BEFORE USING YOUR PRODUCT. 2. Do not charge products in water. Do not place products in wet surfaces. 3. Only use while using a fire, gas, or oil. 4. Do not place children's toys with this product. This product contains small parts that can be a choking hazard. Parental supervision is advised. 5. Do not expose product to excessive heat or fire. 6. Do not expose product to water or any liquid or do not immerse product in water. Do not use product in wet or damp conditions. 7. Do not use product in areas with explosive gas or vapors. 8. Do not charge while used to prevent a possible overheating or fire risk. 9. Do not charge while plugged into a power outlet, as this will cause an explosion. 10. Using charging cables when used in case or during transportation.

FCC Statement	FCC ID: J888-11820
<p>Change or modifications not expressly approved by the party responsible for compliance with the user's safety to operate the equipment.</p> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) it must accept any interference received, including interference that may cause unintended operation.</p> <p>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to residential reception. The equipment operates with a maximum output power of 100mW and is not intended and used in accordance with the instruction, the class limit compliance radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, you can be determined to fix the interference by and you, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> - Reorient or relocate the receiving antenna. - Increase the space between the equipment and receiver. - Connect the equipment into a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. 	
<p>©2021 Sega Intellectual Property Company, Ltd. Sega, Sonic, and Sonic the Hedgehog are trademarks or registered trademarks of SEGA CORPORATION.</p>	

One Year Warranty
<p>This warranty covers the original consumer purchaser only and is not transferable.</p> <p>This warranty covers products that fail in function periods: USER SERVICE, US\$40.00. No charge in material or workmanship. Your product will be repaired or replaced or a new product or later for a period of one year.</p> <p>What Is Not Covered by Warranty</p> <p>Damage or malfunctions resulting from neglect, misuse, accident, or tampering or damage or malfunctions from other than normal use, including but limited to repair by unauthorized parties, tampering, modification or accident.</p> <p>To Obtain the Best Service and Troubleshooting Information:</p> <p>Call 1-800-555-7622 or visit our website at www.segaworld.com.</p> <p>To receive Warranty service along with the name and address of an authorized product repair center, the original purchaser must provide the name and address of the distributor and invoice number. Proof of purchase in the form of a bill of sale or receipt is required. The bill of sale must include the date of purchase, the name of the retailer, the model number and serial number of the product. It is your responsibility to provide the product and send any accessories to the repair center along with a bill of sale or receipt, or for other evidence of purchase. We will not repair, replace or substitute any accessories or other parts received by the authorized service center that are not covered by warranty will be returned unopened.</p> <p>For Consumers in Australia Only</p> <p>Each product should be returned to point of sale, requiring proof of purchase for a refund or exchange.</p> <p>Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. This is an offence to sell goods for a major failure and for compensation for any other reasonably foreseeable loss or damage.</p> <p>You are encouraged to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.</p> <p>All our Technical Support in Australia please call 1-800-555-6212</p>

©2021 SEGA Intellectual Property Company, Ltd. Sega, Sonic, and Sonic the Hedgehog are trademarks or registered trademarks of SEGA CORPORATION.

2021 CH1 | Edison, NJ 08817
Tel: (908) 762-7941
©2021. All rights reserved.
SEGA is registered in the U.S. Patent and Trademark Office.
SEGA and SONIC THE HEDGEHOG are either registered trademarks or trademarks of SEGA CORPORATION.