




Press the top left corner 45° sideways to move the car to the top left corner sideways.



Press the top right corner 45° sideways to move the car to the top right corner sideways.



Press the lower left corner 45° side move, the car side move to the lower left corner.



Press the lower right corner 45° side move, the car side move to the lower right corner.

WATCH FUNCTION DESCRIPTION

Functions after the watch is turned on: forward, backward, left and right.

Power button: ① Long press to power on.

② After starting, tap to suspend the watch function.

Press again to restore watch function.

③ Long press the power button for 3 seconds, the watch is turned off.



Finger keys

① Long press the finger button to turn off the sound. Press and hold the finger button again, and the sound will turn on.


② Long press the finger button for 2 seconds to switch mode one and mode two;

Mode 1: Forward/backward/left/right/left up and down/right up and down


Mode 2: Forward/backward/left rotation/right rotation/left drift/right drift




The gesture swings down and the car moves forward.



The gesture swings up and the car moves back.



The gesture swings to the left and the car moves to the left.



The gesture swings to the right and the car moves to the right.

PRECAUTIONS FOR BATTERY USE

1. The remote control car uses a 3.7V rechargeable lithium battery; The remote control uses two 1.5V/AA non-rechargeable batteries;

2. Rechargeable batteries must be charged under adult supervision;

3. Do not use different types of batteries or old and new batteries together.

4. Only recommended batteries with the same or equivalent battery can be used;

5. Remove exhausted batteries from toys; Remove the battery if it is not used for a long time.

6. Do not short-circuit the power terminal.

7. Unscrew the battery compartment cover with a screwdriver, install the battery with the correct positive and negative polarity, and unscrew the battery compartment cover with a screwdriver. Screw, remove the battery.

8. Repair and maintenance: This product is composed of plastic, hardware and electronic components, and shall not be placed or used in water or in a damp environment for a long time.

Check wires, plugs, housings and other components regularly for defects and discontinue use when defects are found until they are repaired.

INSTRUCTIONS

• Thank you for using our company's toy products. In order to have a better understanding of this product, please read the following instructions before use, which will bring you a different operating experience.


• This product is suitable for children 8 years old and above. After assembled / charged by adults, play with children again.

⚠ Warning: please do not disassemble or modify the product without authorization, any changes may cause the product to not work properly.

How to switch Remote control to Gesture Control: First, turn off the power to the remote control, turn off the power to the car; Then, turn on the power of the watch, watch light slowly flash; Then turn on the power of the car, the car and the watch on the frequency, the watch light is on, the car has starting music.

HOW TO INSTALL THE BATTERY

1. Switch the remote control car and the switch on the remote control to "OFF"
2. Open the battery cover using a Phillips screwdriver
3. Insert the battery, as shown in the following figure.
4. Close the battery cover.




USB charger
Charging time,
3 hours,
Play time 30
minutes


Rechargeable
battery
(included)

HOW TO PLAY REMOTE CONTROL CAR


1. Turn on the remote control car/remote control switch to complete frequency adjustment.
2. Operate the joystick and buttons of the remote control to control the car forward or backward, turn left Rotate or right, move left or right and one-click demonstration.
3. When the battery is consumed, the left and right steering is not sensitive, Moving forward and backward will also be slower. Remove the battery and charge it.




HOW TO USE THE BASIC OPERATION OF THIS PRODUCT




The rocker pushes forward and the car moves forward.




The rocker pushes back and the car moves back.




When the stick is pushed left, the car spins left.



The stick pushes to the right and the car spins to the right.



Press left, the car goes left.



Press right, the car goes right.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction