


# Package List

02




1 x Oleap Pilot headset



1 x Bluetooth dongle



1 x Charging cable



1 x Carry case



1 x User manual

## Multi-function button

Press and hold for 3 seconds ..... Power on/off

Press ..... Answer/End a call  
Play/Pause

Press and hold for 5 seconds in power-off status ..... Start Bluetooth pairing

Triple press ..... Start Bluetooth pairing for a second device

### Mute button

Press ..... Mute microphone during a call

Press again ..... Unmute microphone

Press and hold for 3 seconds ..... Access phone's voice assistant

## Volume down

Press ..... Volume down

Press and hold for 2 seconds ..... Skip backward

## Volume up

Press ..... Volume up

Press and hold for 2 seconds ..... Skip forward

## Microphone


Use microphone during a call/recording ..... Rotate mic down close to the mouth


Not talking or recording ..... Fold the mic up

**Fully charge the headset before using it for the first time.**

Method 1: Charge the headset via the supplied charging cable.

1. Connect the small end of the charging cable to the type-C port.
2. Connect the other end to a USB wall charger (not supplied in the package).
3. Power off the headset while being charged.





#### Method 2: Charge the headset via the charging stand.

1. Connect the charging stand and the power supply with the supplied charging cable.
2. Get Type-C port of the headset inserted by the charging plug on the stand, and place the headset firmly to charge.

\*The charging stand needs to be purchased separately.

Battery capacity	180mAh
Charging time	≈30mins
Quick charging	10mins≈5hrs
Talk time	≈10hrs
Audio playback	≈16hrs

Type-C port

## **Oleap Pilot connects with mobile devices via Bluetooth**

### **1. Start Oleap Pilot's Bluetooth pairing mode**

In the off state, press and hold the multi-function button until you hear the prompt "Pairing", and the headset indicator flashes red and blue alternately.

### **2. Pair Oleap Pilot with a mobile Bluetooth device**

Turn on the Bluetooth of the mobile device, find and select "Oleap Pilot" in the Bluetooth list, after successful pairing, you will hear the prompt "Device one connected", and the indicator light of the headset flashes blue slowly.

### **3. Pair the Oleap Pilot with a second Bluetooth device**

After the first bluetooth device is successfully connected, triple press the multi-function button until you hear the "Pairing" prompt, and the headset indicator light flashes in red and blue alternately, and you can pair with another device at the same time, please refer to the above for the connection process.


\*Oleap Pilot can connect up to two Bluetooth devices simultaneously.

## 1. How to connect the dongle

Insert the supplied Bluetooth dongle into the USB port of the computer. After the headset is turned on, it will automatically pair with the dongle.

\*If the dongle has connected two Bluetooth headsets, you need to disconnect at least one of them before pairing with the dongle.

.....  
Note:

- The Windows system usually sets the newly installed headset as the default audio input and output device. If the headset is not set as the default device, please click the sound settings icon  in the lower right corner of the computer, select and confirm that the playback device is Oleap Pilot, and it will work normally.
- The MAC OS system will not set the newly installed headset as the default audio input and output device. After the installation is successful, you need to enter the Settings--->Open the Sound Settings---->Select the input device and the output device as Oleap Pilot, and it will work normally.

## 2. Dongle button function

Pairing the dongle with other Oleap headsets

1. After plugging the dongle into the computer for the first time, press and hold the button on the dongle for about 3 seconds to enter the pairing mode, and the dongle indicator light flashes red and blue alternately.
2. Trigger the other Oleap Bluetooth headset into Bluetooth pairing mode, and pair it with the dongle; the dongle indicator light turns solid blue after successful pairing.

Delete pairing list

Press and hold the button on the dongle for 10 seconds, and then the dongle indicator flashes yellow 3 times quickly, which means the deletion is complete.

### 3. The connection status between the dongle and Oleap Pilot

**Reconnect automatically** After Oleap and the dongle are disconnected due to long distance, they can automatically reconnect when they return to the normal Bluetooth distance.

**Standby mode** If there is no headset pairing within 5 minutes, it will enter standby mode, and the blue light flashes slowly.

#### **Oleap Pilot will reconnect automatically after power on**

When the dongle is in the standby state, and the headset automatically reconnects to the dongle when it is powered on.

#### **To connect the dongle to another new Oleap headset**

Firstly delete the pairing list, then the dongle will enter pairing mode automatically. Turn on your new Oleap Bluetooth headset and trigger the pairing mode to connect with the dongle.

### 4. Dongle indicator lights

Blue light flashes slowly

Disconnected with headset

Not connected to any headset

Red and blue lights flash alternately

Pairing mode

Solid blue

Paired successfully/playing music

Solid red

Headset microphone muted

Yellow light flashes 3 times

Pairing list deleted

## 1. Working status

Red and blue lights flash alternately  
Blue light flashes  
Red light flashes

Ready to pair  
Works fine  
Need to charge

## 2. Battery status ( View the indicator light when the headset is charging )

Solid blue  
Red light flashes

Fully charged  
Charging

# Care And Maintenance

- When not in use, fold the microphone up and place the headset flat into the carry case.
- Make sure to power off the headset when not in use.
- Before storing the headset for more than a few months, make sure the battery is fully charged.
- Wipe the outside surfaces with a soft, dry cloth.
- Don't allow moisture to get inside the headset or the microphone.

## **If you need more help, please contact us:**

Manufacturer: Shenzhen Huangli Technologies Co., Ltd

Address: Room 11-11, Yuanxing Technology Building, No. 1 Songping Road,  
Nanshan District, Shenzhen City, Guangdong Province

[www.oleapai.com](http://www.oleapai.com)

✉ [service@oleapai.com](mailto:service@oleapai.com)

© 2022 Oleap is manufactured by Shenzhen Huangli Technologies Co., Ltd

Bluetooth is a registered trademark of Bluetooth SIG, Inc.

The above trademarks are the property of their respective owners.

Product ID: Oleap Pilot P200b



## **Warnings and cautions**

1. The suitable temperature for the product and accessories is -10~60°C, the charging temperature is -10~60°C.

2. This device operates the frequency bands(s) and the maximum output power (E.I.R.P) :

2402MHz – 2480MHz : 9.73dBm

2412MHz – 2472MHz : 17.83dBm

3. EU Regulatory Conformance

Hereby, Shenzhen Huangli Technologies declares that this device Oleap Pilot is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

For the declaration of conformity, visit the Web site [www.XX.com/certification](http://www.XX.com/certification)



## Warnings and cautions

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device."

Mark: The product is too small to place complete label information, so the label is placed in the charging bin.