

尺寸:75x110mm  
 材质:100g铜版纸, 折叠式单黑




**无线游戏鼠标**  
 型号: SA-SL01

快速入手指南

### 01 / 技术参数

产品品牌:	仁魔RAWM
产品型号:	SA-SL01
传输方式:	USB有线+2.4G无线+蓝牙无线
接口类型:	Type-C接口
产品尺寸:	118mm*61.32mm*38.4mm
外壳材质:	ABS注塑
按键数量:	7按键+1开关+1模式选择
线材长度:	2M
传感器:	PAW3395
分辨率:	26000DPI
最大加速:	50G
最大速度:	650IPS
支持系统:	WindowsVista/XP/7/8/10/11Mac



SA-SL01

### 02 / 按键功能说明



①左键 ②右键 ③中键(滚轮键)  
 ④前进键 ⑤后退键

⑥查看电量  
 绿灯表示电量充足;黄灯表示需要充电;红灯表示需要尽快充电。

⑦电源开关  
 a. ON档: 往右拨到ON档, 即电源开启;  
 b. OFF档: 往左拨到OFF档, 即电源关闭。

⑧DPI切换键  
 六档DPI键: 默认DPI为1600【黄】。(可在驱动软件中自定义调节 DPI值)  
 切换指示灯: 400(蓝)/800(绿)/1600(黄)/3200(红)

⑨蓝牙/2.4G切换开关

### 03 / 无线接收器 功能灯光说明

**USB有线模式:**  
 USB有线模式切换方法: 无论电源开关是OFF档还是ON档, 插入TYPE-C线后, 都自动切换为有线模式, 并开始为鼠标充电。

**无线模式:**  
 1. 2.4G模式切换方法:  
 鼠标底部的模式开关调到2.4G, 电源开关拨到ON档, 即为2.4G模式; (出厂已默认配对2.4G接收器)  
 2. 2.4G配对方法:  
 在2.4G模式下, 鼠标指示灯闪烁(黄灯)说明鼠标需要重新配对2.4G接收器; (请在USB有线模式下在驱动软件中进行配对)  
 3. 蓝牙模式切换方法:  
 鼠标底部的模式开关调到BT, 电源开关拨到ON档, 即为蓝牙模式;

**低电模式:**  
 ①、低电时状态: 鼠标指示灯闪烁(红灯);  
 ②、充电时状态: 鼠标指示灯常亮(红灯);  
 ③、满电时状态: 鼠标灯灭;

**休眠模式:**  
 ①、一级休眠状态: 鼠标停止移动10秒后, 鼠标进入省电休眠状态, 移动/按键可唤醒鼠标;  
 ②、二级休眠状态: 鼠标停止移动1分钟后, 鼠标进入省电休眠状态, 移动/按键可唤醒鼠标。

**恢复出厂设置:**  
 按住DPI按键并将电源开关重新拨至ON档, 指示灯(蓝灯)重新亮起则代表鼠标已恢复出厂默认设置。



### 04 / 产品质保

感谢您对仁魔产品的信任与支持, 为了让您放心使用本产品, 更好地保障您的权益, 我司将严格遵守并执行相关规定, 实行售后服务。

1. 服务有效期: 自购买之日起质量保证12个月;
2. 服务内容: 按微型计算机商品维修更换退货责任规定进行服务;
3. 不属于服务范围:
  - ①. 已经超出有效服务或免费维修期的;
  - ②. 未按照正确使用说明使用、维护保养导致故障或损坏的;
  - ③. 非本司授权维修机构维修导致的故障或损坏;
  - ④. 质保卡上无经销商资料及盖章之产品, 擅自涂改三包凭证内容的;
  - ⑤. 由于不可抗力(如自然灾害等)原因造成产品之不良;
  - ⑥. 人为因素导致产品不良(如操作失误、碰撞、输入不合适电压等);
  - ⑦. 其他非产品设计、技术、制造、质量等问题导致的故障或损坏。

非常感谢您选购仁魔RAWM SA-SL01无线游戏鼠标, 希望您能带给您全新的操作体验。要获得更多增强的设置和功能, 可以从官网下载驱动软件。

### 质保卡

产品型号: \_\_\_\_\_  
 购买日期: \_\_\_\_\_  
 客户姓名: \_\_\_\_\_  
 联系电话: \_\_\_\_\_  
 联系地址: \_\_\_\_\_



\*本凭证为仁魔产品售后服务的重要依据, 请您妥善保管。  
 \*任何产品问题可扫码咨询微信公众号小编。




了解更多产品信息  
 请关注微信公众号: 仁魔电竞

制造商: 深圳市仁魔电子科技有限公司  
 地址: 深圳市龙华区大浪街道同胜社区鹤  
 厦山新村三和国际2号楼4层405-406室  
 邮箱: support@rawmtech.com

www.rawmtech.com





**WIRELESS GAMING MOUSE**  
 MODEL: SA-SL01

Quick Start Guide


### 01 / Technical Parameters

Brand:	RAWM
Product model:	SA-SL01
Transmission method:	USB wired + 2.4G wireless + Bluetooth wireless
Interface type:	Type-C interface
Product size:	118mm*61.32mm*38.4mm
Shell material:	ABS injection molding
Number of buttons:	7 buttons + 1 switch + 1 mode selection
Wire length:	2M
Sensor:	PAW3395
Resolution:	26000DPI
Maximum acceleration:	50G
Maximum speed:	650IPS
Supported systems:	WindowsVista/XP/7/8/10/11Mac



SA-SL01

### 02 / Key Function Description



①Left button ②Right button ③Middle button (scroll wheel button)  
 ④Forward button ⑤Back button

⑥Check the battery capacity  
 The green light indicates that the battery is sufficient; the yellow light indicates that it needs to be charged; and the red light indicates that it needs to be charged as soon as possible.

⑦Power on  
 1. ON gear: Dial right to the ON gear, that is, the power is turned on.  
 2. OFF gear: Dial left to the OFF gear, that is, the power is turned off.

⑧DPI switch button  
 Adjustable six levels of DPI: The default DPI is 1600 [yellow]. (The DPI value can be customized and adjusted in the driver software)  
 Switching indicator light: 400(blue)/800(green)/1600(yellow)/3200(red).

⑨Bluetooth/2.4G switch

### 03 / Wireless Receiver Function Lighting Description


**USB Wired Mode:**  
 USB wired mode switching method: Regardless of whether the power switch is OFF or ON, after plugging in the Type-C cable, it will automatically switch to wired mode and start charging the mouse.

**2.4G Wireless Mode:**  
 ①. 2.4G mode switching method: Set the mode switch at the bottom of the mouse to 2.4G, and turn the power switch to the ON position, which is the 2.4G mode. (The 2.4G receiver is paired by default at the factory)  
 ②. 2.4G pairing method: In 2.4G mode, the mouse indicator light flashes (yellow light) indicating that the mouse needs to be re-paired to receive 2.4G device. (Please pair in the driver software in USB wired mode)  
 ③. Bluetooth mode switching method: Set the mode switch at the bottom of the mouse to BT, and set the power switch to ON, which is Bluetooth mode.

**Low Power Mode:**  
 ①. Low power state: the indicator light of the mouse is flashing (red light).  
 ②. Charging state: the indicator light of the mouse is always on (red light).  
 ③. State when fully charged: the indicator light of the mouse is always on (green light).

**Sleep Mode:**  
 ①. Level 1 sleep state: 10 seconds after the mouse stops moving, the mouse enters the power-saving sleep state, and the mouse can be woken up by moving/pressing keys.  
 ②. Level 2 sleep state: After the mouse stops moving for 1 minute, the mouse enters a power-saving sleep state. Moving/pressing a button can wake up the mouse.

**Restore Factory Settings:**  
 Press and hold the DPI button and turn the power switch back to the ON position. If the indicator light (blue light) lights up again, it means that the mouse has been restored to factory default settings.



### 04 / Product Warranty

Thank you for your trust and support for RAWM products. In order to allow you to use this product with confidence and better protect your rights and interests, our company will strictly abide by and implement relevant regulations and provide after-sales service.

1. Service validity period: Quality guarantee for 12 months from the date of purchase.
2. Service content: Provide services in accordance with the liability regulations for repair, replacement and return of microcomputer products.
3. Does not belong to the scope of service:
  - a. The effective service or free maintenance period has expired.
  - b. Failure or damage caused by failure to use, maintain and store in accordance with the correct instructions.
  - c. Failure or damage caused by repairs not authorized by our company;
  - d. Products without dealer information and seal on the warranty card, altering the contents of the Three Guarantees Voucher without authorization.
  - e. Product defects caused by force majeure (such as natural disasters, etc.).
  - f. Product defects caused by human factors (such as operating errors, bumps, inappropriate voltage input, etc.).
  - g. Other failures or damages not caused by product design, technology, manufacturing, quality and other issues.

www.rawmtech.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in porlable exposure condition without restriction.