



3. Do not charge in a humid environment. Regularly clean the magnetic charging port to ensure the cleanliness of the magnetic charging port for normal charging.



App Download and Con



Hold for 2 seconds to enter the watch face and right to switch watch faces, and click to switch faces through the app.	 Weather When the watch is connected to the cloud, it can push real-time weather and temperature information for the week.
Calories recorded for the day. You can set the goal in the app.	 Sports Options for sports mode: walking, running, soccer, badminton etc., click the icon to enter the sports mode, and the watch can push sports.
Step status for the day, with data updated daily.	 Status After the watch is connected to the cloud, it can push step status for the day.

 Sports	Options for sports mode: walking, soccer, badminton etc., click the icon to push sports.
 Music	After the watch is connected to the music player.
 Timer	System presets common timer into custom button to set the time.

 Control center :Do not disturb mode

hiking, cycling, basketball, start the exercise interface. APP
You can control the phone's
click to quickly time. Click the

Common Issues

1. The watch cannot be turned on. Please press the power button for more than 3 seconds or the battery may be low and needs to be charged.
2. Wireless is not connected or cannot connect to your phone.
 - 1) Try restarting the watch and reconnecting to your phone.
 - 2) Try connecting again after restarting your phone.
 - 3) Do not connect your phone to other WiFi networks.

than 3 seconds or the battery may be low and the watch will not sync.

2. Wireless is not connected or cannot connect to your phone.
 - 1) Try restarting the watch and reconnecting to your phone.
 - 2) Try connecting again after restarting your phone.
 - 3) Do not connect your phone to other Wireless devices.
 - 4) When Wireless is disconnected, function and health data syncing will not work.
3. Manual heart rate/blood oxygen/blood pressure monitoring.

FCC Warning

I hold the power button for more
s charging.

's Wireless.
ices at the same time.

This device complies with part 15 of
the following two conditions:
(1) This device may not cause harmful
accept any interference received, in
undesired operation.

the following two conditions:
(1) This device may not cause harmful
interference. The user is required to
accept any interference received, in
undesired operation.

Any Changes or modifications not e

particular installation. If this equipment is to be used in a different environment, it is the responsibility of the user to make sure that the equipment is suitable for the environment.

Rules. Operation is subject to interference, and (2) this device must not cause interference that may cause radio or television reception, which can be controlled by turning the equipment off and on, the user is encouraged to eliminate interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.

ference, and (2) this device must
interference that may cause
approved by the party

interference by one or more of the foll

- ▶ -Reorient or relocate the receiving
- ▶ -Increase the separation between t
- ▶ -Connect the equipment into an ou
which the receiver is connected

cause harmful interference to

to try to correct the measures:

measures:
1. component and receiver.
a circuit different from that to