

SOBAST


S20

磁吸蓝牙音箱使用说明书



欢迎使用我们的音箱产品,为了让您更好地使用本产品,请您仔细阅读说明书。

*由于产品的迭代升级,有可能部分描述和包装变化,请以实物为准!



蓝牙连接:音箱开机后进入蓝牙配状态,手机搜索到蓝牙名“S20”点击即可连接。

规格参数

项目	规格参数	项目	规格参数
蓝牙版本	V5.3	充电电压	5V/0.3A
蓝牙传输距离	10M	产品重量	87g
功率	5W	频率响应	100Hz-16KHz
电池容量	600mAh	产品尺寸	68*62*36mm

合格证与保修卡

合 格 证		保 修 卡	
产品名称		用户姓名	
机型		购买日期	
颜色		联系方式	
生产日期		保修记录	
执行标准		保修记录	
检验结果		备 注	

温馨提示

- ✓ 充电前请检查充电器规格,请勿使用快充或高电压充电器对机器进行充电。
- ✓ 为了听力健康,请勿长时间最大音量使用。
- ✓ 请勿靠近火源或者高温环境下使用,以免对产品产生永久性损坏。
- ✓ 请严格按照说明书使用,请勿私自改装或者拆解产品。
- ✓ 请勿跌落、撞击、敲打、挤压或其他严重影响产品结构的行为,避免损坏产品的强度和可靠性。
- ✓ 使用过程中如遇到高温、变形、腐蚀等异常时,请立即停止使用并联系商家妥善处理。

执行标准:GB8998-2011;GB/T138372012;GB17625.1-2012

SOBAST


SOBAST

S20

Magnetic Bluetooth Speaker User Manual



Welcome to purchase our speaker, in order to let you use this product better, please read the manual carefully. Due to the iterative upgrading of the product, there may be some changes in the description and packaging. Please refer to the real object!



Bluetooth connection: After turning on the speaker, it enters Bluetooth configuration mode. The phone searches for the Bluetooth name “S20” and clicks to connect.

Specifications

Bluetooth version	V5.3	Charging voltage	5V/0.3A
Bluetooth distance	10M	Net Weight	87g
Power	5W	Frequency response	100Hz-16KHz
Capacity of battery	600mAh	Product size	68*62*36mm

Certificate		Warranty Card	
Product name		User's name	
Model		Date of purchase	
Color		Contact information	
Production Date		Warranty record 1	
Executive standard		Warranty record 2	
Test result		Remark	

Kindly reminder

- ✓ Please check the charger specifications before charging, do not use fast charging or high voltage chargers to charge the speaker.
- ✓ For hearing health, please do not use it at maximum volume for a long time.
- ✓ Do not use it near a fire source or in a high temperature environment to avoid permanent damage to the speaker.
- ✓ Please use it strictly in accordance with the instructions, and do not modify or disassemble the product without permission.
- ✓ Do not drop, impact, knock, squeeze or other behaviors that seriously affect the product structure to avoid damage to the strength and reliability of the product.
- ✓ If you encounter high temperature, deformation, corrosion and other abnormalities during use, please stop using it immediately and contact the merchant for proper disposal.

Executive standard
GB8998-2011;GB/T13837-2012;GB17625.1-2012

SOBAST

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.