

User manual

Model: G6T1

Brand: LEO

## Introduction

This controller is used for electric kid's cars, including a remote control and a controller (for receiving). It uses 2.4G wireless remote control. The controller controls two motors to rotate. The remote control uses 3V battery to supply power. The receiver uses 12V battery to supply power. Product ship with no battery.

Connect the controller to the electric kid's car with wire and turn on the car and controller at the same time.

Coding the controller and receiver when control with the remote controller. When the remote controller first turns on, the top light flashes slowly and then turns on the receiver. When the light long bright, it means coding finishes and you can turn on the car.

There are 8 buttons on the remote controller: power, forward, backward, left, right, speed up, speed down, stop. The power button is used as the power supply when the remote controller is stand-by. When the remote control is working, it is used to control the front motor.

You may not control the car with the remote controller but the button connected to the car to control the car to go forward, go backward, turn left, turn right, slow down or speed up. At this point, the steering function can be achieved by turning the steering wheel to control the rotation of the front motor.

When the remote controller and the car switch are both on, the remote controller is prior and the car's switch controller will not work. When the remote controller is no longer operational, the car switch controller can also play a role after about 2 seconds later.

## G6T1 remote controller Test mode entry method

### 1. Signal carrier mode:

First keep pressing the "left" button on the remote controller and then connect the remote controller to power supplies. Afterwards the remote controller should be in signal carrier mode. The default frequency is 2480MHz.

Press the "forward" button over and over, frequency changes by 2480 - 2412 - 2447 - 2480.

### 2. Fixed frequency mode

First keep pressing the "right" button on the remote controller and then connect the remote controller to power supplies. Afterwards the remote controller should be in fixed frequency mode. The default frequency is 2480MHz.

Press the "forward" button over and over, frequency changes by 2480 - 2412 - 2447 - 2480.

## FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.