Package contents

- Galaxy Fit e
- Charger
- The items supplied with the Galaxy Fit e and their images may vary by region.


Device layout

Galaxy Fite









Quick start guide

Do not insert sharp objects into the pressure vent. Inner components of the Galaxy Fit e may be damaged along with the water-resistance feature.

Charging the battery

After purchasing the Galaxy Fit e, connect the charger to turn on the power. You must first charge the battery sufficiently.



Use only Samsung-approved chargers.

- The Galaxy Fit e has no separate power key and is powered on when the battery is charged is charged
 - The charger should remain close to the electric socket and be easily accessible while charging.

Accessing more information

To view the full user manual and the full safety information, including device and battery disposal instructions, launch Galaxy Wearable on you mobile device and tap \longrightarrow User manual. Or, visit www.samsung.com.

- The method for accessing the user manual from the Galaxy Wearable app may vary depending on your mobile device.
 - The user manual may not be available depending on the web browser or service provider.


Connecting the Galaxy Fit e to a mobile device

On your mobile device, launch Galaxy Store or Play Store and download the Galaxy Wearable app, launch it and follow the on-screen instructions to complete the connection.

- Connection methods and screen may vary depending on your mobile device and software version.
- Supported mobile devices and features may vary depending on your region, service provider, and device manufacturer.

Notice for measuring the heart rate

When measuring your heart rate, wear the Galaxy Fit e snugly on your arm above your wrist as shown in the figure below. Do not fasten the Galaxy Fit e too tightly.



- The accuracy of the heart rate sensor can be affected depending on the user's movements, personal physiology, and the measurement conditions and surroundings. Take heart rate measurements when you are seated and relaxed.
- Do not look directly at the heart rate sensor's lights. Doing so may impair your vision.
- If your device becomes hot to the touch, please remove it until it cools. Exposing skin to a hot surface of the device for a long time may cause skin burn.

If your device is frozen and unresponsive, connect the charger to restart it.

Taking off the Galaxy Fit e

When taking off the Galaxy Fit e, pull up on the buckle and pull out the band as shown in the figure below.



Declaration of Conformity

Samsung Electronics declares that this device complies with the essential requirements and relevant provisions of Directive 2014/53/EU.

Go to www.samsung.com/mobile_doc to view the Declaration of Conformity.

Samsung Electronics, Service Dept, PO Box 12987, Blackrock, Co. Dublin, Ireland

Some content may differ from your device depending on the region, service provider, or software version, and is subject to change without prior notice.

 THIS DEVICE AND ANY SOFTWARE, SERVICE, FUNCTION PROVIDED THEREIN IS SOLELY INTENDED FOR FITNESS AND WELLNESS PURPOSES ONLY AND IS NOT INTENDED FOR USE IN THE DIAGNOSIS OF DISEASE OR OTHER CONDITIONS, OR IN THE CURE, MITIGATION, TREATMENT OR PREVENTION OF DISEASE.

• Any information that is obtained from use of the Galaxy Fit e or the Fit Software or any application preloaded within may not be suitable, accurate, complete or reliable.

Correct disposal



Safety information

explosion

or liauids.

Warning

Do not expose the device to physical impact or damage.

Use manufacturer-approved chargers, accessories, and supplies.

For information on Samsung's environmental commitments and product regulatory obligations, e.g. REACH,

Follow the warning information provided below to prevent incidents such as fire or

Prevent the multipurpose iack and battery terminals from contacting conductive elements, such as metal

WEEE or Batteries, visit our sustainability page available via www.samsung.com.

Read all safety information before using the device to ensure safe and proper use.

This marking on the battery, manual or packaging indicates to manual or packaging indicates that the batteries in this product should not be disposed of with other ∕**—⊙**∖ household waste

- If any part of the device, such as the glass or acrylic body, is broken, smokes, or emits a burning odor, stop using the device immediately. Use the device again only after it has been repaired at a Samsung Service Centre
- Do not turn on or use the device when the battery compartment is exposed.

Follow the warnings below to prevent injury to people or damage to the device

- Do not allow children or animals to chew or suck the device.
- The device can be used in locations with an ambient temperature of 0 °C to 35 °C. You can store the device at an ambient temperature of -20 °C to 50 °C. Using or storing the device outside of the recommended temperature ranges may damage the device or reduce the battery's lifespan.
- Do not use your device in a hot environment or near fire.
- · Comply with all safety warnings and regulations regarding mobile device usage while operating a vehicle.
- Do not wear the device too tightly. Make sure to keep the device clean and dry. Though this device has met international safety standards, some people may experience skin irritation if they are allergic to certain substances

Maintaining water and dust resistance

Your device supports water- and dust-resistance. Follow these tips carefully to maintain the water- and dustresistance of your device. Failure to do so may result in damage to your device.

- Do not expose the device to water moving with force.
- Do not use your device when you dive into the water, snorkel or try any water sports in fast-flowing water.
- If the device or your hands are wet, dry them thoroughly before handling the device.
- If the device is exposed to fresh water, dry it thoroughly with a clean, soft cloth. If the device is exposed to other liquids, such as salt water, swimming pool water, soapy water, oil, perfume, sunscreen, hand cleaner, or chemical products such as cosmetics, rinse it with fresh water and dry it thoroughly with a clean, soft cloth, If you do not follow these instructions, the device's performance and appearance may be affected.

Copyright © 2019 Samsung Electronics

- If the device is dropped or receives an impact, the water- and dust-resistant features of the device may be damaged
- Some features such as the touchscreen may not work properly if the device is used in water.

Your device has been tested in a controlled environment and certified to be water- and dustresistant in specific situations and conditions. (Meets the requirements of the water-resistance in a 50 m deep water as described by the international standard ISO 22810:2010 and your device can be used in shallow water. Meets the requirements of the dust-resistance as described by classification IEC 60529 IP6X.)

Removing the battery

- To remove the battery, contact an authorised service centre. To obtain battery removal instructions, please visit www.samsung.com/global/ecodesign_energy.
- For your safety, you must not attempt to remove the battery. If the battery is not properly removed, it may lead to damage to the battery and device, cause personal injury, and/or result in the device being unsafe.
- Samsung does not accept liability for any damage or loss (whether in contract or tort. including negligence) which may arise from failure to precisely follow these warnings and instructions, other than death or personal injury caused by Samsung's negligence.

Band and mode

Band and mode	Output power
Bluetooth 2.4 GHz	20 dBm

FCC Statement

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

IC Statement

This Class B digital apparatus complies with Canadian ICES-003.

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil numérique de la classe B est conforme á la norme NMB-003 du Canada. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate this equipment.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

The device could automatically discontinue transmission in case of absence of information to transmit, or operational failure. Note that this is not intended to prohibit transmission of control or signaling information or the use of repetitive codes where required by the technology.

IMPORTANT NOTE:

IC Radiation Exposure Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0mm between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour unenvironnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 0mm de distance entre la source de rayonnement et votre corps.

Transmit Antenna Notice

This radio transmitter [IC: 649E-SMR375] has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Antenna list	' type	maximum	dain(dBi))
Antenna iist	type,	maximum	yan (ubi	,,

Model	Туре	Maximum gain (dBi)
SM-R375	Pattern antenna	-2.49 dBi