


Size: 140 x 170mm

Size: 2012/1/4

User Manual



Product Specifications

- Dimension: 90 * 40 * 12mm
- 1 Upstream and 4 downstream ports
- LED power indicator
- Interface: USB 2.0, compatible with USB 1.1
- Power supply voltage: DC 5V by PC
- Driverless, hot swap function
- Data transfer rate: 1.5/12/480Mbps
- Overcurrent protection circuit
- Bamboo case

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.

OS Support

Windows ME/2000/XP/Vista/7, MAC OS 8.6 or later version.

User Operation

1. Connect the USB hub to the computer. No driver installation is needed.
2. When connection is successful, the green LED indicating light will be ON.
3. Then plug in any USB device to one of the four downstream ports on the USB hub to proceed with the data transmission.
4. Four downstream ports can be used at one time.
5. To remove the USB hub, simply unplug the USB connector from the computer.

FCC Statement

NOTE: This equipment has been tested and found to comply with the Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.