

IC-M402A ADJUSTMENT PROCEDURES

1 PREPARATION

REQUIRED TEST EQUIPMENT

EQUIPMENT	GRADE AND RANGE	EQUIPMENT	GRADE AND RANGE
DC power supply	Output voltage : 13.8 V DC Current capacity : 10 A or more	Distortion meter	Frequency range : 1 kHz \pm 10 % Measuring range : 1–100 %
RF power meter (terminated type)	Measuring range : 1–50 W Frequency range : 100–300 MHz Impedance : 50 SWR : Less than 1.2 : 1	Audio generator	Frequency range : 300–3000 Hz Measuring range : 1–500 mV
		Standard signal generator (SSG)	Frequency range : 0.1–300 MHz Output level : 0.1 μ V–32 mV (–127 to –17 dBm)
Frequency counter	Frequency range : 0.1–300 MHz Frequency accuracy : \pm 1 ppm or better Sensitivity : 100 mV or better	External speaker	Input impedance : 4 Capacity : 5 W or more
FM deviation meter	Frequency range : 30–300 MHz Measuring range : 0 to \pm 10 kHz	Attenuator	Power attenuation : 40 or 50 dB Capacity : 50 W or more
DC voltmeter	Input impedance : 50 k Ω /V DC or better		

2 PLL ADJUSTMENTS

ADJUSTMENT		ADJUSTMENT CONDITION	MEASUREMENT		VALUE	ADJUSTMENT POINT	
			UNIT	LOCATION		UNIT	ADJUST
LOCK VOLTAGE	1	<ul style="list-style-type: none"> • Operating channel : ch16 • Receiving 	MAIN	Connect a digital multi-meter or oscilloscope to the check point LV.	1.8 V		Verify
	2	<ul style="list-style-type: none"> • Operating channel : ch16 • Output power : Low • Transmitting 			1.6 V		
REFERENCE FREQUENCY	1	<ul style="list-style-type: none"> • Operating channel : ch16 • Output power : Low • Connect an RF power meter or a 50 dummy load to the antenna connector. • Transmitting 	Rear Panel	Loosely couple the frequency counter to the antenna connector.	156.8000 MHz	MAIN	C12

3 TRANSMITTER ADJUSTMENTS

ADJUSTMENT		ADJUSTMENT CONDITION	MEASUREMENT		VALUE	ADJUSTMENT POINT	
			UNIT	LOCATION		UNIT	ADJUST
OUTPUT POWER	1	<ul style="list-style-type: none"> • Operating channel : ch16 • Output power : High • Transmitting 	Rear Panel	Connect an RF power meter to the antenna connector.	23.5 W	MAIN	R114
FREQUENCY DEVIATION	1	<ul style="list-style-type: none"> • Operating channel : ch16 • Output power : Low • Connect an audio generator to J4 (pin 3) on the MAIN unit with an AC millivoltmeter and set as: <ul style="list-style-type: none"> Frequency : 1 kHz Level : 30 mV • Set an FM deviation meter as: <ul style="list-style-type: none"> HPF : OFF LPF : 20 kHz De-emphasis : OFF Detector : (P-P)/2 • Transmitting 	Rear Panel	Connect an FM deviation meter to the antenna connector through an attenuator.	±4.3 kHz	MAIN	R327

4 RECEIVER ADJUSTMENTS

ADJUSTMENT	ADJUSTMENT CONDITION	MEASUREMENT		VALUE	ADJUSTMENT POINT	
		UNIT	LOCATION		UNIT	ADJUST
SENSITIVITY	1 <ul style="list-style-type: none"> • Operating channel : ch16 • [SQUELCH] control: Max. counterclockwise • Connect an SSG to the antenna connector and set as: Frequency : 156.800 MHz Level : 3.2 μV* (-97 dBm) Modulation : 1 kHz Deviation : \pm 3.5 kHz • Receiving 	MAIN	Connect the distortion meter to the [EXT SP]jack with a 4 load. Connect a DC voltmeter to check point CP3.	Maximum voltage	MAIN	L35, L36, L38, L39
SQUELCH	1 <ul style="list-style-type: none"> • Operating channel : ch16 • [SQUELCH] control: Max. counterclockwise • Connect an SSG to the antenna connector and set as: Frequency : 156.800 MHz Level : 0.28 μV* (-118 dBm) Modulation : 1 kHz Deviation : \pm 3.5 kHz • Receiving 	MAIN	Connect a DC voltmeter to check point CP5.	1.0 V	MAIN	R214

*This output level of a standard signal generator (SSG) is indicated as SSG's open circuit.