




Almond Click QSG SC1



1. LED indicator
2. Push button
3. CR 2032 battery
4. Join/Reset/Tamper button
5. Lanyard hole and groove

English

Adding an Almond Click

Step 1: Remove the back cover by pulling the back cover upwards at the groove provided in the lanyard hole.

Step 2: Tap the “Add Sensors” icon on the LCD UI of your Almond router and tap on “Add” to start the adding process.

Step 2: Press the join/reset button on the back of the Almond Click.

Step 3: Insert the battery into the battery holder on the back of the Almond Click while the join/reset button is kept pressed. The LED indicator on the front will start blinking. This indicates that the Almond Click is being added to your Almond router.

Step 4: Wait for the Almond router to finish adding the Almond Click. You will see a message that the sensor has been added. Enter a name and location for the sensor and tap on “Done”.

Step 5: Snap the back cover on to the Almond Click. Make sure that the lanyard holes in the body of the Almond Click and the back cover are lined up.

Step 6: On the Almond LCD, go back to the “Home” screen and tap on “Connected Sensors” and tap on the sensor you just added. Next tap on “Tampered” to reset the tamper switch.

Your sensor should now be fully operational. Click the push button once and twice to see “One Press” and “Two Press” on the Almond LCD.

Resetting and Almond Click

To reset the Almond Click, remove the back cover and remove the battery from the battery holder. Wait for 10 seconds, and then reinsert the battery while the Join/Reset switch is pressed. The LED indicator on the front of the Almond Click will start blinking, and the reset process will be complete once the LED stops blinking.

Using the Almond Click

1. You can press the push button once for “One Press” and twice quickly for “Two Press”.
2. You can control other devices like smart plugs with the Almond Click by creating rules on our free Almond app available for Android and iOS. The apps also have more information and help about creating and using rules.
3. You can also use the Almond’s local web user interface available at <http://10.10.10.254> by default, to create rules and control other devices with Almond Click.

Troubleshooting

The Almond Click can’t be added to an Almond router

Please reset the Door/Window Sensor as described in the reset section above and try to add it again.

The LED does not flash

Please make sure you’ve inserted the battery the correct way with the positive side facing you. You could also try using another battery if the one you have is dead.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

For product available in the USA/Canada market, only channel 1~11 can be operated. Selection of other channels is not possible.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements ISEDétablies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.