

<b>TYPE OF EXHIBIT:</b>	OPERATIONAL DESCRIPTION
<b>FCC PART:</b>	2.1033 (c)(6)
<b>MANUFACTURER:</b>	RITRON, INC. 505 West Carmel Drive Carmel, IN 46032
<b>MODELS:</b>	SPX-200
<b>FCC ID:</b>	AIERIT19-150
<b>DATE:</b>	December 28, 2004

<b>IC STANDARDS:</b>	RSP-100, Issue 8, Section 7.2(b)
<b>INDUSTRY CANADA:</b>	1084A-RIT19150
<b>MODELS:</b>	SPX-200-BC, SPX-200-CANADA

Included in this exhibit is a draft of the Maintenance and Operating Manual for the Ritron Model SPX-200 VHF-FM Portable Transceiver.

Specifically, the manual includes a technical description of the SPX-200 sufficient to establish compliance with the technical standards of the applicable rule part(s).

This includes, but is not limited to, the following items required under FCC Part 2.1033(c):

- (1) FCC Identifier.
- (2) A copy of the installation and operating instructions.
- (3) Type of emission.
- (4) Frequency range.
- (5) Range of operating power, and means to provide variation in operating power.
- (6) Maximum power rating.
- (7) Tune-up procedure.
- (8) A description of all frequency determining and stabilization circuits. A description of the circuits used to suppress spurious radiation, limiting modulation, and limiting power.
- (9) Drawing with labels for controls and complete circuit diagrams.

Signed:



Kevin G. Matson - Project Engineer

# SPX-200

(Preliminary)

## **MAINTENANCE / REPAIR / OPERATING MANUAL**

# TABLE OF CONTENTS

<b>CONTENTS .....</b>	<b>1</b>
<b>1. INTRODUCTION .....</b>	<b>60</b>
<b>2. OPERATION FEATURES .....</b>	<b>3</b>
<b>3. TECHNICAL SPECIFICATIONS .....</b>	<b>61</b>
1) GENERAL .....	4
2) TRANSMITTER.....	4
3) RECEIVER .....	4
<b>4. CIRCUIT DESCRIPTION .....</b>	<b>5</b>
1) PHASE-LOCK LOOP (PLL) CIRCUIT.....	5
2) TRANSMITTER .....	5
3) RECEIVER .....	62
<b>5. ALIGNMENT PROCEDURE .....</b>	<b>6</b>
1) MEASUREMENT CONDITION .....	6
2) DISASSEMBLING THE UNIT.....	63
3) TRANSMITTER CIRCUIT ADJUSTMENT .....	7
4) RECEIVER CIRCUIT ADJUSTMENT .....	64

# 1. INTRODUCTION

This manual is intended for use by experienced technicians familiar with similar types of commercial grade communications equipment. SPX-200 is a micro size FM transceiver operating between 136 ~ 174 MHz. With the output power of 5 W(1 ~ 5 W).

In addition to its small size, the SPX Series offers many advanced features that could only be found in the most expensive Land Mobile Radios.

## 2. OPERATION FEATURES

### 2-1) Physical Layout



### 2-2) Panel controls

- ❑ Power switch / Volume Control  
Turn clockwise to switch ON the transceiver. Rotate to adjust the volume. To switch OFF the transceiver, turn counterclockwise fully.
- ❑ Emergency button  
Pressing this key to enter the emergency mode
- ❑ Antenna connector  
Connect the supplied antenna here (SMA connector)
- ❑ TX / RX / Battery Indicator (LED 3 colors)

Red	On	Transmitting
	Blinking	Low battery
Green	On	Receiving, monitoring
	Blinking	Different sub-tone when receiving
Orange	On	Initializing, programming and cloning

- ☐ Function button (Menu / Esc.)
- ☐ Universal connector  
Connect the external accessories (speaker / microphone, cloning cable & wall charger) (optional)
- ☐ Belt clip
- ☐ MIC.
- ☐ PTT(Push To Talk) Button  
Hold down to transmit, release to receive.
- ☐ Channel Select Button (Up & Down buttons)  
Select the desired channel with pressing Up and Down button, pressing and holding down more than 1 second
- ☐ Monitor Button  
Press to monitor. Holding down over 2 seconds keeps monitoring function on, and press shortly again or PTT Button to stop.
- ☐ Lamp  
This key illuminates the LCD and keys on the front panel.
- ☐ Programmable keys

### 3. TECHNICAL SPECIFICATIONS

#### 1) GENERAL

1) Frequency Range	: 136 ~ 156 MHz / 146 ~ 174 MHz
2) Modulation Type	: 11K0F3E / 16K0F3E (FM)
3) Channel capacity	: 128 channels
4) Channel spacing	: 12.5 kHz / 25kHz
5) Power Supply	: DC 7.5V, Ni-Mh Rechargeable Pack
6) Current Drain	: High Transmitter (5W) ----- 2000mA Receiver (0.5W) -----350mA Standby-----45mA Standby (PSC mode)-----40mA
7) Battery Life	: 10hrs (Ni-Mh Rechargeable Pack) (At 5%-5%-90% transmit-receive-standby cycles)
8) Operating Temperature	: -30□ to +50□
9) Dimension	: 110(H) x 50.5(W) x 37.5(D) mm
10) Weight (W/Batteries)	: 320g (1350mAH Rechargeable battery)

#### 2) TRANSMITTER

1) Power Output	: High (5W), Low (1W)
2) Frequency Stability	: Better than +/- 0.0005% within operating temperature
3) Hum & Noise	: -45dB (with 300Hz to 3KHz audio filter)
4) Spurious Emissions	: Less than -65dBc
5) Audio Distortion	: Less than 5% (1KHz tone 60% modulation)
6) Audio Response @6dB/oct	: +1 to -3dB
7) Max deviation	: ±2.5kHz at 12.5kHz / +/-5.0kHz at 25kHz

#### 3) RECEIVER

1) Sensitivity (12dB SINAD)	: Less than 0.25 uV(-119dBm)
2) Selectivity	: -70dB
3) Hum & Noise	: -45dB
4) Inter-modulation	: -65dB
5) Spurious and image rejection	: 70dBc
6) Maximum Audio Output(16Ω)	: More than 500mW
7) Audio Distortion	: less than 5% at 1kHz deviation

## 4. CIRCUIT DESCRIPTIONS

### 1) PHASE-LOCK LOOP (PLL) CIRCUIT

#### \* REFERENCE OSCILLATOR

The reference oscillator consists of X401 in U401 with a frequency of 12.8MHz. The reference oscillator frequency is stabilized by the thermistor R403 and drives a divider to produce a comparison frequency. This comparison frequency is selected by decoding the first three bits of the data input from microcomputer.

#### \* PROGRAMMABLE DIVIDER

The programmable divider in U401 consists of a two-modulus prescaler with a 7bit control register followed by a 11-bit internal programmable divider. The overall division ratio is selected by a single 19-bit word located on the serial data bus.

#### \* PHASE COMPARATOR

A digital-type phase comparator in U401 with output (pin 6) and an open drain lock detect output (pin 10) compares divided VCO frequency with the comparison frequency.

#### \* VCO CIRCUIT

*The transmit/receive frequency is directly generated by the Colpitts oscillation circuit contains Q402, Q405. The oscillation frequency is variable by applying the VCO control voltage to variable to variable capacitors D401, D402, D403, D404 and D405, 406, 407, 408.*

### 2) TRANSMITTER

#### \* MIC AMP CIRCUIT

Voice signal from the microphone are applied to microphone amplifier U8 through MK2.

U8 contains a low-pass filter that has a 6dB/oct response between 300Hz and 3 kHz and eliminates harmonics above 3 kHz. The Pre-emphasized audio signal is applied U8 pin 22 to adjust maximum frequency deviation by software.

#### \* VCO AND AMPLIFIER

The VCO signal output is amplified by Q101 and then fed to power module U405.

#### \* POWER AMPLIFIER CIRCUIT

U405 is provided approximately 7.5V DC power source.

RF power output is adjusted by software (DA-TX power) to 1W~5W.

Signals from U405 is supplied through antenna switch D101 to a low-pass filter made up of L101, L102, L103 and C101-C106, then applied to Antenna Jack.

### 3) RECEIVER

#### \* ANT SWITCHING CIRCUIT

Signals from antenna connector fed to the antenna switching circuit through the low pass filter consisting of L101~106. In receive mode, D101 is turned off, isolates the antenna from the transmitter circuit and matching circuitry, so that the incoming signals are fed to the RF amplifier through L105.

#### \* RF AMPIFIER CIRCUIT

The signals from the switching circuit are fed to the RF amplifier Q201 through a band pass filter made up of spring coil, vvc diode and capacitor.

#### \* FIRST MIXER CIRCUIT

The amplified signals are fed to Gate 1 of the first mixer Q202 through C230. First local oscillator signal is supplied to Gate 2 of Q202 from the PLL circuit through C258 to convert the RF signals into 21.4MHz first IF signal.

#### \* IF CIRCUIT

The first IF signals from Q202 are fed to the matched pair crystal filter XFL201, then IF signals are amplified in Q203. And those signals are fed to U201, which is composed of the second local oscillator, second mixer, limiter

amplifier, quadrature detector and active filter circuit. The second local oscillator at 20.945MHz with X202 and is fed to the second mixer with the first IF signals to convert into 455kHz second IF signals.. The second IF signals leave through pin 3, and are fed to external ceramic filters XFL203, XFL204 which has excellent selectivity, then fed to U201 (pin 5) again to be amplified and detected. Narrow /Wide band are switched by software. The detected AF signals are output from pin 9.

#### \* AUDIO AND SQUELCH CIRCUIT

The detected audio signals are put through a 6dB/oct de-emphasis circuit made up of R221 and C248. The signal is then applied to audio power amplifier U3 through the volume control VR1 to obtain enough power to driver the speaker.

Part of the recovered noise signal is fed to the integrated operational amplifier inside U201, which, with R232, C256, C257 makes up an low pass filter . The DC signal detected by U201 (pin13) reaches the integrated DC amplifier in U201 which has hysteresis to prevent jitter. The sensitivity of squelch is adjusted by VR201.

## 5. ALIGNMENT PROCEDURE

### 1) MEASUREMENT CONDITION

The following sections describes the alignment procedure for SPX-200 VHF transceiver under the following reference environment conditions:

Temperature	:	25° C (77° F)
Relative Humidity	:	65%
Power Supply Voltage	:	7.5VDC +/- 5%

### TEST EQUIPMENT / TOOLS REQUIRED

The following list of equipment is recommended for use in setting up the radio properly. Please ensure the test equipment are calibrated according to the manufacturer's instructions:

- Frequency counter more than 100MHz +/-100Hz tolerance, high input impedance and high sensitivity
- FM Signal generator, 1GHz with adjustable frequency, FM deviation, and RF output attenuators. 50Ω Output impedance.
- Oscilloscope, high input impedance.
- 16Ω 1 Watt resistor as loudspeaker load
- Audio Signal Generator, 10Hz to 20KHz, 600Ω impedance with attenuators.
- RF Watt meter, with 50Ω 10 Watt termination resistor (Or RF Voltmeter with 50Ω termination and external 50Ω attenuators)
- Regulated Power Supply 7.5VDC 3A output
- Digital A-V-O Multi-meter
- SINAD Meter
- External Speaker Mic. plug (or special audio test jig)
- Interconnection test cable for RF and Control PCB
- Circuit Diagram for SPX-200
- PCB layout diagram for SPX-200
- Tuning tools for RF/IF transformer and the VR potentiometers

### 2) DISASSEMBLING THE UNIT

The antenna

Disconnect the antenna

The Cover

- Remove the battery.
- Remove the 2 screws.
- The case could then be opened for servicing.
- Be careful NOT to disconnect the pin connector between RF board and Control board.

The PCBs

- The radio consists of two PCBs, the RF (rear side) and control board (front side)..
- On the RF Board, connect ANT1 to a signal generator or RF power meter.
- On the RF Board, connect Power Supply to the battery terminal contacts.
- Connect External Speaker Mic Plug (or Audio Test Jig) to J3.

### **3) TRANSMITTER CIRCUIT ADJUSTMENT**

- Crystal frequency  
On receiving mode, check Crystal output is at 12.8MHz
- Transmitter Frequency  
Connect RF Power meter to ANT1, Activate PTT to transmit on 146.125MHz.
- Transmitter Output Power  
Activate PTT to transmit on 146.125MHz, Output power is adjustable by software
- Transmitter Sub-Audible Tone Deviation  
Set radio to transmit on M146.125Hz, with CTCSS code 01 (67Hz) and no audio modulation. It is adjustable by software for 0.45KHz deviation.
- Transmitter Deviation Limit  
Set radio to transmit on 146.125MHz, with CTCSS code 01 (67Hz) and audio modulation. At the external microphone input, inject 1KHz tone at -20dBm. It is adjustable by software for 2.3KHz deviation.

### **4) RECEIVER CIRCUIT ADJUSTMENT**

- FM Demodulator Adjustment  
Set radio to receive on 146.125MHz, No CTCSS or DCS. Connect RF Signal Generator to ANT1, Set generator to 146.125MHz at -60dBm (50Ω) output with 1KHz tone modulation at 1.5KHz deviation.
- Receiver Squelch Adjustment  
After checking the receiver sensitivity, further lower the RF Signal Generator output to 8-10dB SINAD and observe the squelch circuit operates. Adjust VR201 if necessary.