

# **Operational Description**

**- Model RC-S430C -**

**Version 1.0**

**Sony Corporation**

## Reader/Writer Operation

After turning on the power switch, the Reader/Writer transmits 13.56MHz 10% ASK polling signal with the specified intensity until receiving a response from a contactless card. After receiving the response from a card the device starts to communicate with the card by using the same frequency and modulation. Though the reader/writer is a self-operating device according to the program installed in the FLASH memory, it can be connected to a host computer (Controller) for more complicated applications by taking out the reader/writer from the enclosure. For the connection to a host computer, refer to the initialization and communication protocols described below.

### 1 Connection with Controller

The connection with controller shall be done as follows.

- Interface Connector : Methode 1100-12-110-02 (right angle)

The interface connector is a 10-pin connector located at the right edge of the RF/Control board which is shown in the schematic drawing of Fig.6. The pitch of connector pins is 2.54mm. The most upper connector pin is No. 1. Pin assignment of the connector is shown in Fig. 4 and Table 4.

|               |   |   |
|---------------|---|---|
| 12V           | : | DC input port   |
| GND           | : | Ground port   |
| SHDN          | : | Shut Down (No Connection in usual operation)<br>Power supply for the circuit on the RF/Control board can be shut down by applying high level voltage (5V) to the pin. |
| RX+,- , TX+,- | : | Serial Data I/O (RS-485)  |
| RXD,TXD       | : | Serial Data I/O (CMOS 5V or RS-232C)  |




Fig.1 : Pin Assignment of Connectors CN1-2

| Pin No.        | 1    | 2   | 3    | 4   | 5   | 6   | 7   | 8   | 9   | 10  |
|----------------|------|-----|------|-----|-----|-----|-----|-----|-----|-----|
| Pin Assignment | SHDN | GND | DCIN | RX- | RX+ | TX- | TX+ | TXD | GND | RXD |

Table 1 : Pin Assignment of Interface Connector CN2

- Power

voltage : DC12V (shall be applied to DCIN of CN2)

voltage allowance : +4V, -0.5V

current :  $\approx 180mA$

voltage ripple allowance :  $100mV$  (peak-to-peak)

The *Reader/Writer* can be operated in the voltage range of 7-11.5V and the voltage ripple  $> 100mV$ , however operating distance cannot be assured in such condition.

- External Interface

serial 1 port : RS-485A, RS-232C and CMOS logic level(5V)

software selectable, non-inverted or inverted, and baud rate

(default setting : CMOS 5V, non-inverted, 115.2kbps)

Common pins are assigned for RS-232C and CMOS logic level. RS-232C is available by mounting MAX3221CAE(MAXIM) as IC10, 4 capacitors C53-56 and 2 resistors R49-50 and removing 2 resistors R43-44 which are located near the right, lower corner of the RF/Control board as is shown in Fig.5.

## 2 Transaction Overview

### 2.1 Communication Protocol

There are two communication protocols, namely, data link level and application level protocol.

Either ACK or NACK packet is returned in every packet transfer. ACK indicates a successful transfer, NACK means unsuccessful.




Fig. 2 : Communication Protocol and Packet Structure

### 2.2 Re-sending Protocol

*Reader/Writer* supports the re-sending procedure in *Controller* interface. Re-sending handling is triggered or required in the two cases below :

1. NACK packet is returned.
2. Neither ACK nor NACK response comes. (time out)

*Controller* should re-send the same packet within 5ms after receiving NACK or detecting time out.

### 2.3 ACK / NACK Packet

ACK / NACK packet format is as follows :

ACK : LEN = 00h & LCS = ffh without Packet Data part and DCS  
NACK : LEN = ffh & LCS = 00h without Packet Data and DCS

## 2.4 Mutual Authentication

Mutual Authentication is a process that is performed between *Controller* and *Reader/Writer* to authenticate each other mutually in order to avoid the fraud usage.

This authentication is based on the following elements :

1. two 8byte (64bit) keys
2. three pass authentication model (ISO 9758)
3. cryptography algorithm mentioned in section 3.2.5.

## 2.5 Encryption and Decryption

The cryptography algorithm is used for the following three stages :

1. mutual authentication between *Controller* and *Reader/Writer*
2. mutual authentication between *Reader/Writer* and *Card*
3. commands and data encryption through *Reader/Writer*

# 3 Communication Commands

## 3.1 General

In this section, the communication commands between *Controller* and *Reader /Writer* are described.

Table 1-3 shows all commands between *Controller* and general *Reader/Writer*. All commands are categorized into 3 groups as follows :

1. *Reader/Writer* internal operation command
2. *Card* operation command
3. *Card* management command

*Card* management command group is for issue *Reader/Writer* and not for general *Reader/Writer* .

## 3.2 *Reader/Writer* Internal Operation Command

### 3.2.1 Attention Command

Attention Command enables *Reader/Writer* and *Controller* to recognize each other and is the only command available before the authentication completes. The main purpose of this Attention Command is to recognize its partner before authentication and to force *Reader/Writer* to be in the idle state.

### 3.2.2 Authentication 1 Command

Authentication 1 Command enables *Controller* to authenticate *Reader/Writer*.

### 3.2.3 Authentication 2 Command

Authentication 2 Command enables *Reader/Writer* to authenticate *Controller*.

### 3.2.4 Disconnect Command

Disconnect Command is for *Controller* to terminate the communication with *Reader/Writer*.

| Command                         | Command Code | Response Code |
|---------------------------------|--------------|---------------|
| Attention                       | 00h          | 01h           |
| Authentication 1                | 02h          | 03h           |
| Authentication 2                | 04h          | 05h           |
| Disconnect                      | 06h          | 07h           |
| Change Reader/Writer Access Key | 20h          | 21h           |
| Self-Diagnosis                  | 40h          | 41h           |
| Check Firmware Version          | 44h          | 45h           |
| Change Communication Mode       | 46h          | 47h           |
| Kill Module                     | 4ah          | 4bh           |
| Reader/Writer Reset             | 4ch          | 4dh           |
| Firmware Maintenance            | 52h          | 53h           |

Table 2 : *Reader/Writer* Internal Operation Command

| Command                  | Command Code | Response Code |
|--------------------------|--------------|---------------|
| Polling                  | 80h          | 81h           |
| Request Service          | 82h          | 83h           |
| Request Response         | 84h          | 85h           |
| Mutual Authentication    | 86h          | 87h           |
| Read Block               | 88h          | 89h           |
| Write Block              | 8ah          | 8bh           |
| Release                  | 8eh          | 8fh           |
| Read Without Encryption  | 98h          | 99h           |
| Write Without Encryption | 9ah          | 9bh           |

Table 3 : *Card* Operation Command

| Command                 | Command Code | Response Code |
|-------------------------|--------------|---------------|
| Register Issue ID       | c0h          | c1h           |
| Register Area           | c2h          | c3h           |
| Register Service        | c4h          | c5h           |
| Register Manufacture ID | e0h          | e1h           |
| Card Self-Diagnosis     | f0h          | f1h           |

Table 4 : *Card* Management Command

**3.2.5 Change Reader/Writer Access Key Command**

Change Reader/Writer Access Key Command performs alteration of the access keys, which are stored in *Reader/Writer* for the mutual authentication between *Controller* and *Reader/Writer*.

**3.2.6 Self-Diagnosis Command**

Self-Diagnosis Command activates self-diagnosis test of *Reader/Writer*. After the Diagnosis completion, *Reader/Writer* sends back the test result.

**3.2.7 Check Firmware Version Command**

Check Firmware Version Command is used for checking the version of *Reader/Writer* firmware.

**3.2.8 Change Communication Mode Command**

Change Communication Mode Command performs the following changes : baud rate, logic level interface(non-inverted or inverted), encryption on/off, time-out.

**3.2.9 Kill Module Command**

Kill Module Command is used for killing the specified module within *Reader/Writer*.

**3.2.10 Reader/Writer Reset Command**

*Reader/Writer* Reset Command executes the initialization routine.

**3.2.11 Firmware Maintenance Command**

Firmware Maintenance Command is used for updating the firmware within *Reader/Writer*.

**3.3 Card Operation Command****3.3.1 Polling Command**

Polling Command enables *Reader/Writer* to give a call to *Card* and to detect existence of *Card* by the response from *Card*.

**3.3.2 Request Service Command**

Request Service Command enables *Reader/Writer* to check whether the specified service code is registered to *Card* or not. In case that the specified service is registered to *Card*, key version of the service is available by the response from *Card*.

**3.3.3 Request Response Command**

Request Response Command enables *Reader/Writer* to check which mode *Card* is in. There are 4 modes, ‘before Authentication’, ‘after Authentication 1’, ‘after Authentication 2’ and ‘after Register xxx Command (see 4.4 Card Management Command)’.

**3.3.4 Mutual Authentication Command**

Mutual Authentication Command activates the mutual authentication procedure between *Reader/Writer* and *Card*.

**3.3.5 Read Block Command**

Read Block Command activates *Reader/Writer* to read the specified block data from *Card* after the mutual authentication between the *Reader/Writer* and *Card* has been established successfully.

Read Block Command enables a Service Provider with successful mutual authentication to read blocks that this Service Provider has the right to access.

With one Read Block Command, up to 8 block can be read simultaneously. If more than 8 blocks should be read, more than one Read Block Command shall be called separately.

The response of Read Block Command is a *1byte* Read result and Block Data that has been read. In the Read result, a *1byte* consequence of one block Read is given in *1bit*. As there are up to 8 blocks, *1byte* is enough to record all the Read consequence.

### 3.3.6 Write Block Command

Write Block Command activates *Reader/Writer* to write the specified block data to *Card* as new data after the mutual authentication between *Reader/Writer* and *Card* has been established successfully.

With one Write Block Command, up to 8 block can be written simultaneously. If more than 8 blocks should be written, more than one Write Block Command shall be called separately.

The response of Write Block Command is a *1byte* Write result. In the Write result, a *1byte* consequence of one block Write is given in *1bit*. As there are up to 8 blocks, *1byte* is enough to record all the Write consequence.

The purse operation can be performed with Write Block Command.

### 3.3.7 Release Command

Release Command enables *Card* to be released from established communication sequence with *Reader/Writer*.

### 3.3.8 Read Without Encryption Command

Read Without Encryption Command activates Reader/Writer to read the specified block data from *Card* without the mutual authentication between the *Reader/Writer* and *Card*. Read Without Encryption Command can be applied only to blocks which service code is registered security-free.

The number of blocks that can be read simultaneously and the response of Read Without Encryption Command are the same as those for Read Block Command (see 4.3.5).

### 3.3.9 Write Without Encryption Command

Write Without Encryption Command activates Reader/Writer to write the specified block data to *Card* without the mutual authentication between the *Reader/Writer* and *Card*, however can be applied only to blocks which service code is registered security-free.

The number of blocks that can be write simultaneously and the response of Write Without Encryption Command are the same as those for Write Block Command (see 4.3.6).

## 3.4 Card Management Command

The commands described in this section are for issue *Reader/Writer* and not for general *Reader/Writer*.

### 3.4.1 Register Issue ID Command

Register Issue ID Command makes it possible to register Issue ID(IDi) , Issue Parameter(PMi), System Code and Area 0000 Key to *Card*, and also makes it to erase other services and to initialize Memory Allocation Information in *Card*.

### 3.4.2 Register Area Command

Register Area Command makes it possible to register new Area and the parameters of new Area to *Card*, which are Service Code Range, Available Block Number and Area Key.

### 3.4.3 Register Service Command

Register Service Command makes it possible to register new Service and the parameters of new Service to *Card*, which are Service Code, Block Number and Service Key.

#### **3.4.4 Register Manufacture ID Command**

Register Manufacture ID Command makes it possible to register Manufacture ID(IDm) , Manufacture Parameter(PMm), System Code, System Key and Area 0000 Key to *Card*, and also makes it to clear Issue ID of *Card*.

In order to execute Register Manufacture ID Command, Manufacture ID must be all 00h. This means that Register Manufacture ID Command is effective to *Card* once for all.

#### **3.4.5 Card Self-Diagnosis Command**

Card Self-Diagnosis Command activates self-diagnosis test of *Card*. After the Diagnosis completion, *Card* sends back the test result.