

## ASSEMBLY INSTRUCTIONS

**IMPORTANT:** Please view the enclosed Training Video before operating the glider

### STEP 1 INSTALL BATTERIES

**Transmitter:** Remove the screw on the bottom of the battery panel of the pistol-grip R/C transmitter. Slide panel to open compartment:



Insert one 9-volt battery into R/C transmitter as shown above. Match the "+" and "-" symbols on the inside of the transmitter to each battery. Close cover, slide back in place, and replace screw.

DO NOT OVERTIGHTEN

**SAFETY PRECAUTION: DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (CARBON-ZINC), OR RECHARGEABLE (NiCad) BATTERIES.**

**Glider Body:** Remove the screw holding the battery panel door on the bottom of the glider body, slide panel towards the front of the pod, and flip panel up to uncover battery area.




Insert the 4 AAA batteries into the compartment as shown above. Match the "+" and "-" symbols on the inside of the glider body to each battery. Then close the cover, slide it back in place, and replace the screw.

DO NOT OVERTIGHTEN


### STEP 2 SCREW IN ANTENNA

Screw antenna into the R/C transmitter as shown below. DO NOT OVERTIGHTEN.




### STEP 3 INSTALL CROSS ROD

Install the cross rod into the small fabric holders on either side of the top of the wing. The picture below shows an insertion of the crossrod into one side of the wing.




### STEP 4 CONNECT LAUNCH MECHANISM

Connect the launcher string-clip to the Glider Body by inserting the "L" shaped end of the clip into the cavity at the back of the pod as shown in the next column. Then simply push the other end of the clip towards the pod until it "clicks" in place. (The assembled launch mechanism includes: the clip, the black elastic cord, the tail connector and rod, and the flight streamers)



Next, tie the loose end of the white flight-string (from the controller) onto the clip as indicated.

Then, stretch the black elastic line, and insert the tail mechanism onto the center rod of the wing.



## STEP 5 CHECK FINISHED ASSEMBLY


The Aggressor Glider is now assembled. The transmitter is now fully assembled with the antenna screwed into the casing. The launch string has been attached to the launch mechanism which is now attached to the glider as shown on the bottom of the next column. Batteries have been installed in both the transmitter and the glider body and the battery compartment doors have been screwed in place. The cross-rod has been put in place on the top of the wing, spreading the wing for flight.

Now it is time to familiarize yourself with the Glider and R/C transmitter.

## STEP 6 LEARN CONTROLLER LAYOUT


Familiarize yourself with the location of the following items:

- ① Low Battery Indicator Light
- ② Turbo-Release button disconnects glider kite string
- ③ On/Off switch for transmitter
- ④ String-reel holds launch string
- ⑤ Trim buttons enable centering of pod (if needed)
- ⑥ Right/Left steering trigger



## STEP 7 TEST R/C CONTROLS

Test the transmitter range every time you fly. Turn the transmitter "power" switch "on". Turn the glider body switch "on" as shown below, collapse the antenna and take the transmitter 25 feet from the glider. Push and pull the trigger button and watch the glider body move. If there is any erratic movement you might be experiencing radio interference from other 27 MHz users. These could be CB radios, other R/C airplanes or R/C cars. If the glider is moving erratically, DO NOT FLY.



## FLIGHT INSTRUCTIONS

**IMPORTANT:** Please view the enclosed Training Video before operating the glider


### STEP 8 FIND A SAFE FLYING AREA

Find a safe flying area. The area should be about the size of a football field. Do not fly near people, streets, houses, trees, or power lines.

**SAFETY PRECAUTION:** The number on the transmitter shows the frequency RC controller. It is not possible for 2 models to operate on the same frequency at the same time. If you turn your transmitter on when another model is operating on your frequency, you could cause that model to lose control. If there are other R/C airplanes or R/C cars operating in the area always check to see if you're using the same

### STEP 9 SOLO-LAUNCH HOLDER

Insert Launch Pole into the ground and insert Glider as shown.



### STEP 10 FEED OUT STARTER STRING

Slowly unwind string while moving away from the launch pole and glider.

**SAFETY PRECAUTION:** ALWAYS WEAR GLOVES WHILE FLYING THE GLIDER. THIS WILL PREVENT THE STRING FROM CUTTING YOUR HANDS, IN CASE IT RAPIDLY UNWINDS. THE GLOVES WILL ALSO PROTECT WHILE WINDING THE STRING BACK ONTO THE REEL.

*HELPFUL HINT:* Practice using the R/C transmitter while the glider is in the launch tube by pulling and pushing the trigger control with your index finger.

### STEP 11 LAUNCH GLIDER

**SAFETY PRECAUTIONS:**

- PICK A LARGE SITE TO FLY THE GLIDER
- NEVER FLY NEAR OBSTACLES SUCH AS ROADS, POWER/ELECTRICAL LINES, TREES, AND BUILDINGS OR HOUSES.
- NEVER FLY IN WINDS ABOVE 10 MPH.

Pull the string tight and quickly pull the R/C Transmitter so that it pulls the Glider out of the launch tube. Keep moving backward to maintain the tension on the line.

**SAFETY PRECAUTION:** NEVER RUN OR WALK BACKWARDS. YOU MAY TRIP, FALL, OR INJURY YOURSELF OR OTHERS. ALWAYS MAINTAIN A LINE OF SIGHT IN THE DIRECTION THAT YOU ARE MOVING.

### STEP 12 MAXIMIZE ALTITUDE

To allow the glider to gain altitude, turn your wrist to the left. The tension from the glider will automatically unwind the string from the controller. To stop unwinding, turn your wrist back straight again. Repeat this motion to achieve the desired altitude. SEE THE VIDEO FOR MORE FLYING HINTS

### STEP 13 RELEASE GLIDER FROM STRING

To release the string from the glider push the "turbo release" button and the string will disengage (along with the glider's launch mechanism) and fall to the ground.

**SAFETY PRECAUTION:** VERIFY THAT THE GLIDER HAS NOT STRAYED INTO AN AREA THAT IS UNSAFE PRIOR TO RELEASING THE STRING. DO NOT RELEASE STRING IF PEOPLE ARE UNDER THE GLIDER

After the string has been released, you will be able to fly the glider back to the ground. Remember that if the glider is flying toward you, the controls for right and left will be opposite.

### STEP 14 FLY GLIDER

After releasing the glider, use the control trigger to steer the glider left and right.

**SAFETY PRECAUTION:** NEVER FLY TOWARDS OBSTACLE SUCH AS ROADS, POWER/ELECTRICAL LINES, TREES, PEOPLE, OR BUILDINGS/HOUSES. IF THE GLIDER IS HEADING TOWARDS A DANGEROUS OBSTACLE OR A PERSON, QUICKLY STEER THE GLIDER AWAY AND WARN THE PERSON OF THE GLIDER'S APPROACH.

### STEP 15 LAND GLIDER

For soft landings point glider into the wind when landing.

**SAFETY PRECAUTION: IF THE GLIDER IS SPIRALLING TOWARDS THE GROUND RELEASE THE TRIGGER SO THAT IT CAN LEVEL OUT. NOT DOING SO, COULD CAUSE THE GLIDER TO BE DAMAGED**

### STEP 16 REWIND STRING, & POWER OFF

After landing the glider, walk over to the string clip as you rewind the string onto the spool.

**SAFETY PRECAUTION: DO NOT REWIND STRING WITHOUT WALKING TOWARDS THE STRING CLIP. REWINDING FROM A STATIONARY POSITION CAN CAUSE THE CLIP TO SNAG AND SNAP THE STRING OR POP IT INTO THE AIR CAUSING INJURY. REMEMBER TO WEAR GLOVES WHILE REWINDING THE STRING.**

*HELPFUL HINT: AFTER YOU ARE FINISHED FLYING THE AGGRESSOR, MAKE SURE THAT YOU HAVE TURNED BOTH THE GLIDER & TRANSMITTER OFF.*

## TROUBLESHOOTING


See Instructional Video for Troubleshooting

### WARRANTY INFORMATION

RCKid Toys will repair or replace factory defects for 90 days from the date of purchase. This warranty specifically does not cover crash damage or abuse. If you find a defect, or need replacement parts, please contact RCKid Toys Service Center. If you wish to return a defective part to RCKid Service Department, send only the part with your purchase receipt, or other adequate proof of purchase, to the Customer Service Department P.O. Box 6179, Baltimore, MD 21231-3406, and RCKid will repair or replace it if judged to be factory defective. There will be an additional handling charge if you send the whole model.

This warranty applies only if the product is operated with adult supervision and in compliance with assembly and operating instructions provided with each model. RCKid Toys assumes no liability except for the exclusive remedy of repair or replacement of parts as specified above. RCKid Toys shall not be liable for consequential or incidental damages. Some states do not allow the exclusion of incidental or consequential damages so the above information may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state.

Big Bang Products, LLC  
P.O. Box 6179 Baltimore, MD 21231  
Toll Free: 877-725-4386



**AGES 8 & UP**

**Adult Supervision  
Required**

## Aggressor Instruction Manual

**PLEASE READ ALL WARNINGS & INSTRUCTIONS, AND WATCH THE ENCLOSED VIDEO BEFORE OPERATING THE AGGRESSOR.**

### CAUTION


FCC regulations state that changes or modifications to this product, not expressly approved by the party responsible for compliance, could void the user's authority to operate the equipment.

### WARNING

- ◆ IMPROPER USE OF THIS PRODUCT MAY RESULT IN PERSONAL INJURY OR DAMAGE TO THE PRODUCT
- ◆ YOU ARE RESPONSIBLE FOR THE SAFE OPERATION OF THIS PRODUCT.
- ◆ USE WITH ADULT SUPERVISION. FLY IN AN OPEN AREA. NEVER FLY NEAR POWER LINES, ROADS, HOUSES, BUILDINGS, CARS, OR TREES
- ◆ HAVE ALL SPECTATORS STAND CLEAR WHEN LAUNCHING THE GLIDER.

### IMPORTANT

**DO NOT RETURN THIS PRODUCT TO THE STORE. PLEASE CALL THE RCKID HOTLINE TOLL-FREE:**

 **1-877-725-4386** 