SCobra



Operating Instructions

The Cobra line of quality products includes:

CB Radios

microTALK® Radios

Radar/Laser Detectors

Safety Alert® Traffic Warning Systems

Accessories

GPS (Global Positioning System)

HighGear® Accessories

VHF Marine Radios

Power Inverters

11 BAND"
HIGH-PERFORMANCE
RADAR/LASER DETECTOR
WITH XTREME RANGE
SUPERHETERODYNE"
TECHNOLOGY

XRS 9300

Printed in China Part No. 480-103-P

OXKKaVSL

For more information or to order any of our products, please visit our website:

www.cobra.com

Nothing comes close to a Cobra[®]

English



Important Information And Customer Assistance

Important Information

Federal Laws Governing The Use Of Radar Detectors

It is not against federal law to receive radar transmissions with your Cobra radar/ laser detector. The Communications Act of 1924 guarantees your right to receive radio transmissions on any frequency. Local laws that contravene this Act, while illegal, may be enforced by your local law enforcement officials until and unless they are prohibited from doing so by federal court action.

Safety Aler

Use of this product is not intended to, and does not, ensure that motorists or passengers will not be involved in traffic accidents. It is only intended to alert the motorist that an emergency vehicle equipped with a Cobra Safety Alert transmitter is within range as defined by that product. Please call local fire and police departments to learn if coverage exists in your area.

Safe Driving

Motorists, as well as operators of emergency or service vehicles, are expected to exercise all due caution while using this product, and to obey all applicable traffic laws.

Security Of Your Vehicle

Before leaving your vehicle, always remember to conceal your radar detector in order to reduce the possibility of break-in and theft.



Customer Assistance

Should you encounter any problems with this product, or not understand its many features, please refer to this owner's manual. If you require further assistance after reading this manual, Cobra Electronics offers the following customer assistance services:

For Assistance In The U.S.A.

Automated Help Desk English only. 24 hours a day, 7 days a week 773-889-3087 (phone).

Customer Assistance Operators English and Spanish. 8:00 a.m. to 6:00 p.m. CT Mon. through Fri. (except holidays) 773-889-3087 (phone).

Questions English and Spanish. Faxes can be received at 773-622-2269 (fax).

Technical Assistance English only. www.cobra.com (on-line: Frequently Asked Questions). English and Spanish. productinfo@cobra.com (e-mail).

For Assistance Outside The U.S.A. Contact Your Local Dealer

©2003 Cobra Electronics Corporation 6500 West Cortland Street Chicago, Illinois 60707 USA www.cobra.com



Nothing comes close to a Cobra®

English



Controls, Indicators And Connections


Controls, Indicators And Connections





Display And Product Features

Display



Product Features

Congratulations! You've made a smart choice by purchasing the XRS 9300 high performance radar/laser detector from Cobra. Just look at some of the sophisticated features and capabilities your new unit includes:

Xtreme Range

Superheterodyne Technology

With super-fast sweep circuitry, XRS provides extra detection range and the best possible advance warning to even the fastest radar guns

Detection And Separate Alerts For:

Radar signals (X. K and Ka bands. with signal strength indicated), laser signals, Safety Alert signals, Strobe Alert signals, VG-2 signals, Spectre 1 signals

LaserEye

For 360° detection of laser and strobe signals

Instant-On Ready

Detects radar guns with "instant-on" (very fast) speed monitoring capabilities

Tone Alerts

With adjustable volume

UltraBright Data Display

Easy-to-read with adjustable brightness

City Or Highway

Modes to reduce false alerts

Safety Alert

Traffic warning system distinguishes important safety alerts from other K band signals

Strobe Alert

Emergency vehicle warning system

Manual Mute Or Auto Mute

A mute function of audio alerts

IntelliMute

A mute function which automatically reduces false alerts by sensing engine RPMs

Mounting

Mounts easily on windshield or dashboard

This booklet describes the simple steps for mounting and setting up your detector. It also provides helpful information about how radar and laser guns are used and how you can interpret the alerts you receive.

Nothing comes close to a Cobra® A3





Order Form

Order Form

Name				
Address (No P.O. Boxes)			
City	State/Province	Zip Country		
Telephone				
Credit Card Number	Type: ☐ Visa ☐ Maste	rCard	Exp. Date	

Customer Signature

Item #	Description	U.S. Cost Each	Qty	Amount
420-030-N-001	Straight 12V Power Cord			
420-026-N-001	Coiled 12V Power Cord			
545-139-N-001	Windshield Mounting Bracket			
CLP-2B	Dual Port Power Adapter			
Amount Shipping/Handling* \$10.00 or less \$3.00 \$10.01-\$25.00 \$5.50 \$25.01-\$50.00 \$7.50 \$50.01-\$90.00 \$10.50	Tax Table Wisconsin add 5% Indiana, Michigan, Ohio add 6% California add 7.25% Illinois add 8.75%	(Tax if	S. Subtotal Applicable) g/Handling	
\$90.01-\$130.00 \$13.50 \$130.01-\$200.00 \$16.50 \$200.01 plus 10% of purchase	50 \$13.50 For AK, HI and PR add additional \$26.95 for FedEx Next Day or Total \$10.00 \$16.50 \$10.95 for FedEx 2nd Day, Excludes weekends and holidays shipments 10% of Please allow two (2) to three (3) weeks for delivery in the U.S.A.			

Ordering From U.S.A.

Call 773-889-3087 for pricing or visit www.cobra.com.

Complete and return this order form to fax number 773-622-2269. Or call 773-889-3087 [Press one (1) from the main menu] 8:00 a.m. to 6:00 p.m. CT, Monday through Friday.

Make Check or Money Order Payable To

Cobra Electronics, Attn: Accessories Dept., 6500 West Cortland Street, Chicago, IL 60707 U.S.A.

To Order Online

Please visit our website: www.cobra.com

Nothing comes close to a Cobra® 25







17	Introduction	
\checkmark	Important Information	
	Customer Assistance	
	Controls, Indicators And Connections	
	Display	
	Product Features	A3
\bigcirc	w .	
\mathbf{Q}	Your Detector	_
	Installation	
	Getting Started	
	Settings	
	Highway/City Mode	
	UltraBright Data Display Brightness	. 7
	Muting An Alert	. 8
	Auto Mute Mode	. 8
	IntelliMute	. 9
	VG-2 And Spectre 1 Alert Audio Settings	12
	Detection	
	Signals Detected	
	Audio Alerts	
	Visual Display	
	Instant-On Detection	
	Responding To Alerts	
	Understanding Radar And Laser	
	Maintenance	
	Specifications	20
凤	Warranty	
	Limited 1-Year Warranty	21
-	Limitod 1 four warranty	۱ ک
	Customer Assistance	
2	Product Service	22
	Trademark Acknowledgement	
	Optional Accessories	
	Order Form	




Installation


Installation

Where To Mount Your Unit

You will get optimum performance from your detector if you Mount it at a point approximately in the center of the vehicle, as low as possible on the front windshield without obstructing the unit's view of the road either to the front or rear. You can also mount it directly on the dashboard.



The unit's lens must not be blocked and the LaserEye should have a clear view out the back window to allow 360° detection.



Radar and laser signals pass through glass but not through other materials and objects. Objects that can block or weaken incoming signals include:

- Windshield wiper blades
- Mirrored sun screens
- Dark tinting at the top of the windshield
- Heated windshields currently available on some vehicles (Instaclear for Ford, Electriclear for GM.) Consult your dealer to see if you have this option.





Installation

Windshield Mounting

1. Attach the rubber cups to the bracket.



- 2. Make sure the rubber cups and your windshield are clean.
- 3. Push the bracket firmly onto the windshield.



4. Attach the detector to the bracket. Check the angle of the unit.



5. To adjust the angle if necessary, gently push or pull on the bracket to bend it. DO NOT use the detector to bend the bracket.



6. Plug the power cord into the detector.



7. Plug the cigarette lighter adapter on the power cord into your vehicle's cigarette lighter.



8. You can temporarily remove the detector whenever you wish by pressing the bracket release button and sliding it off the bracket.



Installation

Dashboard Mounting

- **1.** Place the detector on the dashboard to find a location where the unit has a clear, level view of the road. The angle can NOT be adjusted after mounting.
- 2. Remove the paper backing from one (1) side of the hook-and-loop fastener.
- 3. Attach the pad to the dashboard at your chosen location and remove the other paper backing.
- 4. Attach the detector to the hook-and-loop fastener. You can remove and reattach the unit as often as you like.
- **6.** Plug the power cord into the detector.
- 7. Plug the cigarette lighter adapter on the power cord into your vehicle's cigarette lighter.



Getting Started

Getting Started



To Turn On The Unit And Adjust The Audio Volume

Rotate the On-Off / Volume control	Tone	Visual Display
clockwise (away from you).	Three (3) beeps	h appears in the display indicating that the power is On .



NOTE

In some vehicles, power is supplied to the cigarette lighter even while the ignition is Off. If this is the case with your vehicle, you should turn Off or unplug your detector when parking for lengthy periods.



Settinas

Settings

When changing the **Settings** on your detector, please keep in mind:

- Buttons can have multiple functions.
- All settings will be stored in memory when the power is turned Off and recalled when the power is turned back On.

Highway/City Mode

Setting your detector to **City** mode delays all X band audio alerts until the signal strength reaches Level 3. (A single beep will sound when the signal is first detected.) This will reduce false alerts while you are driving in, or near, urban areas where there are many sources for conflicting X band signals such as microwave towers and automatic door openers.

To change settings, follow the procedure listed below, which indicates what you will see and hear as you complete each step. The factory setting is **Highway** mode.



То	Change	From	Highway	Mode	То	City	Mode

Press and release	Tone	Visual Display
the City button.	One (1) beep	c appears in the display

To Change From City Mode back To Highway Mode

Press and release	Tone	Visual Display
the City button again.	Two (2) beeps	h appears in the display





UltraBright Data Display Brightness

You can choose from three (3) settings for **Brightness** of the display. You can cycle through the settings by repeatedly pushing the **Dim** button. The factory setting is **Bright**.



To Change The Brightness To Dim

Press and release	Tone	Visual Display
the Dim button once.	One (1) beep	Display dims

To Change The Brightness To Dark		
Press and release	Tone	Visual Display
the Dim button again.	One (1) beep	Display remains dim (no visual alerts will be seen)

To Change The Brightness To Bright		
Press and release	Tone	Visual Display
the Dim button a third time.	Two (2) beeps	Display returns to full brightness



Settings

Muting An Alert

Your detector allows you to quickly turn **Off** an audio **Alert** by momentarily pressing the **Mute** button. If you press the **Mute** button a second time during the Alert, the audio Alert will be turned back On.

Auto Mute Mode

Auto Mute will automatically reduce the audio volume of all alerts after four (4) seconds for as long as the signal is detected. The factory setting for **Auto Mute** is **On**.



To Turn Auto Mute Off

Press and release	Tone	Visual Display
the Mute button while no alert	One (1) beep	None
is occurring.		

To Turn Auto Mute On

Press and release	Tone	Visual Display
the Mute button again while no alert is occurring.	Two (2) beeps	None



Settings

IntelliMute

IntelliMute is a unique new feature that allows you to avoid alerts you don't need to hear because you are stopped or moving slowly. By sensing the "revs" (RPMs) of your engine, IntelliMute knows when you are at low speed and automatically mutes alerts (except for strobe signals from emergency vehicles).

Before IntelliMute will work, you must set an activation point for your engine's revs (see page 11). Whenever the revs are below that point, IntelliMute will begin muting. The activation point will be stored in memory and recalled each time the power is turned **On**. The factory setting is **IntelliMute Off**.



NOTE

IntelliMute may not work with some vehicles because it cannot sense the engine's revs. In such cases, you can reduce unwanted audio alerts by using Auto Mute and City mode when appropriate.





To Turn IntelliMute On

Press and release	Tone	Visual Display
the IntelliMute button.		Dot appears next to the large character on the right

Tο	Turn	IntelliMute	Off

Press and release	Tone	Visual Display
the IntelliMute button again.	One (1) beep	None



Settinas

What To Remember While Using IntelliMute

IntelliMute works with both City and Auto Mute modes.

Whenever your engine revs are below the activation point, the dot next to the large character on the right side of the display will remain lit. Above the activation point, the dot will blink twice every two (2) seconds.

Below Activation Point

Above Activation Point





If, for any reason, the unit stops sensing your engine's revs, IntelliMute will indicate an error and automatically turn Off.

The rev point you set will be stored in the unit's memory when power is turned **Off** and recalled each time the power is turned **On**.



The rev point must be reset if you use your detector in a different vehicle.



NOTE

When initially choosing your IntelliMute activation point, a setting of approximately 300 to 600 RPMs above idle is recommended. You can reset the activation point at any time to fit your individual preferences and driving style.

Setting The IntelliMute Activation Point

Your detector must be installed in your vehicle.



CAUTION

Do not attempt to set the rev point while driving. Your vehicle should be parked and idling.

IntelliMute must be turned **On** before setting the activation point. You will hear a series of beeps as you follow the steps on page 11.





Settinas



To Set The IntelliMute Activation Point		
Press and hold	Tone	Visual Display
the IntelliMute button for two (2) seconds.	Two (2) beeps	None
Rev your engine to the level you wish	None	Three (3) bars will flash in succession
to set (recommend slightly above idle) and hold revs steady for two (2) seconds.		1 2 3
At the desired rev level, press	Three (3) beeps	All three (3) bars flash three (3) times
and release the IntelliMute button.		1 2 3



NOTE

If the unit is unable to sense usable pulses within three (3) seconds or if you do not set a rev point within 20 seconds of beginning these steps, IntelliMute will indicate an error and automatically turn Off.

Tone	Visual Display
Four (4) beeps	E appears
	хкка у ѕ Е



Settinas

VG-2 And Spectre 1 Alert Audio Settings

The detector is undetectable by police VG-2 and Spectre 1 radar detector detectors and will alert you when such a device is in use near your vehicle. During the alert, the unit continues to detect other signals. You can choose whether or not you want your unit to show VG-2 and Spectre 1 alerts. The factory setting is **VG-2** and **Spectre 1** alert **On**.





To Turn VG-2 And Spectre 1 Alerts Off

While no signal		
is being detected,		
press and hold		
the Dim button for		
two (2) seconds.		

Tone	Visual Display
	V will blink once in the display

To Turn VG-2 And Spectre 1 Alerts On

While no signal	Tone	Visual Display
is being detected, press and hold the Dim button for two (2) seconds again.	Two (2) beeps	V will blink twice in the display



Detection

Detection

Signals Detected

The tables on the following pages show you the types of Signals your detector will detect, as well as the visual alerts it provides for each of them.

Audio Alerts

A distinctly different **Alert** tone is used for each type of signal detected (including separate tones for each laser signal). For X, K and Ka band radar signals, the tones will repeat faster as you approach the signal source. The repeat rate of the tones gives you useful information about the signal detected. (See responding to alerts on page 16.)

Visual Display

An indication of the type of signal detected will appear in the UltraBright data **Display**. During X, K and Ka alerts, a number will also appear, indicating the strength of the signal detected. (1 = weakest, 5 = strongest)

X Signal Detected

K Signal Detected

Ka Signal Detected







During laser alerts the letter \d will appear, instead of the signal strength indication. Laser Signal Detected



During VG-2 or Spectre 1 alerts, the letter **V** will appear. It will be steady during VG-2 and blink during Spectre 1.

VG-2 Alert Signal Detected Spectre 1 Alert Signal Detected





During Safety Alert and Strobe Alert the letter **S** will appear. It will be steady during a Safety Alert and will blink during a Strobe Alert.

Safety Alert Signal Detected Strobe Alert Signal Detected





Nothing comes close to a Cobra® 13



Detection

Radar Signals And Visual Displays

Type of Signal	Visual Display
X Band Radar	X and Signal Strength
K Band Radar	K and Signal Strength
Ka Band Radar	Ka and Signal Strength

X Signal Detected

K Signal Detected

Ka Signal Detected

XKKaVS





Laser Signals And Visual Displays

Type of Signal	Visual Display
LTI 20-20*	L is Steady
LTI Ultra-Lyte*	L is Steady
Kustom Signals ProLaser*	L is Steady
Kustom Signals ProLaser III*	L is Steady

^{*} Your detector provides 360° detection of these signals.

Laser Signal Detected





Beep rate changes with different laser alerts.



Detection

Strobe Alert Signals And Visual Displays

Type of Signal	Visual Display
3M Opticom or Tomar*	S Blinks

^{*} Your detector provides 360° detection of this signal.

Strobe Alert Signal Detected



Safety Alert Signals And Visual Displays

Type of Signal	Visual Display
Emergency Vehicles	S is Steady
Road Hazards	S is Steady
Trains	S is Steady

Safety Alert Signal Detected






There are different tones for each Safety Alert.

VG-2 And Spectre 1 Alert Signals And Visual Displays

Type of Signal	Visual Display
Interceptor VG-2	V is Steady
Spectre 1	V Blinks

VG-2 Alert Signal Detected

Spectre 1 Alert Signal Detected







There are different tones for each alert.



Detection

Instant-On Detection

Your detector is designed to detect **Instant-On** speed monitoring signals, which can suddenly appear at full strength.



NOTE

You should take appropriate action immediately whenever an instant-on alert is given.

Responding To Alerts

Description	Interpretation	Recommended Response	
Tone repeats slowly at first, then speeds up rapidly.	Probably police radar	FULL ALERT	
Tone sounds one (1) time only.	Probably a false alarm, but possibly pulsed radar, VG-2, or Spectre 1 nearby	Exercise caution	
Tone instantly begins repeating rapidly.	Radar, VG-2, or Spectre 1 nearby has been activated suddenly	FULL ALERT	
Tone repeats slowly as you approach a hill or bridge, then speeds up sharply as you reach it.	Probably police radar beyond the hill or bridge	FULL ALERT	
Tone repeats slowly for a short period.	Probably a false alarm	Exercise caution	
Any type of laser alert.	Laser alerts are never false alarms	FULL ALERT	
Any Safety Alert or Strobe Alert.	You are nearing an emergency vehicle, railroad crossing, or road hazard (construction, accident, etc.)	Exercise caution	

16 English



Understanding Radar And Laser

Understanding Radar And Laser

Radar Speed Monitoring Systems

Three (3) band frequencies have been approved by the Federal Communications Commission (FCC) for use by speed monitoring radar equipment:

10.525 GHz X band K band 24.150 GHz

33.400 - 36.00 GHz Ka band

Your detector detects signals in all three (3) radar bands.

VG-2 And Spectre 1

VG-2 and **Spectre 1** are "detector detectors" that work by detecting low-level signals emitted by most radar detectors. Your detector does not emit signals that can be detected by VG-2 or Spectre 1, but does detect VG-2 and Spectre 1 signals and will alert you when a device is in use near your vehicle, if you so choose.

Safety Alert Traffic Warning System



FCC-approved Safety Alert transmitters emit microwave radar signals that indicate the presence of a safety-related concern. Depending on the frequency of the signal emitted, it can indicate a speeding emergency vehicle or train, or a stationary road hazard.

Because these microwave signals are within the K band frequency, most conventional radar detectors will detect Safety Alert signals as standard K band radar. Your detector, however, is designed to differentiate between standard K band and Safety Alert signals, and give separate alerts for each.

Safety Alert technology is relatively new. Safety Alert transmitters can be found in limited numbers in all 50 states, but the number is growing. Depending on your location, you may not receive these alerts regularly and may often encounter emergency vehicles, trains and road hazards without being alerted. As the number of transmitters increases, these alerts will become more common.

When you receive such an alert, please watch for emergency vehicles ahead of you, on cross streets and behind you. If you see an emergency vehicle approaching, please pull over to the right side of the road and allow it to pass.



Understanding Radar And Laser

Strobe Alert

Special strobes mounted on the light bars of authorized emergency vehicles (fire trucks, police cars, ambulances) automatically change traffic signals as the vehicle approaches an intersection. These strobes and the special strobe detectors located on the traffic signals, introduced fairly recently by 3M and Tomar, are already in use in more than 1000 cities nationwide. Cobra's exclusive Strobe Alert detector will detect these special strobes and give an emergency vehicle alert.

When you receive such an alert, please watch for an approaching emergency vehicle and pull over to allow it to pass. To inquire about coverage in your area, contact your local fire and police departments.

LIDAR (Laser)

The correct name for the technology that most people refer to as laser is actually **LIDAR**, which stands for Light Detection and Ranging.

LIDAR operates much like radar. Its signal spreads out like a radar signal, though not as widely. Unlike radar, LIDAR must have a clear line of sight to its target vehicle throughout the entire measurement interval. Obstructions such as sign posts, utility poles, tree branches. etc., will prevent valid speed measurement.

Some common questions about LIDAR include:

- Does weather have any affect on LIDAR? Yes. Rain, snow, smoke, fog, or airborne dust particles will reduce the effective range of LIDAR and can, if dense enough, prevent its operation.
- Can LIDAR operate through glass? Yes. Newer LIDAR guns can obtain readings through most types of glass. However, the laser pulse also can be received through glass to trigger an alarm by your detector.
- Can LIDAR operate while in motion? No. Because LIDAR operates by line of sight, the person using it cannot drive the vehicle, aim and operate the gun all at the same time.
- Is LIDAR legal to use? Yes. It is legal in all 50 states.



Maintenance

Maintenance

Maintenance Of Your Radar Detector

Your detector is designed and built to give you years of trouble-free performance without the need for service. No routine **Maintenance** is required.

If your unit does not appear to be operating properly. please follow these troubleshooting steps:

- Make sure the power cord is properly connected.
- Make sure the socket of your vehicle's cigarette lighter is clean and free of corrosion.
- Make sure the power cord's cigarette lighter adapter is firmly seated in your cigarette lighter.
- Check the power cord fuse. (Unscrew the ribbed end cap of the cigarette lighter adapter and examine the fuse. If required, replace it with a 2-amp fuse only.)



Specifications

Specifications

Band And Frequencies

Band	Frequenci	es	
X Band	10.525	± 0.050	GHz
K Band	24.125	± 0.125	GHz
Safety Alert Traffic Warning System	24.070	± 0.010	GHz
	24.110	± 0.010	GHz
	24.190	± 0.010	GHz
	24.230	± 0.010	GHz
Ka Band	34.700	± 1.300	GHz
Laser	910	± 50	nm
Strobe	700	± 300	nm

Unit Dimensions And Weight

Dimensions* (H x W x D)	Weight*	
11/3" x 23/4" x 41/3"	4.83 oz.	
(34 mm x 70 mm x 110 mm)	(137 g)	

^{*} Dimensions and weight measurements are approximate.

This radar detector is covered by one or more of the following U.S. patents: 5,497,148; 5,594,432; 5,612,685; 6,078,279; 6,094,148. Additional patents may be listed inside the product or pending.



Warrantv

Limited 1-Year Warranty

For Products Purchased In The U.S.A.

Cobra Electronics Corporation warrants that its Cobra 11 Band Radar/Laser Detectors, and the component parts thereof, will be free of defects in workmanship and materials for period of one (1) year from the date of first consumer purchase. This warranty may be enforced by the first consumer purchaser, provided that the product is utilized within the U.S.A.

Cobra will, without charge, repair or replace, at its option, defective 11 Band Radar/Laser Detectors, products or component parts upon delivery to the Cobra Factory Service Department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt.

You must pay any initial shipping charges required to ship the product for warranty service, but the return charges will be at Cobra's expense, if the product is repaired or replaced under warranty.

This warranty gives you specific rights, and you may also have other rights which vary from state to state.

Exclusions: This limited warranty does not apply:

- 1. To any product damaged by accident.
- 2. In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
- **3.** If the serial number has been altered, defaced or removed.
- **4.** If the owner of the product resides outside the U.S.A.

All implied warranties, including warranties of merchantability and fitness for a particular purpose are limited in duration to the length of this warranty.

Cobra shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.



Product Service

Product Service

If you have any questions about operation or installing your new Cobra product, or if you are missing parts...

Please call Cobra first! DO NOT RETURN THIS PRODUCT TO THE STORE! See customer assistance on page A1.

If you suspect that your unit requires service, please call 773-889-3087 BEFORE shipping it to Cobra. This will ensure that you receive service as quickly as possible.

If you are asked to send your unit to the Cobra factory, please follow these steps:

- 1. Send the complete unit, including power cord. (It is not necessary to include the mounting bracket.)
- 2. For warranty repair, enclose some form of proof-of-purchase, such as a photocopy or carbon copy of a sales receipt. If you send the original receipt, it cannot be returned.
- **3.** Enclose a typed or clearly written description of the problem you are having with your unit, plus the name and address where you want the unit returned.
- **4.** Pack the unit securely to prevent damage during transit. If possible, use the original packing materials.
- **5.** Ship prepaid and insured using a traceable carrier such as United Parcel Service (UPS), Federal Express, or Priority mail with delivery confirmation. Ship to: Cobra Factory Service, Cobra Electronics Corporation, 6500 West Cortland Street, Chicago, IL 60707 U.S.A.
- **6.** Please allow three (3) to four (4) weeks before contacting us about the status of your service. Call 773-889-3087 for assistance. If your unit is under warranty, it will either be repaired or replaced upon receipt. depending on the model. If your unit is out of warranty, you will receive a letter informing you of the repair or replacement charge.



Trademark Acknowledgement

Trademark Acknowledgement

Cobra, microTALK, DigiView, LaserEye, Safety Alert Traffic Warning System, Strobe Alert, VG-2 Alert and Nothing comes close to a Cobra are registered trademarks of Cobra Electronics Corporation.

HighGear, 11 Band, EasySet, IntelliMute, SmartPower, Spectre Alert, Voice Alert and Xtreme Range Superheterodyne are trademarks of Cobra Electronics Corporation.

Opticom is a trademark of 3M Corporation. Instaclear for Ford is a registered trademark of Ford Motor Company, Inc. Electriclear for GM is a registered trademark of General Motors Corporation. 20-20 and Ultra-Lyte are trademarks of Laser Technology, Inc. ProLaser and ProLaser III are trademarks of Kustom Signals, Inc. Bee III and Pop are a trademarks of MPH Industries. Spectre is a trademark of Stalcar. Interceptor VG-2 is a trademark of TechniSonic Industries LTD. Tomar is a registered trademark of TOMAR Electronics. Inc.



Optional Accessories

Optional Accessories

You can find quality Cobra products and accessories at your local Cobra dealer, or in the U.S.A., you can order directly from Cobra.



Straight 12V DC Power Cord Includes plug and fuse Item # 420-030-N-001



Windshield Mounting Bracket Includes suction cups Item # 545-139-N-001



Coiled 12V DC Power Cord Includes plug and fuse Item # 420-026-N-001



Dual Port Power Adapter Includes adjustable plug (up to 90°) and fuse Item # CLP-2B

