

Owner's manual Golf Edition 07.2019

Owner's manual

Golf



Owner's manual Golf Print status: 20.03.2019 English: 2019.07

Vehicle data sticker




Fig. 1 1: Vehicle identification number; 2: Vehicle type, engine power, gearbox type; 3: Engine code, gearbox code, paint number, interior equipment; 4: Optional extras, PR numbers

Pre-delivery inspection carried out on:	Date of delivery to customer/initial registration: ^{a)}
Volkswagen dealership stamp	Volkswagen dealership stamp

^{a)} Whichever comes first.

Volkswagen works continuously to develop and further improve all models. Please understand that we must therefore reserve the right to alter any part of the vehicle and its equipment or technical specifications at any time. The information provided concerning scope of delivery, appearance, performance, dimensions, weights, fuel consumption, standards and vehicle functions is all correct at the time of going to print. Some of the equipment and functions described might not yet be available in a particular vehicle (information can be provided by your local Volkswagen dealership), or may be available only in certain countries. The vehicle illustrated on the cover may have certain items of optional equipment which are only available at extra cost, or which are only available in certain markets. Your Volkswagen dealership will be able to inform you about variations in different countries. Subject to alteration and amendment. No legal commitment may be inferred from the information, illustrations or descriptions in this manual.

No part of this manual may be reprinted, reproduced or translated without the written permission of Volkswagen AG.

All rights under the laws of copyright are expressly reserved by Volkswagen AG. Subject to alteration and amendment.

Printed in Germany.

© 2019 Volkswagen AG

This paper was bleached without the use of chlorine.

Thank you for choosing Volkswagen

By purchasing this Volkswagen, you have become the owner of a vehicle fitted with the most up-to-date technology and a multitude of convenience functions for your use and enjoyment.

Before using your vehicle for the first time, please read and observe the information in this owner's manual. It will quickly help you to become familiar with your vehicle and all of its functions as well as making you aware of dangers to yourself and others and of how these dangers can be avoided.

If you have any further questions about your vehicle, or if you think that the vehicle wallet has not covered everything, please get in touch with your Volkswagen dealership. They will always be happy to deal with your questions, suggestions or problems.

We hope you enjoy driving your new vehicle. Happy motoring.

Volkswagen AG

Infotainment

Getting started

\square Introduction to the topic

The function and settings of the Infotainment system depend on the country and vehicle equipment.

Before using for the first time

Before using the device for the first time, please observe the following points so you can make full use of the available functions and settings:

- − Observe the basic safety instructions \triangle → page 190.
- Reset the Infotainment system to factory settings.
- Find your favourite radio stations and store them to station buttons for quick access \rightarrow page 202.
- − Use only suitable audio sources and data media \rightarrow page 205.
- − Pair a mobile device to make calls using the telephone interface \rightarrow page 212.
- − Use current map data for the navigation \rightarrow page 207.
- Register with Volkswagen We Connect to use the corresponding services → page 177.

Other applicable documents

In addition to this manual, please observe the following documents when using this Infotainment system and its components:

- Supplements to the vehicle wallet of your vehicle.
- The operating instructions for the mobile device or audio sources.
- The operating instructions for external data media and playback devices.
- Instructions for any Infotainment accessories subsequently installed or additionally used.
- Service description when using Volkswagen We Connect services.
- Digital operating instructions in the Infotainment system (where available)

Safety notes

🕮 Please refer to 🛕 and 🕕 on page 190.

 Some functions may contain links to websites that are operated by third parties. Volkswagen AG does not assume ownership of the third-party websites that are reached via links and is not responsible for their content.

- Some functions may contain external information supplied by third parties. Volkswagen AG is not responsible for external information being correct, up-to-date and complete, or for any infringement of third-party rights.
- The radio stations or owners of the data storage media and audio sources are responsible for the content provided.
- Multi-storey car parks, tunnels, high buildings, mountains, and other electrical devices, e.g. battery chargers, can also impair radio reception.
- Films or metal-coated stickers on the aerial and on the windows can interfere with radio reception.

WARNING

The central computer of the Infotainment system is networked with the control units installed in the vehicle. Incorrect repair or incorrect removal and installation of the central computer therefore lead to an increase risk of accident and injury.

- Never replace the central computer with a used central computer from end-of-life vehicles or from recycling.
- Have the central computer removed and installed or repaired only by a qualified workshop.
 Volkswagen recommends using a Volkswagen dealership for this purpose.

A WARNING

The factory-installed radio with integrated hardware is networked with the control units installed in the vehicle. Incorrect repair or incorrect removal and installation of the radio therefore lead to an increase risk of accident and injury.

- Never replace the radio with a used radio from end-of-life vehicles or from recycling.
- Have the radio removed and installed or repaired only by a qualified workshop. Volkswagen recommends using a Volkswagen dealership for this purpose.

WARNING

<

Accidents and injuries can occur if the driver is distracted. Reading information off the screen and operating the Infotainment system can distract you from the road and cause accidents.

• Always drive carefully and responsibly.

🛕 WARNING

Connecting, inserting or removing data media or audio sources while the vehicle is in motion can distract you from the road and lead to accidents.

🛕 WARNING

Set the volume so that noises outside the vehicle (e.g. emergency service sirens) can be easily heard at all times.

 Setting the volume too high may damage your hearing. This is the case even if you are only exposed to high volumes for short periods.

🛕 WARNING

The following conditions can lead to situations where emergency calls, telephone calls and data transmission are not possible or are interrupted:

- If your current location is in an area with no or insufficient mobile communications and GPS reception. This can also include tunnels, streets with tall buildings, garages, underpasses, mountains and valleys.
- If you are in an area with sufficient mobile communications and GPS reception but the telecommunications provider's mobile network is out of order or is not available.
- If the components in the vehicle required for emergency calls, telephone calls and data transmission are damaged, not working or do not have sufficient electrical power.
- If the rechargeable battery in the mobile device is flat or has insufficient charge level.

WARNING

In some countries and mobile networks, a call for assistance or an emergency call can be made only if a mobile device is connected to the vehicle's mobile phone interface that contains an "un-locked" SIM card with sufficient credit, and if there is sufficient network coverage.

WARNING

Read and follow the appropriate operating manuals of the respective manufacturer when using mobile devices, data media, external devices, external audio and media sources.

🛕 WARNING

Arrange the wires for external devices and audio sources so that they do not obstruct the driver.

WARNING

The volume level may suddenly change when you switch the audio or media source or connect a new source.

• Reduce the volume before switching the audio or media source or connecting a new source.

WARNING

The limit values for electromagnetic radiation in the vehicle may be exceeded, and thus the health of the driver and vehicle occupants may be endangered when operating a mobile or wireless device without a connection to an external aerial. This also applies to external aerials which have not been correctly installed.

- Maintain a minimum distance of 20 centimetres between the aerials of the mobile device and an active medical implant, since the mobile devices may impair the function of active medical implants.
- Do not carry an operational mobile device close to or directly above an active medical implant, e.g. in a breast pocket.
- Switch off mobile devices immediately if you suspect they may be interfering with an active medical implant or any other medical device.

WARNING

Mobile devices, external devices and accessories in the vehicle that are not properly secured can be flung though the vehicle interior and cause injuries in the event of a sudden driving or braking manoeuvre or in the event of an accident.

 Secure any mobile devices and accessories outside the deployment zone of the airbags or stow them safely.

WARNING

The centre armrest can obstruct the driver's arm movements. This can cause accidents and severe injuries.

 Always keep the stowage compartment in the centre armrest closed while the vehicle is in motion.

WARNING

Unfavourable light conditions and a damaged or dirty screen may result in displays and information not being read or not being read correctly from the screen.

• Displays and information on the screen must never cause you to take safety risks. The screen

is no substitute for full concentration on the part of the driver.

Radio stations can transmit catastrophe and danger warnings. The following conditions can prevent these warnings from being received or issued:

- If your current location is in an area with no or insufficient radio signal reception. This can also include tunnels, streets with tall buildings, garages, underpasses, mountains and valleys.
- If the frequency bands of the radio stations are subject to interference or are not available in areas with adequate radio signal reception.
- If the loudspeakers and the components required for radio reception in the vehicle are damaged, not working or do not have a sufficient power supply.
- When the Infotainment system is switched off.

WARNING

Switch off mobile devices in areas with a risk of explosion.

Driving recommendations and traffic symbols displayed by the navigation system may differ from the current traffic situation.

- Road signs, traffic signals, traffic regulations and local conditions have priority over the recommendations and displays provided by the navigation system.
- Adapt your speed and driving style to suit visibility, weather, road and traffic conditions.
- Certain events can make the originally planned driving time and route to the destination considerably longer or make navigation there temporarily impossible, e.g. due to a road being closed.

NOTICE

Your mobile device must always be switched off in areas where special regulations apply and when the use of mobile devices is forbidden. The radiation produced by the mobile device when switched on may interfere with sensitive technical and medical equipment, possibly resulting in malfunction or damage to the equipment.

NOTICE

The loudspeakers may be damaged if the volume is too high or the sound is distorted.

Notes on use

📖 Please refer to 🛕 and 🕕 on page 190.

- The Infotainment system needs a few seconds for a complete system start and does not respond to inputs during this time. During system startup, only the rear view camera image can be displayed.
- The Infotainment system needs to start up completely before all displays are available and before it is possible to run functions. The duration of a system start depends on the functional scope of the Infotainment system and can also take longer than usual particularly at low and high temperatures.
- When using the Infotainment system and the corresponding accessories, such as a headset or earphones, please observe the country-specific regulations and legal requirements.
- Some Infotainment functions require an active We Connect user account for the vehicle and an online connection to the Internet. The data transfer must not be restricted for the execution of the functions.
- Lightly pressing the buttons or touching the touchscreen is sufficient to operate the Infotainment system.
- To ensure that the Infotainment system works properly, it is important to make sure the system is switched on and that the correct date and time are set in the vehicle – where available.
- A missing function button on the screen does not constitute a fault in the unit; it corresponds to the country-specific equipment.
- Some functions of the Infotainment system are available only when the vehicle is stationary. In some countries, the selector lever must additionally be in parking position P or neutral position N. This is not a malfunction, but simply a legal requirement.
- There may be restrictions on the use of Bluetooth[®] devices in some countries. Information is available from the local authorities.
- Switch the ignition on before switching the Infotainment system back on if the 12-volt vehicle battery has been disconnected.
- Changes to settings may cause the display content to vary and some aspects of the Infotainment system operation to differ from the descriptions given in this manual.
- Repairs and modifications to the Infotainment system should be carried out only by a qualified

workshop. Volkswagen recommends using a Volkswagen dealership for this purpose.

- Using a mobile device in the vehicle may cause noise from the speakers.
- In some countries, the Infotainment system is automatically switched off when the engine is switched off and when the 12-volt vehicle battery charge level is low.
- In certain vehicles with Park Distance Control, the volume of the current audio source is lowered automatically when reverse gear is engaged. It is possible to lower the volume.
- Information on the included software and the licence conditions is stored under: Setup
 Copyright.
- If you sell your vehicle or loan it to somebody else, make sure that all the stored data, files and settings are deleted and that the SD card, external audio sources and data media are removed where applicable.

Start screen HOME

🕮 Please refer to 🛕 and 🕕 on page 190.

You can configure the layout of the tiles, views and displays on the start screen of the display and operating unit or have them positioned on the basis of factory layout templates.

If a tile is not present, this is not a fault but corresponds to the country-specific equipment of your vehicle.

The following main menus may be included as tiles on the start screen:

Main menus on the start screen



on the functions and operation of the Infotainment system.

Main menus on the start screen		
*	Air conditioning \rightarrow page 106	
c()»	Sound \rightarrow page 198	
\otimes	Media Control	
\land	Navigation \rightarrow page 207	
[<u>^</u>]	Users, User management $ ightarrow$ page 176	
۲	Podcasts	
5 0	Radio/Media → page 202, → page 205	
$\langle \Diamond \rangle$	Settings \rightarrow page 198	
<u>)</u> **	Auxiliary heater $ ightarrow$ page 110	
Ð	Telephone $ ightarrow$ page 212	

Technical data

<

🕮 Please refer to 🛕 and 🕕 on page 190.

Radio with integrated hardware (8.25")

The radio installed in the vehicle at the factory contains country-specific components and software for connectivity and for execution of Infotainment, convenience and vehicle functions.

The corresponding displays are shown on the screen of the radio and in some cases in the instrument cluster and head-up display.

- Capacitive colour screen:
 - 8.25-inch variant, TFT display, WVGA: 1,082 x 480 pixels.
- Device operation by touching the screen, rotary/ push knob, menu control and buttons on the multifunction steering wheel.

Central computer with display and operating unit (10")

The central computer installed in the vehicle at the factory contains country-specific components and software for connectivity and for execution of Infotainment, convenience and vehicle functions.

The corresponding displays are shown on the screen of the display and operating unit and in some cases in the instrument cluster and head-up display.

- Capacitive colour screen:
 - 10-inch variant, TFT display, HD: 1,280 x 720 pixels.

- Device operation by:
 - Sensor fields. Touch operation.
 - Buttons on the multifunction steering wheel.
 - Proximity sensor (driver/front passenger detection, gesture control).

Convenience and vehicle functions

- Settings for driver assist systems
- Settings for heating and air conditioning system.
- Settings for light and vision functions.
- Settings for convenience functions.
- Settings for parking and manoeuvring

Sound system

📖 Please refer to 🛕 and 🕕 on page 190.

Basic equipment:

The Infotainment system available from the factory is equipped as follows:

- Two to four loudspeakers, in different installation locations.
- Amplifier output power, max. 5 x 20 watts.
- Setting options:
 - Treble, Mid, Bass.
 - Volume distribution front, rear and left, right (balance, fader).

Optional sound system

The Infotainment system can be extended as follows by an optional sound system:

- Up to 9 loudspeakers, in different installation locations and with different power ratings (watt).
- External amplifier (DSP-Ethernet).
- Separate subwoofer.
- Setting options:
 - Equaliser, Treble, Mid, Bass.
 - Volume distribution front, rear and left, right (balance, fader).
 - Seat-dependent sound optimisation (sound focus).
 - Subwoofer volume.
 - Surround settings.

Connectivity

📖 Please refer to 🛕 and 🕕 on page 190.

Wi-Fi (only for 10")

- Wi-Fi in accordance with IEEE 802.11 a/b/g/n/ac.
- Transfer in 2.4 GHz and 5 GHz.
- Three Wi-Fi modes simultaneously:
 - Tethering (2.4 or 5 GHz),
 - 2.4 GHz access point,
 - 5 GHz access point.
- Wi-Fi aerial.
 - One multiband aerial each for 2.4 and 5 GHz.
 - Up to 8 Wi-Fi devices can be connected simultaneously.
 - Internet connection via Wi-Fi:
 - Tethering via customer telephone,
 - Hotspot for clients in the vehicle.
 - Apple CarPlay via Wi-Fi.
 - Audio and video streaming via Wi-Fi
 - Simplified coupling process via WPS, NFC or QR code.

Bluetooth[®] profiles

A maximum of three $\mathsf{Bluetooth}^{\circledast}$ devices can be connected at the same time.

The Infotainment system is delivered with a version 4.2 Bluetooth[®] interface.

These Bluetooth® profiles may be present:

- HFP 1.7 (Hands-Free Profile)
 - Telephony and speakerphone.
- A2DP 1.3 (Advanced Audio Distribution Profile).
 - Music playback.
- AVRCP 1.6 (Audio Video Remote Control Profile)
 - Display and operation of music playback.
 - Transmission of Cover Arts.
- PBAP 1.2 (Phone Book Access Profile)
 - Access to phone book and call lists.
- MAP 1.3 (Message Access Profile)
 - Access to SMS and e-mail.
- SSP 1.2 (Serial Port Profile).

<

Serial data transmission via Bluetooth[®].

<

Overview and controls: 10 inch

🛱 Please refer to 🛕 and 🕕 on page 190.




Fig. 129 Overview: display and control unit of the 10 inch version (10").

- 1) Time.
- (2) Status of privacy settings with number of possible notifications.
- (3) HOME button: □.
- (4) Status display for seat heating and seat ventilation.
- (5) Sensor field (Infotainment system on or off).
- 6 Touch slider for temperature.
- (7) Touch slider for volume.
- (8) Views (the current view is highlighted).
- 9 Temperature display (adjustment via 6).
- 10 Scroll bar.
- (1) Drop-down menu.
- (12) Function buttons for main menus (tiles).
- (13) Screen (touchscreen).
- (14) Gesture control is switched on.

Further information and tips on operating the Ĺ Infotainment system can be found at

 \rightarrow page 197, Operating the Infotainment system.

3 HOME button:

Opens the start page. - Touch \square .

(5) Sensor field (on or off)

Switches the Infotainment system manually on and off.

- Touch the sensor field.

(6) Touch slider for temperature

Touch slider for the driver position, touch slider for the front passenger position.

- Swipe to the left to reduce the temperature.
- Swipe to the right to increase the temperature.

(7) Touch slider for volume

- Swipe to the left to reduce the volume.
- Swipe to the right to increase the volume.

8 Views

Submenus and functions have several views with different content. Active views are marked by being highlighted in colour.

- Touch a marking to change the view.
- Swipe left or right across the screen to switch between views.

10 Scroll bar

Some menus and functions have further content above or below the current screen view.

Touch the scroll bar and pull it up or down.

11 Drop-down menu

Further function buttons for functions and notifications can be found in the drop-down menu. Displayed functions can be configured \rightarrow page 198.

 Touch a marking and pull it down to open the drop-down menu.

Overview and controls: 8.25 inch

🕮 Please refer to 🛕 and 🕛 on page 190.

12 Function buttons for main menus (tiles)

Open the main menus using the function buttons. The position of the function buttons can be configured \rightarrow page 198.

13 Screen

Operate the functions of the Infotainment system via the screen. A detailed description of the various finger movements can be found in the digital instructions.

- Touch $\square \triangleright ? \triangleright \bigcirc \triangleright$ (Operation).

 \triangleleft



Fig. 130 Overview: radio of the 8.25 inch version (8.25").

- Rotary/push knob.
- Time.

3 Status of privacy settings with number of possible notifications.

- (4) HOME button: .
- (5) Status display for seat heating and seat ventilation.
- 6 Function buttons for main menus (tiles).
- ⑦ Drop-down menu.
- 8 Screen (touchscreen)
- (9) Views (the current view is highlighted).
- (10) Scroll bar.
- Menu control.

1 Rotary/push button

- Press to switch the Infotainment system on or off.
- Turn to the left to reduce the volume.
- Turn to the right to increase the volume.

6 Function buttons for main menus

Open the main menus using the function buttons. The position of the function buttons can **not** be configured.

 Touch to open a main menu, e.g. *P* for the telephone interface.

Operating the Infotainment system

🛱 Please refer to 🛕 and 🕕 on page 190.

Carry out functions and settings via the controls of the Infotainment system.

Depending on equipment, the Infotainment system has different controls:

- Touchscreen.
- Sensor fields outside the screen, e.g. MENU
- Function buttons, e.g. (RADIO) or (PHONE).
- Rotary/push knob.
- Menu control.

Opening the Quick Guide

You can find further information and tips for operation in the Quick Guide of the Infotainment system. - Touch $(HOME) \ge (2) \ge \bigcirc$.

Switching the Infotainment system on and off

Provided that it has not been switched off manually, the Infotainment system is switched on when the ignition is switched on.

The Infotainment system starts at the last selected volume setting, provided that this does not exceed the preselected maximum switch-on volume.

8 Screen

Operate the functions of the Infotainment system via the screen. A detailed description of the various finger movements can be found in the digital instructions.

– Touch HOME ▶ ? ▶ ♥ ♥ Operation.

11 Menu control

- Turn to control the selection in lists.
- Turn to confirm a selection.

 \triangleleft

The Infotainment system switches off automatically when the vehicle key is removed from the ignition lock.

C The Infotainment system switches off automatically when you open the driver door with inactive ignition.

If you switch on the Infotainment system manual when the ignition is inactive, it will switch off automatically after around 30 minutes.

Scrolling through lists, switching tracks

Select the desired function, setting or track of the Infotainment system via the touchscreen or menu control.

Moving objects, adjusting volume

Move objects on the screen to adjust settings, e.g. of sliders, or to move areas of a menu.

Personalise menus and views depending on equipment \rightarrow page 198.

Zooming images and maps in and out

Recommendation: use thumb and index finger.

- Touch the map simultaneously with two fingers and leave your fingers on the screen.
- To zoom in views, move your fingers slowly apart.
- To zoom out views, move your fingers slowly towards each other.

Personalising the Infotainment system

📫 Please refer to 🛕 and 🕛 on page 190.

Personalise the menus and views of the Infotainment system to permit faster access to favourite or frequently used functions.

Function buttons for accessing further menus and functions are located in the HOME menu. Adapt the positions of the function buttons.

You can reach the quick access options for certain functions via the drop-down menu. Adapt the displayed functions.

Configure personal menus and the displayed functions to adapt the Infotainment system to your needs.

- For further tips and information on personalisation, touch HOME \triangleright (?) \triangleright \bigtriangledown \triangleright Custom.

Adapting the HOME menu

- 1. Touch a menu and keep your finger on the screen until the menu is visibly highlighted.
- 2. Move the menu to the desired position and then take your finger off the screen.

Configuring personal menus

You can find the personal menus in the different views via the HOME menu of the Infotainment system \rightarrow page 197. Remove or add menus via the configuration function.

- Touch a function button in a personal menu and keep your finger on the screen until an additional window opens.
- 2. Touch $\mathscr{D} \models \oplus$ to open the configuration function.
 - Touch the desired template to add a new menu. New personal menus are created without functions.
 - Touch \otimes to remove a menu.
- 3. Touch Q to close the configuration function.
- 4. Add functions to a new menu \rightarrow page 198.
- 5. Touch a free area on the screen to return to the personal menu.

• At least two personal menus are always available. These cannot be removed.

You can add a maximum of two further personal menus (maximum of four personal menus in total).

Adapting personal menus

- 1. Touch a function button in a personal menu and keep your finger on the screen until an additional window opens.
- 2. Touch the function button to which you would like to add a function.
- Touch the desired function in the additional window. Various functions are available depending on the size of the function button.
- 4. Touch a free area on the screen to return to the personal menu.

Arrow the functions are available for some function buttons than are visible at first glance in the additional window. To find all functions, swipe to the left or right in the additional window.

Adapting the drop-down menu

- 1. Touch a function and keep your finger on the screen until an additional window opens.
- Touch the desired function in the additional window and keep your finger on the screen until the function is visibly highlighted.
- Move the function to the desired position and then take your finger off the screen. The active function is automatically removed from the drop-down menu and added to the additional window.

O More functions are available for the dropdown menu than are visible at first glance in the additional window. To find all functions, swipe to the left or right in the additional window.

<

Settings (system, sound)

📖 Please refer to 🛕 and 🕕 on page 190.

The range of possible settings varies according to the country, the device and the vehicle's equipment specification.

Changing settings

The meanings of the following symbols apply to all system and sound settings.

Changes are automatically stored when a menu is closed.

Symbol, meaning



The setting is selected and activated or switched on.

Symbol, meaning	
	The setting is not selected or deactivated
	or switched off.
∇	– Open the drop-down list.
\sim	
+	Increase the setting values.
_	Decrease the setting values.
<	Gradually back.
>	Gradually forwards.
	Change setting values with the slider con- trol (infinitely variable).

Sound settings

Opening the sound settings:

10": (Home button) ► (Sound) + + .

8.25": MENU ▶ (Sound).

The following functions, information and setting options may be available in the sound settings:

- Equalizer.
- Position.
- Volume.
- Settings.

System settings

Opening the system settings:

10": Home button ► Settings).

8.25": MENU ► .

The following functions, information and setting options may be available in the system settings:

- Screen.
- Time and date.
- Language.
- Additional keyboard languages.
- Units.
- Voice control.
- Wi-Fi.
- Data connection.
- Manage mobile devices.
- Reset to default settings.
- System information.
- Copyright.
- Configuration assistant.

Adjusting the volume of external audio sources

If you need to increase the output volume of an external audio source, first lower the volume on the Infotainment system.

If the sound from the external audio source is **too quiet**, increase the **output volume** of the external audio source. If this is not sufficient, set the **input volume** to Medium or Loud.

If the sound from the connected external audio source is **too loud or distorted**, lower the **output volume** on the external audio source. If this is not sufficient, set the **input volume** to Medium or Quiet.

1

<

Cleaning the screen

🕮 Please refer to 🛕 and 🕛 on page 190.

Remove stubborn dirt carefully and without using aggressive cleaning agents.

Observe the checklist when cleaning the screen:

- ✓ Infotainment system is switched off.
- Use a soft, clean cloth that is moistened with water.

OR: use a cleaning cloth available from Volkswagen dealerships.

In the case of stubborn dirt: moisten dirt with only a little water and allow to soak in. Then carefully remove with a clean, soft cloth.

NOTICE

You can damage the screen if you clean the screen with the wrong cleaning agents or when the screen is dry.

- Use only gentle pressure.
- Do not use aggressive or solvent-based cleaning products. These cleaners may damage the Infotainment system and "dull" the screen.

Trademarks, licences, copyright

🕮 Please refer to 🛕 and 🕕 on page 190.

Trademarks and licences

Certain terms in this manual are accompanied by the symbol $^{\odot}$ or TM . They indicate brand names or a registered trademark. However, the absence of these symbols does not constitute a waiver of the rights concerning any term.

Other product names are registered trademarks or brand names of the respective legal owner.

- Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.
- Manufactured under license from Dolby Laboratories. Dolby, Pro Logic and the double-D symbol are trademarks of Dolby Laboratories.
- Android Auto[™] is a certified trademark of Google Inc.
- Apple CarPlay[™] is a certified trademark of Apple Inc.
- Bluetooth[®] is a registered trademark of Bluetooth[®] SIG, Inc.
- iPod[®], iPad[®] and iPhone[®] are trademarks of Apple Inc.
- MirrorLink[®] and the MirrorLink logo are certified trademarks of Car Connectivity Consortium LLC.
- SD[®] and SDHC[®] are trademarks or registered trademarks of SD-3C LLC in the USA and other countries.
- Windows[®] is a registered trademark of Microsoft Corporation, Redmond, USA.
- MPEG-4 HE-AAC audio coding technology and patents are licensed by Fraunhofer IIS.
- This product is subject to certain intellectual property rights and copyrights owned by the Microsoft Corporation. The use or distribution of this type of technology outside this product requires a licence from Microsoft or an authorised Microsoft company.

Some trademark symbols:



Copyright law

Audio and video files saved on data media and audio sources are normally subject to national and international copyright laws. Observe the legal requirements.

Voice control

\square Introduction to the topic

Voice control works online and offline.

Voice commands are recorded more accurately in online mode because more data are available.

Voice control understands questions and statements without the need to learn voice commands. The voice commands can be freely formulated and colloquial. You can find suggested voice commands in the Infotainment system.

The functions are reduce in offline mode.

Loud interior and exterior noises can cause malfunctions and misleading sentences and answers.

• Voice control recognises only voice commands in the language set in the Infotainment system.

O Test voice control while the vehicle is stationary before starting a journey in order to familiarise yourself with the function.

Seat-based voice control

Voice control uses additional microphones to detect whether the driver or passenger is speaking. This enables you to access seat-related functions in the supported online languages, e.g. switching on the seat heating.

Opening suggested voice commands

– Touch (HOME) ▶ ? ▶ ?».

Supported languages, market-dependent

- Online and offline: German, American English, British English, French, Italian, Spanish, Czech.
- Offline: Bulgarian, Danish, Finnish, Canadian French, Greek, Japanese, Korean, Dutch, Polish, Portuguese, Brazilians Portuguese, Russian, Swedish, Mexican Spanish, Turkish.

Prerequisites

- Online and offline: voice control with corresponding Infotainment system is installed in the vehicle.
- Online: valid We Connect Plus contract is activated.

Activation word and voice commands

🗅 Please refer to 🛕 and 🕕 on page 190.

Activation word for voice control

If you have activated the control by means of an activation word, the activated Infotainment system scans the words spoken in the vehicle for the activation word. The activation word depends on the language set in the Infotainment system. Apart from scanning for the activation word, there is no recording and no transmission of anything spoken in the vehicle.

Voice control starts when the Infotainment system recognises the activation word \rightarrow page 201.

Switching the activation word on and off

1. Touch (HOME) ► 🔅 ► Voice control ► Activation word.

o If the activation word is switched off, the voice control cannot be activated via the activation word. Voice control remains available via the Ω_{ϑ} button in the multifunction steering wheel or the VOICE function button in the Infotainment system. Availability depends on the country and vehicle equipment.

Activation word in national languages	
BG	Здравей Volkswagen
BR	Olá Volkswagen
CDN	Bonjour Volkswagen
CZ	Ahoj Volkswagen
D	Hallo Volkswagen
DK	Hej Volkswagen
E	Hola Volkswagen
F	Salut Volkswagen
FIN	Hei Volkswagen
GB	Hello Volkswagen
GR	Γεια σου Volkswagen
	Ciao Volkswagen
J	こんにちは Volkswagen
MEX	Hola Volkswagen
N	Hallo Volkswagen
NL	Hallo Volkswagen
P	Olá Volkswagen
PL	Cześć Volkswagen
ROK	안녕하세요 Volkswagen
RUS	Привет Volkswagen
S	Hej Volkswagen

Activation word in national languages	
TR	Merhaba Volkswagen
USA	Hello Volkswagen

Voice commands

To ensure that the voice control recognises voice commands reliably, follow the tips for successful voice commands.

Tips for successful voice commands

- ✓ Clear pronunciation. Unclear voice commands are not recognised.
- Speak at normal volume. Speak slightly louder at higher speeds.
- ✓ Avoid outside noises. Open windows and doors may hinder voice control.
- Avoid background noise, such as conversations in the vehicle.
- Do not point the airflow from the vents towards the microphones or vehicle roof.
- No over emphasis or strong dialects.
- ✓ No long pauses when speaking.

Depending on the content of the telephone book, it may be advisable to swap the order of the contact's forename and surname to ensure it is reliably recognised from the telephone book.

<

Starting and stopping voice control

🛱 Please refer to 🛕 and 🕕 on page 190.

Depending on the vehicle equipment, you can start voice control by different methods.

Starting the voice control function

- Voice activation: say the activation word for voice control. Pay attention to the national languages of the activation words → page 200.
- Multifunction steering wheel: press the voice control button ¬→ → page 10.
- Infotainment system: touch VOICE.

Voice control is automatically ended when you use functions on the Infotainment system, activate the parking system or when voice outputs occur, e.g. incoming calls or traffic announcements.

In some cases, the voice control function of the connected mobile device can be started by pressing and

holding the voice control button $\mathfrak{I}\mathfrak{I}$ or the VOICE button.

Ending voice control manually

- Voice control can be cancelled by means of a voice command.
- Multifunction steering wheel: press the voice control button twice in succession.

Radio mode

\square Introduction to the topic

In radio mode, you can receive available radio stations on different frequency bands and store your favourites to station buttons for quick access.

The available reception types and frequency bands depend on the equipment and country. Frequency bands may be discontinued, deactivated or no longer offered in individual countries.

Opening the RADIO menu

1. HOME ▶ ♫ ▶ 🖻.

Accessing settings

1. (HOME) ↓ □ ↓ (③) ▶ (Radio).

Online functions in radio mode

Online functions in radio mode are only available under the following conditions:

- We Connect or We Connect Plus equipment.
- You have an active We Connect user account.
- Vehicle is assigned to your user account.
- You have purchased a corresponding data package from the In-Car-shop or can use data from your own mobile device via a Wi-Fi hotspot.
- Streaming services always require an existing account with the relevant provider.
- The radio stations are responsible for the content of the information sent.

Additional electrical devices connected in the vehicle can interfere with reception of the radio signal and cause noises in the loudspeakers.

• Foil or metal-coated stickers attached to the windows may affect reception on vehicles with a window aerial.

Equipment scope and radio symbols

📖 Please refer to 🛕 and 🕕 on page 190.

Radio

<

- The available functions and the possible reception modes and frequency band depend on the vehicle equipment and country.
- AM tuner.
- FM dual tuner (diversity aerial).
- Combined station list.
 - Combination of DAB and FM stations in one list.
- Combined preset list.
 - Combination of all stations stored to station buttons in one list.
 - 36 station buttons as storage locations for favourites.
- Station logos.
- Aerial amplifier.
- DAB/DAB+.
- DAB Slideshow.
 - Stationary images are transmitted parallel to the current broadcast.
- Hybrid Radio.
- Internet Radio.

General symbols in radio mode

Select AM frequency band.



Select FM/DAB frequency band.

Select FM/DAB frequency band.

Select Internet Radio reception Internet Radio mode.

 Select previous station from the station list or station on previous station button.

> Select next station from the station list or station on next station button.

Display station buttons.



<

Station already stored to a station button in a station list.

TP Traffic news monitoring (TP) is activated.

- No TP The selected traffic news station is not available.
- AF off Automatic station tracking is switched off. RDS off Radio Data System (RDS) is switched off.

Symbols in the FM/DAB frequency band



Display frequency band for manual selection of FM frequency.

Possible only if the combined station list is switched off.

No DAB reception possible.





DAB station supports slideshow.

Slideshow is not available for the DAB station.

Symbols in the AM frequency band



Update station list manually.

Display frequency band for manual selection · of AM frequency.

Symbols in Internet Radio mode



Open full-text search.

Display recently listened to internet radio stations.

TOP Display 100 most frequently listened to inter-100 net radio stations.

Display available internet radio podcasts.

Display internet radio stations from the desired country.

Display internet radio stations that broadcast in the desired language.

Display internet radio stations who broadcast programmes from the desired genre. ⊲

Tuning, selecting and storing stations

🕮 Please refer to 🛕 and 🕕 on page 190.

Selecting a frequency band

Before selecting a station, you must first select a frequency band or reception mode. Different stations are available depending on the selected frequency band or reception mode.

The available frequency bands and reception modes depend on the vehicle equipment and country.

- 1. Touch Source to open the list of frequency bands and reception modes.
- Select frequency band or reception mode: 2.
 - AM.
 - FM/DAB
 - FM (for devices without DAB support).

- Internet Radio.
- Satellite radio.

Searching for and selecting stations

You can select radio stations in different ways. The possibilities vary depending on frequency band and reception mode.

Selecting via frequency band (AM and FM)

- 1. Display frequency band.
- 2 Touch the cursor, move on the frequency band and release at the desired frequency.
- **OR:** touch a point on the frequency band. The 3 cursor automatically jumps to the corresponding frequency.

The station at the set frequency is set.

■ Selecting from station list (AM and FM/DAB)

The station list shows the stations that can currently be received. In the AM frequency band it may be necessary to manually update the station list if you have left the corresponding region since you last opened the station list. The station list is updated automatically in the FM/DAB frequency band.

- 1 Open the station list.
- Touch the desired station.

The selected station is set. In the case of FM/DAB, the best reception mode is selected automatically according to availability of the station.

a Searching for and filtering stations (Internet Radio)

In Internet Radio mode, it is possible to filter stations according to categories or search for stations by means of a full-text search.

- 1. Open the station selection.
- Select the category according to which you wish 2 to filter the stations.
- 3. **OR:** touch Q to start the full-text search. The input field is displayed.
- Enter the name of the desired station. The list 4 of found stations is automatically updated during input.
- 5. Touch the desired station.
- The selected station is set.

(SCAN) Searching in SCAN mode (AM and FM/DAB)

In SCAN mode, the stations of the frequency band are automatically set successively and played for approx. 5 seconds in each case.

1. Touch (SCAN) at the right display edge.

The SCAN function starts and the currently set station is shown on the display. A (SCAN) function button is displayed next to this.

2. To select a station, touch (SCAN) again.

The SCAN function stops and the station is set.

\bigtriangledown Storing stations to station buttons

You can store up to 36 stations from different frequency bands and reception modes as favourites on station buttons.

- 1. Set the desired station.
- 2. Open the station buttons.
- 3. Touch \oplus .

OR: touch an already assigned station button and hold for approx. 3 seconds.

- 4. **OR:** touch and hold a station in the station list. The station buttons are displayed.
- 5. Touch station button.

The station is stored to the selected station button.

If a station was already stored on the station button, this station will be removed from the station button and replaced by the new station.

Special functions in radio mode

📖 Please refer to 🛕 and 🕕 on page 190.

TP (Traffic Programme)

The TP function monitors the reports from a set traffic news station and automatically outputs them during radio operation or media playback. Reception of a traffic news station must be possible for this.

Some stations that do not broadcast their own traffic news support the TP function through a corresponding traffic news station (EON).

In the AM frequency band or media mode, the system will always automatically tune to a traffic news station in the background if one is available.

If no traffic news station can be received, No TP will be shown on the display. The unit automatically searches for a receivable traffic news station. As soon as a new traffic news station can be received, the status in the display changes to TP again.

Traffic news stations are not available in all countries.

Switching on the TP function

Internet radio

Internet radio is a reception mode for internet radio stations and podcasts which is independent of AM,

FM and DAB. Due to transmission via the internet, reception is not regionally restricted.

Internet radio is available only when the Infotainment system has an active internet connection. Costs may be incurred for data transmission from the internet when using Internet Radio mode.

Hybrid Radio

When Hybrid Radio is switched on, the radio switches to the same station in Internet Radio mode when reception in the FM/DAB frequency band is poor.

Depending on setting, this changeover takes place automatically or must be confirmed after the corresponding query on the display.

(WEB) is displayed next to the station name as long as the station is being received in Internet Radio mode.

The radio automatically switches to the FM/DAB frequency band as soon as the station can be received again via FM/DAB.

Activating Hybrid Radio

- — In the FM/DAB frequency band, touch (∞) ►
 <u>Advanced settings</u>) and activate (✓ Additional online <u>data</u>).
- In Internet Radio mode, touch [™]) and set the audio quality for internet radio reception to ^{High} or Low.

Station logos

Station logos may be pre-installed for some frequency bands in the Infotainment system.

If (Autoselect station logos) is activated in the settings in the FM/DAB frequency band, the station logos will be automatically assigned to the stations.

In Internet Radio mode, the Infotainment system accesses station logos from an online database and automatically assigns them to the stations.

Manually assigning station logos

- In FM/DAB mode, touch
 ⇒ Radio
 ◆ Station logos).
- Select the station to which you wish to assign a station logo.
- Select station logo.
- Repeat the process for further stations if desired.
- End assignment of station logos with ().

 \triangleleft

Media mode

\square Introduction to the topic

In media mode, you can play media files from data media and streaming services on the Infotainment system.

With some equipment levels, the following data media can be used:

 USB storage device (e.g. USB stick, mobile telephone connected by USB).

Bluetooth[®] device (e.g. mobile telephone, tablet).
 With some equipment levels, the following types of media files can be played back:

- Audio files (e.g. music, audiobooks).
- Video files.

You can also use streaming services. The availability of streaming services depends on the equipment and the country.

To use streaming services, you require a separate user account for each service.

Opening the MEDIA menu

1. HOME ► J ► (Browser). Accessing settings

1. (HOME) ↓ □ ↓ ∅ ♦ (Media).

Restrictions and notes on data media

Dirty, overheated or damaged data media may be unusable. Observe the manufacturer's instructions.

Differences in the quality of data media from different manufacturers can interfere with media playback.

Incorrect configuration of a data medium can render it unreadable.

The read time of data media can be increased by the storage capacity, usage state (copying and deletion processes), file system, folder structure, and the amount of stored data.

Playlists simply specify a playback sequence. They link to the location of the media files within the folder structure. There are no media files stored in a playlist. To play a playlist, the media files must exist in the locations on the data medium referenced by the playlist.

No liability can be accepted for damaged or lost files on data media.

Equipment features and media symbols

🛱 Please refer to 🛕 and 🕛 on page 190.

Audio, media, connectivity:

- Media playback and media control via Bluetooth.
- Audio playback in the following formats:
 - AAC
 - ALAC
 - AVI
 - FLAC
 - MP3
 - MP4
 - WMA
- Video playback in the following formats:
 - MPEG-1 and MPEG-2 (.mpg, .mpeg)
 - ISO MPEG4; DivX 3, 4 and 5 Xvid (.avi)
 - ISO MPEG4 H.264 (.mp4, .m4v, .mov)
 - Windows Media Video 10 (.wmv, .asf)
- Cross-device playlists.
- Cross-source media database:
 - The data of all media sources connected to the Infotainment system are stored in a media database.
- Media streaming (online)
- Media search.

Symbols for media sources

- Select My media as the media source. Connected devices can be selected under My media.
- Select a device connected via Bluetooth[®] as
- media source. Set up available streaming services.
- Set up available streaming services. Already set up streaming services will be displayed in the list of media sources with their own logo.

General symbols in media operation

- Start playback.
- Pause playback.
- Go to previous track.
 - Go to next track.
- Repeat current track.
- Ca Repeat all tracks.

Activate shuffle mode.

Show favourites list.

 Go back to higher-level folder of the media source.

Symbols for categories and groups of media files

Music tracks.

Videos.

Playlists.

J) Albums.

Artists.

Genre.

Podcasts.

Audio books.

Symbols for video playback

Play video in full-screen mode.

....

Minimise playback.

Selecting and playing a media source

🗅 Please refer to 🛕 and 🕕 on page 190.

Selecting a media source

Before playing media files you must first connect a media source.

An internet connection must be available in order to use streaming services.

- 1. Connect an external media source (if playback from an external media source is desired).
- 2. Select the connected media source that is to be used for playback.

> Playing audio and video files

You can search for and play media files from an available media source in various ways.

$J \equiv$ Searching in the folder structure

All media files of USB devices are filtered according to categories (e.g. album, artist, track). This category view is always displayed in My media. The classic folder

structure of the individual USB data storage devices is additionally located under $\ensuremath{\mathsf{My\,media}}$.

1. Show folder structure.

The folder structure of the selected media source is displayed. If My media is selected, categories (music, videos, playlists) and connected media sources are displayed first.

- 2. Search through the folder structure for the desired track.
- 3. Or: touch \mathbb{Q} to start the full-text search. The input field is displayed.
- Enter the name of the desired track. The list of found tracks is automatically updated during input.
- 5. Touch the desired track.

If the selection is located in a folder on a media source at the start of playback, the media files located in this folder will be added for playback.

If a playlist is played, all available tracks in the playlist will be added for playback.

6. Close the selection with X.

♡ Selecting favourites

You can save individual tracks, genres, artists and albums as favourites.

1. Open favourites.

 \triangleleft

2. Touch the desired favourite.

Depending on the selection, all tracks that belong to the favourite added for playback.

Setting up streaming services

Depending on the vehicle equipment, you can use streaming services directly via the Infotainment system. For this you require an existing user account with the respective streaming service and must log in on the Infotainment system with this account. An internet connection is also required to use these services.

1. Select Streaming as the media source.

A list of available streaming services is displayed.

2. Select the desired streaming service.

An input field for input of the login data is displayed.

3. Enter the login data of the desired user account and confirm.

The streaming service is added to the list of media sources as a new function button.

♡ Saving favourites

Only media files that are stored in the internal memory (Jukebox) of the Infotainment system can be saved as favourites. You can save individual tracks, albums, artists and genres.

- 1. Start playback.
- 2. Open favourites.
- 3. Touch \oplus .

Or: touch an already assigned favourite location and hold for approx. 3 seconds.

- 4. Choose from the selection list:
 - Track.
 - Album.
 - Artist.
 - Genre.
 - Plavlist.

The selection is saved as a favourite at the selected favourite location. If the favourite location was already assigned, the previously stored favourite is overwritten.

The selection options in the selection list depend on the data attached to the media file. If no genre is specified for music files, for example, the genre cannot be saved as a favourite.

If a video file is currently being played, only this video can be saved as a favourite.

Entertainment playback via the Infotainment system

🕮 Please refer to 🛕 and 🕕 on page 190.

The Infotainment system can be used to play music and videos.

Video operation

In video mode, the Infotainment system display can play a video from a data medium, from internal memory, or from a streaming service. The video audio is relayed via the vehicle loudspeakers.

The video image is displayed only when the vehicle is stationary. When the vehicle is in motion, the Infotainment system display is switched off. The video audio can continue to be heard.

A stable Internet connection is required for playback via a streaming service. Costs may be charged by the mobile operator.

Navigation

\square Introduction to the topic

A global satellite system calculates the current vehicle position. Sensors in the vehicle analyse busy routes. All measurements and potential traffic reports are compared with the available map material to ensure optimum navigation to the destination.

Acoustic navigation announcements and visual guidance direct the driver to the destination.

The navigation is operated on the screen.

Depending on the country, some Infotainment functions can no longer be selected when the vehicle is travelling above a certain speed. This is not a malfunction, but simply a legal requirement.

WARNING

Configure the settings and enter destinations and changes for the navigation only when the vehicle is stationary.

ิธ์

รัเ

<

The navigation may recalculate the route if the driver misses a turning.

C The quality of the navigation recommendations depends on the navigation data available and any reported traffic jams.

Navigation announcements

Navigation announcements are acoustic driving instructions for the current route.

The type and frequency of navigation announcements depends on the driving situation, e.g. starting route guidance, driving on a motorway or gyratory system, and the settings.

A navigation announcement informing you that you have reached the destination area is given if the exact destination cannot be reached, e.g. because it is located in a non-digitised area. In addition, notes on the direction and distance to the destination are displayed on the screen.

During dynamic route guidance, you receive information about reported traffic jams on the route. An additional navigation announcement is given if the route is recalculated due to traffic jams \rightarrow page 211.

The volume of a navigation announcement can be adjusted during output of the announcement. All other navigation announcements are then given with this volume setting.

Navigation announcements are not given if the Infotainment system has been muted.

Restrictions during navigation

When the Infotainment system cannot receive any data from GPS satellites, e.g. in a tunnel or underground car park, navigation can still continue using the vehicle sensors.

In areas that are not or are not completely included in the Infotainment memory, the Infotainment system will also try to enable route guidance.

If navigation data are unavailable or incomplete, the navigation system may be unable to determine the exact vehicle position. As a result, the navigation may not be as exact as usual.

Road navigation is subject to continuous changes, e.g. new roads, road works, road closures, changes in the road names and house numbers. In the case of obsolete navigation data, there may be errors or inaccuracies during navigation.

Controlling the navigation map

For optimal viewing, you can also operate the navigation map with advanced finger movements.

Advanced operation is available depending on the equipment.

Moving the map

Recommendation: use your index finger.

Use your finger to move the map.

Zooming in

Recommendation: use your index finger.

Touch the map twice to zoom in on a particular position.

Zooming out

Recommendation: use your index and middle finger.

Touch the map with two fingers simultaneously.

Changing view

Recommendation: use your index finger.

- Touch the map twice and hold your finger on the screen.
- Move your finger upwards to zoom out from the map view. Move your finger downwards to zoom in on the map view.

Changing view

Recommendation: use thumbs and index finger.

- Touch the map with two fingers simultaneously and hold them down.
- Move your fingers together to zoom out from the map view. Move your fingers apart to zoom in on the map view.

Tilting the view

Recommendation: use your index and middle finger.

- Touch the map with two fingers horizontal to each other and hold them down.
- Move your fingers upwards to tilt the map view forwards. Move your fingers downwards to tilt the map view backwards.

Rotating the map

Recommendation: use thumbs and index finger.

- Touch the map with two fingers simultaneously and hold them down.
- Turn your fingers clockwise or anticlockwise to rotate the map view.

Stored data

The Infotainment system stores certain data, e.g. frequently driven routes and position information, to enable you to enter destinations quickly and to optimise route guidance.

Deleting stored data

- 1. Touch Settings ► Basic settings ► Delete Usage pattern.
- 2. Touch the required data.

⊲

Navigation equipment and symbols

 \square Please refer to **A** and **(**) on page 190 and **A** at the start of the chapter on page 207.

Navigation

The navigation functions depend on the equipment level and country.

Equipment

- Destination entry and route calculation (offline and online).
- Import of routes and destinations.
- Simultaneous display of two navigation maps (screen and instrument cluster).
- Online map update.
- Predictive navigation.
- 3D City Maps.
- Online Traffic Information, e.g. dynamic POIs or traffic reports.
- 360° range display (electric and hybrid vehicles).

Map symbols

The buttons and displays depend on the set up and the current driving situation.

The map displays symbols for traffic reports and POIs, e.g. petrol stations, railway stations or interesting stopovers, when navigation data is available \rightarrow page 211.



Further options for route guidance.

Displays the navigation map.

Opens the contact list.

Navigation setup.

Additional window with further options.

Additional window with route options.

AFI AFI Centres map on the current position.

Aligns the map to north.

Information on current route guidance.

Map scale. _

; []]

N)

Symbols in the additional window

- Touch \equiv to open the additional window.

Centres map on the current position.

Route options and information on current route guidance.

360° range display.

Repeat the previous navigation announcement.

Volume for navigation announcements. à.

Other symbols



Detailed destination entry for a particular address.

Route plan symbols



Current position.

Destination of the current route guidance.

Close the route plan.

POI symbols

POIs are displayed on the map when navigation data is available.

Touch the desired POI to start a route guidance \rightarrow page 210.

ÂΝ

Filling station.

E-charging station.

Car park.

- Tourist information.
- Train station.

Restaurant.

Traffic reports

Traffic reports displayed on the map when navigation data is available \rightarrow page 211, Traffic information.

Touch a traffic report to open an additional window with further details \rightarrow page 211, Function descriptions.



<

Navigation data

🕮 Please refer to \Lambda and (!) on page 190 and \Lambda at the start of the chapter on page 207.

The Infotainment system has an internal navigation data memory. Depending on the country, the required navigation data is already pre-installed.

In order to carry out route guidance correctly and make full use of the functions offered, the Infotainment system always requires up-to-date navigation data.

NOTICE

If you use obsolete data, navigation may be impaired. Current routes cannot be determined or route guidance leads to the wrong destination.

Always keep navigation data up-to-date.



Updating navigation data online

Navigation data for frequently travelled regions is automatically updated in the background with an existing Internet connection and valid privacy settings \rightarrow page 175, *Privacy settings*.

1. Navigation data is automatically updated while the ignition is switched on.

Automatic update of navigation data depends on the privacy settings set. No update is carried out in "incognito"- mode \rightarrow page 175.

Updating navigation data manually

Current navigation data for larger regions, e.g. Western Europe, can be downloaded from the Internet at www.volkswagen.com and stored on a suitable USB data storage device available commercially. If you switch off the Infotainment system, installation will be interrupted and will automatically continue once the unit is switched on again. Navigation via the USB memory stick is not possible.

- 1. Download navigation data to a USB data storage device
- 2. Switch on the vehicle ignition.
- Connect the USB data storage device to the Infotainment system. The navigation data is automatically updated in the background.

The version of the map data is displayed under HOME ► ۞ ► System information.

WARNING

Updating navigation data manually while driving may result in accidents and serious injuries.

• Only update navigation data when the vehicle is stationary.

Starting route guidance

 \square Please refer to \bigwedge and () on page 190 and \bigwedge at the start of the chapter on page 207.

Depending on country and vehicle equipment, different functions are available for destination input.

Further information about the symbols on the Infotainment system display is available on \rightarrow page 208.

Destination inputs are located in the main menu of the navigation system.

Opening the main menu of the navigation system

- Touch (HOME) $\blacktriangleright \bigtriangleup \models \boxtimes$.

Entering an address

Enter a known address for route guidance. The navigation system will suggest possible destinations during input.

Selecting a destination and starting navigation

1. Touch ♡ ▶ Q Search.

OR: touch 🔊 .

- 2. Enter the address of the destination and select the desired destination.
- 3. Touch Route or Start).

Quick start

- 1. Touch ♡ ▶ P Search.
- Enter the address of the destination and press and hold the desired destination for a few seconds.

• Enter the destination as accurately as possible. If you make a mistake when entering the destination, route guidance will not be possible or you may be navigated to the wrong destination.

Predictive navigation

The "Predictive navigation" function uses stored data to suggest possible destinations.

Selecting a destination and starting navigation

- 1. Touch ♡ ▶ (Predictive Navigation).
- Select the desired destination. Route guidance starts automatically.

Last destinations

The navigation system stores up to ten destinations that you have driven to last in order to make them available for route guidance. New destinations automatically overwrite the oldest destination.

Selecting a destination and starting navigation

- Touch ♡ ▶ Last destinations) and select the desired destination.
- 2. Touch Route).

Quick start

 Touch ♡► Last destinations) and press and hold the desired destination for a few seconds.

Favourite destinations

Save up to 20 destinations as favourites.

Saving a destination as a favourite

 Touch ☆ in the additional window during destination input.

Selecting a destination and starting navigation

1. Touch ♡ ▶ Favourites.

- 2. Touch the desired destination.
- 3. Touch (Route).

Quick start

Touch ♡ ▶ Favourites and press and hold the desired destination for a few seconds.

Selecting on the map

The navigation map contains active areas at many locations which are suitable for destination input. To do this, touch the desired position or location on the map. You can start route guidance if map data are available at this location.

Destination input via the navigation map depends on the data status and is not possible for all positions.

To start "offroad navigation", touch a free area without positioning data \rightarrow page 211.

Starting navigation

- 1. Touch 🔀.
- Move the map view until the desired position can be selected. The navigation map can be operated by extended touch gestures → page 207.
- 3. Touch the desired destination on the map.
- 4. Touch Route

Offroad navigation

The "offroad navigation" function calculates routes to selected destination points with unknown data. If a destination point is not on known roads or there is no positioning data available for this point, the navigation system will calculate the route up to the nearest point on the known roads and then complete the route up to the destination point by a direct connection.

Starting navigation

- 1. Touch 🔀.
- Move the map view until the desired position can be selected. The navigation map can be operated by extended touch gestures → page 207.
- 3. Touch any point on the map without positioning data.
- 4. Touch Route.

Using contact data

Start navigation using the stored address data of a contact. Stored contacts without address data cannot be used for route guidance.

Starting navigation

- 1. Touch 🛞.
- 2. Touch the desired destination.
- 3. Touch (Route).

• ΝΟΤΙCE

If the address data of a contact are out-of-date, navigation will still be performed to the stored address. Make sure that the address of the contact is up-todate.

Traffic information

 \square Please refer to \triangle and \bigcirc on page 190 and \triangle at the start of the chapter on page 207.

The Infotainment system automatically receives detailed traffic information when connected to the Internet. This information is indicated by symbols and colouring of the road network on the map.

P Receipt of traffic information depends on the privacy settings set. In the maximum privacy settings mode, no traffic information is received \rightarrow page 175.

Traffic reports

Traffic reports, e.g. traffic jams or slow-moving traffic are shown as symbols on the navigation map \rightarrow page 208, *Navigation equipment and symbols*.

When route guidance is active, traffic reports that are on the current route are displayed in the route plan. You can bypass these traffic reports \rightarrow page 211, Function descriptions.

Traffic flow display

The traffic flow is shown on the navigation map for all traffic reports by colouring of the road network.

Orange Slow-moving traffic. **Red** Traffic jam.

 \triangleleft

<

Function descriptions

 \square Please refer to \triangle and \bigcirc on page 190 and \triangle at the start of the chapter on page 207.

Route plan

The route plan contains information on all events, e.g. starting points, stopovers, traffic reports, POIs and destinations, if navigation data is available.

When you touch an event, an additional window opens with further options. The options available depend on the event and the current settings \rightarrow page 207.

Opening and closing the route plan

Touch the route plan directly to open it.

- To close it, touch >.

Editing route guidance

To edit route guidance, move the stopovers or the destination to TripView.

- 1. Hold the desired destination until it is visibly highlighted.
- 2. Move the destination into the desired position.
- 3. Remove your finger from the screen. The route will be recalculated.

Bypassing traffic reports

The route plan displays current traffic reports when navigation data is available. Bypass traffic reports by editing the route plan \rightarrow page 211, *Traffic information*.

- 1. Touch a traffic report.
- 2. Touch Bypass. The route will be recalculated.

Additional window

If you use any navigation functions, an additional window with further options may appear. The possible options depend on the function used.

Closing the additional window

- Touch a free area outside the additional window.

- OR: Touch 🗵.

Functions in the additional window:

 Display on map
 Display the selection on the map.

 Add stopover
 Add a stopover to the route guidance.

 Direct route
 Start direct route guidance.

Delete Stopover from the route guidance. Bypass Bypass traffic congestion. The route will be recalculated.

(Stop route guidance) End the current route guidance.

 \bigotimes

Add a destination to favourites.

Learning usage patterns

While travelling, the navigation saves the routes travelled and destinations arrived at in order to create suggested destinations automatically. Destinations are learned depending on the time of day and the day of the week.

The navigation system can suggest up to five routes at the same time. The suggested routes may differ from the routes used in normal route guidance.

Route guidance begins when one of the suggested routes is selected.

The route guidance follows the selected route until the vehicle deviates from it. The route is recalculated and will guide you back to the selected route via a direct alternative. Serious traffic congestion is taken into account in the route guidance and, if an alternative route is available, avoided if navigation data is available.

You can activate or deactivate the function at any time.

Activate and deactivate learning usage patterns

The setting can be found in the relevant navigation menu ② ▶ Basic function settings).

- To activate the function, activate Learn usage pattern).
- To deactivate the function, deactivate Learn usage pattern.
- To delete saved data, touch Delete usage pattern).

360° range display.

For hybrid and electric vehicles, the 360° range display shows the possible range with the current charge level of the high-voltage battery.

Activating the 360° range display

— Touch 丰 🔐

 \triangleleft

Mobile phone interface

🕮 Introduction to the topic

You can connect your mobile phone to the Infotainment system via the telephone interface and then use the Infotainment system to control the telephone functions. Sound is played back using the via the vehicle loudspeakers.

You can connect up to two mobile devices to the Infotainment system simultaneously. Only one device is active and can be used to make calls.

You can use the second connected device to receive calls via the Infotainment system and for media playback.

High speeds, poor weather and poor road conditions, loud noise levels (also outside the vehicle) and also network quality may impair telephone calls in the vehicle.

As a general rule, a device (e.g. mobile phone) must only be paired once. The Bluetooth or Wi-Fi connection with the device can be restored at any time without having to pair the device again. ⊲

Equipment and symbols of the mobile phone interface

🛱 Please refer to 🛕 and () on page 190.

Equipment features

- Hands-free function.
- Use up to two phones simultaneously.
- Phone book with a maximum of 5,000 contact entries (2,000 for 8.25-inch and 6.5-inch radio).
- Text message functions via Bluetooth[®]:
 - Read text messages.
 - Write text messages (including templates).
 - Have text messages read out loud.
 - Message history.
- Email functions via Bluetooth[®]:
 - Read emails.
 - Write emails.
- Bluetooth[®] and Wi-Fi device pairing via NFC.
- Convenience telephony.
- Connection to wireless charging function.
- Connection to microphone installed in the vehicle.

Symbols in the main menu

The appearance of the symbols may differ depending on Infotainment system.

Contacts.

Call lists for incoming and outgoing calls.

Dial phone number. Text messages (texts and email).



Settings of mobile phone interface.

Select active device.

Symbols for phone calls

The appearance of the symbols may differ depending on Infotainment system.

Start call or bring to foreground.



End or reject call.



Open contact list.



Dial phone number.

Mute hands-free system.



Hold call.

Continue call.

- Start conference. <u>୫</u>+ଥ୍}
- SOS Make emergency call. Obtain help in the event of breakdown. -



Obtain information about the Volkswagen brand and selected value-added services relating to traffic and travel.

Voicemail.

Symbols in the contact window

- Touch (A) to open the contact window.
 - Input to search for contacts.



+

111

- Edit favourites.
- Add favourites.
- Remove favourites.

Symbols for call lists

- Touch (-) to open the call lists.





Missed call. æ

- Phone number (work).
- m ഹ്പ

- Phone number (private).
- ŪŊ Mobile number (work).
 - Mobile number (private).
 - Fax (private).



Symbols for text messages

The appearance of the symbols may differ depending on Infotainment system.



Activate voice input \rightarrow page 200.

Templates for text messages. 昆



Areas where special regulations apply

📫 Please refer to 🛕 and 🕛 on page 190.

Switch off the telephone and mobile phone interface in areas with a risk of explosion. These areas are not always clearly signposted. They include, for example:

- Areas immediately around chemical pipelines and tanks.
- Lower decks of ships and ferries.
- The area around vehicles which run on liquid gas (such as propane or butane).
- Places where there are chemicals or particles such as flour, dust and metal powder in the air.
- All other places where the vehicle engine and telephone must be switched off.

WARNING

Switch off telephones in areas with a risk of explosion.

NOTICE

Your telephone must always be switched off in areas where special regulations apply and when the use of telephones is forbidden. The radiation produced by the telephone when switched on may interfere with sensitive technical and medical equipment, possibly resulting in malfunction or damage to the equipment.

Pairing, connecting and managing

🕮 Please refer to 🛕 and 🕕 on page 190.

Prerequisite for pairing:

- ✓ Bluetooth[®] is activated on the mobile device.
- ✓ Bluetooth[®] is activated in the Infotainment system.

Pair a telephony-capable mobile device with the Infotainment system to use the functions of the mobile phone interface. The mobile device must be paired with the Infotainment system before the first connection is established. A user profile is then automatically stored in the Infotainment system \rightarrow page 215.

The pairing process can take a few minutes. The available functions depend on the mobile device used and its operating system.

Pairing the mobile device

- Open the list of available Bluetooth[®] devices on the mobile device and select the device name of the Infotainment system.
- 2. Observe the messages on the mobile device and Infotainment system and confirm as necessary.

If pairing was successful, the data of the telephone will be stored in the user profile.

3. *Optional:* confirm message for data transfer on the mobile device.

WARNING

If you carry out pairing when driving, this can cause accidents or injuries.

• Carry out pairing only when the vehicle is stationary.

When some mobile devices are paired, a PIN number is shown on the display of the mobile device. Enter this number on the Infotainment system to finish pairing.

Bluetooth[®] pairing via NFC

Prerequisites for one-off pairing:

- Stowage compartment with wireless charging function (compartment with interface for mobile telephone) is installed in the vehicle.
- NFC is activated on the mobile device.
- 1. Open the Telephone settings menu and touch (Select mobile phone).
- 2. Unlock the mobile device.

⊲

3. Place the mobile device correctly on the shelf for the wireless charging function.

The mobile device is paired with the Infotainment system.

• The wireless charging function is deactivated while the Infotainment system is in the Known

mobile phones menu. Wireless charging will be activated again when you leave the menu.

Active and passive connection

At least one mobile device must be **connected** to the Infotainment system in order to use the functions of the mobile phone interface. If several mobile devices are connected to the Infotainment system, you can switch between active and passive connections. Establish an active connection to the Infotainment system in order to operate the mobile phone interface with the desired mobile device.

Difference between connection types

Active Mobile device is paired and connected. The functions of the mobile phone interface are

performed with the data of this mobile device.

Passive Mobile device is paired and connected. Only incoming calls can be accepted via the mobile phone interface. No other functions are available.

Paired mobile devices are stored in the Infotainment system even if they are not currently connected.

Connecting a mobile device

Prerequisite: the mobile device is paired with the Infotainment system.

1. Activate Bluetooth® on the mobile device.

Establishing an active connection

Prerequisite: several mobile devices are connected with the Infotainment system simultaneously.

- 1. Touch 🕙.
- 2. Touch the name of the active mobile device.
- Select the desired mobile device. Other mobile devices then automatically have a passive connection.

User profiles

An individual user profile is automatically created for every paired mobile device. Data from the mobile device are stored in the user profile, e.g. contact details or settings. A maximum of ten user profiles can be stored in the Infotainment system simultaneously.

Deleting a user profile

- 1. Open the settings in the telephone main menu.
- 2. The user profiles are located in the area Mobile devices or (Select mobile phone).
- 3. Select the user profile and touch $\overline{\mathbf{m}}$ to delete.

Basic and convenience telephony

🛱 Please refer to 🛕 and 🕕 on page 190.

Depending on equipment, you can use two mobile phone interface types:

- Basic mobile phone interface
- Comfort mobile phone interface

Basic mobile phone interface

The Basic mobile phone interface uses the HFP Bluetooth[®] profile for transmission. This allows use of telephone functions via the Infotainment system and output via the vehicle speakers.

Comfort mobile phone interface

The Comfort mobile phone interface uses the HFP Bluetooth[®] profile like the Basic mobile phone interface.

The Comfort mobile phone interface may be equipped with a wireless charging function \rightarrow page 215.

In order to use the wireless charging function, you must place a suitable mobile device correctly in the stowage compartment. The mobile device is then connected to the vehicle aerial. This improves the reception and call quality.

 \triangleleft

Wireless charging function

🕮 Please refer to 🛕 and 🕛 on page 190.




Fig. 131 Illustration: stowage area with mat for wireless charging function.

The wireless charging function is dependent on the equipment level and is not available in all countries. The stowage area for the wireless charging function is located either in the centre console or in the area between the front seats depending on vehicle.

The wireless charging function enables wireless energy transmission by electromagnetic induction over a short distance.

The maximum charging power is 5 watts.

 \triangleleft

The Qi standard enables wireless charging of suitable Qi-enabled mobile devices.

In certain vehicles, a "telephone symbol" on the mat indicates the centre position of the wireless charging function \rightarrow Fig. 131 1.

To charge a Qi-enabled mobile device, place it in the stowage compartment with the display facing up so that it is centrally positioned and has full surface contact. The charging process will start automatically. The operating instructions or the telephone manufacturer will provide information about whether the mobile device supports the Qi standard. The factory-fitted Infotainment system will provide information about the start of the charging operation and, where applicable, about any foreign objects with metallic components such as coins, keys, etc. that are detected in the stowage compartment. **Remove foreign objects immediately!**

If the mobile device has not been placed correctly or is too large, it cannot be detected or cannot be detected correctly. In certain circumstances, the system will then report that there is a foreign object in the stowage compartment. Correct positioning in the stowage compartment may rectify the fault.

Qi-enabled mobile devices that are too large in their dimensions cannot be charged using the wireless charging facility.

Always place only one Qi-enabled mobile device without protective case and with a maximum length of 140 mm on the stowage area of the wireless charging function.

Declaration of conformity

"Wireless charging function":

Hereby, Novero Dabendorf GmbH, declares that this WCH-185 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

WARNING

Do not place any objects made of metal or with metallic components on the stowage area of the wireless charging function. Metallic objects may become very hot. This may cause burn injuries to the skin and cause a fire.

NOTICE

Do not place any ID cards, credit cards etc. with magnetic strips or with a chip on the stowage area with the wireless charging function. The data saved on the magnetic strip or on the chip may become unusable.

Making phone calls and sending messages

🕮 Please refer to 🛕 and 🕕 on page 190.

Opening the mobile phone interface

- Touch (HOME) ► C.

Using the telephone

Select a phone number to start a call. Different functions are available for selection of phone numbers.

Using contact data

If there are several phone numbers for each contact, you must select these correspondingly.

- Touch (③) ▶ Q and enter the contact data you are looking for. Touch the contact in the list to start the call.
- Touch
 → Favourites and a contact in the list to start the call.
- Touch
 All and a contact in the list to start the call.

Using the call list

The mobile phone interface stores incoming and outgoing calls in the call list. Frequently used phone numbers are stored as favourites. Start calls via the call list.

- Touch ④ ▶ All and a number in the list to start the call.
- Touch ④ Missed calls and a number in the list to start the call.
- Touch ④ ► Favourites and a contact to start the call.

Entering a phone number manually

- 1. Touch I and enter the phone number.
- 2. Touch C to start the call.

9 While you are entering a phone number, contacts that match the number will be shown on the Infotainment system display.

Sending text messages

Depending on the mobile device and the Infotainment system used, you can send and receive text messages and emails via the mobile phone interface.

Switching between text messages and email

To send text messages or emails, activate the corresponding option at the top left of the screen. The active option is displayed on the screen, e.g. (Text message).

- 1. Touch ⊠.
- 2. Touch the desired option at the top left of the screen.

Sending text messages

- 1. Touch ▷ ▶ New message and enter the message on the screen.
- Touch OK and one or more contacts in the list. If necessary, you can search for a contact by means of O<u>Search</u>.

Sending emails.

- Touch OK and one or more contacts in the list. If necessary, you can search for a contact by means of Q Search.

Telephone book, favourites and speed dial buttons

🕮 Please refer to 🛕 and 🕛 on page 190.

Telephone book

When a telephone is paired with the Infotainment system for the first time, the telephone book is stored in the Infotainment system. It may be necessary to confirm transfer on the telephone.

The telephone book is updated each time a new connection is established. The still existing telephone book can be used during the update.

If conference calls are supported, the telephone book can be opened during a call.

If an image is stored for a contact, this can also be displayed in the list next to the entry.

Favourites and speed dial buttons

A favourite from the telephone book can be assigned to a speed dial button. If an image is stored in the entry, it will be displayed on the speed dial button.

Speed dial buttons must be assigned manually and are assigned to a user profile.

Assigning a speed dial button

- 1. Touch \oplus .
- Touch a contact from the telephone book. If several phone numbers are stored for a contact, touch a number from the list.

Editing a speed dial button

- 1. Press and hold the speed dial button until the telephone book is opened.
- 2. Touch a new contact from the telephone book. If several phone numbers are stored for a contact, touch a number from the list.

Calling a favourite

1. Touch the assigned speed dial button.

• Favourites are not automatically updated. If the phone number of a contact changes, the speed dial button must be assigned again.

Deleting a speed dial button

1. Touch ₽.

<

 Touch the speed dial button and confirm the query about whether you want to delete with OK.

⊲

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is con-nected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

FCC RF Radiation Exposure Statement:

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 5 centimeters between the radiator and your body. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter. French Canadian Compliance Statements

"Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device."

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil nedoit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

"This Class B digital apparatus complies with Canadian ICES-003."

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

"This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter."

Cet appareil et son antenne (s) ne doit pas être co-localisés ou fonctionnant en conjonction avec une autre antenne ou transmetteur.

"This equipment should be installed and operated with a minimum distance of 5 cm between the radiator and your body"

Cet équipement doit être installé et utilisé à une distance minimale de 5 cm entre le radiateur et votre corps.

Industry Canada Statement (For Canada)

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

NOTE : THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT.

SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

RSS-247 Requirement

[For product having the wireless function using 5 GHz frequency bands] (1) The device for operation in the band 5150 – 5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

- For device installed in vehicles point (1) is not required.

(2) For devices with detachable antenna(s), the maximum antenna gain permitted for devices in the bands 5250-5350 MHz and 5470-5725 MHz shall be such that the equipment still complies with the e.i.r.p. limit;

- For device does not included 5250-5350 MHz and 5470-5725 MHz (3) For devices with detachable antenna(s), the maximum antenna gain permitted for devices in the band 5725-5850 MHz shall be such that the equipment still complies with the e.i.r.p. limits as appropriate; and

- This device does not use a detachable antenna. (4) where applicable, antenna type(s), antenna models(s), and worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in section 6.2.2.3 shall be clearly indicated.

- For device does not included 5250-5350 MHz