



ALIGNMENT INSTRUCTIONS

WARNING

Any repairs or adjustments should be made under the supervision of a qualified radio-telephone technician.

TRANSMITTER

1. Power Supply Voltage

The power supply voltage should be set for 4.5 VDC measured at the radio during transmit. Periodically check the power supply voltage during the alignment procedure.

2. Frequency Setting

- A. Connect a frequency counter or Communications Service Monitor to the antenna connector through an RF power attenuator (5 watt minimum rating, 20 dB minimum attenuation).
- B. Depress the PTT switch.
- C. Adjust the C26 trimmer capacitor such that the output frequency is equal to the channel frequency with a maximum error of +/- 200 Hz.
- D. Release the PTT switch.

3. Output Power Alignment.

- A. Set the power supply voltage for 4.5 VDC.
- B. Connect a Communications Service Monitor or watt meter and dummy load to the antenna connector.
- C. Depress the PTT switch.
- D. To be convinced for 0.45 Watt (50 ohm load) output power with a maximum error of -0.15 Watts.
- E. Release the PTT switch.

4. Modulation Adjustment.

- A. Connect an audio generator.

The audio frequency should be set at 1 KHz at 400mVrms.

- B. Connect an FM deviation meter or Communications Service Monitor to the antenna connector through an RF power attenuator (5 watt minimum rating, 20dB minimum attenuation). Set the monitor to read peak deviation.
- B. Depress the PTT switch.
- D. Adjust RV 1 for +/- 2.5 KHz maximum deviation.

E. Release the PTT switch.

RECEIVER

NOTE: Insure that the proper channel has been selected before proceeding with the alignment procedure.

1.Power Supply Voltage.

The proper voltage for testing is 4.5 VDC.

2.Receiver Alignment

A. Connect an RF signal generator or Communications Service Monitor to the antenna connector.

C. Connect a SINAD meter and oscilloscope across the speaker terminals.

Note : Don't share speaker & antenna ground

C. Set the output level of the RF signal generator for -47dBm, the generator should be set for +/- 1.5KHz deviation of a 1KHz tone.

D. Monitor the audio output level for 0.5Vrms.

E. Adjust L1 for maximum audio output.

3.FM Radio Alignment

A. Connect an RF signal generator or Communications Service Monitor to the antenna connector.

B. Connect a SINAD meter and oscilloscope across the speaker terminals.

Note : Don't share speaker & antenna ground

C. Set the output level of the RF signal generator for -47dBm, the generator should be set for +/- 60KHz deviation of a 1KHz tone.

D. Set FM radio mode at Function operation.

E. Monitor the audio output level for 0.5Vrms.

F. Adjust L30 for maximum audio output