
# WF-4000 Quick Start Guide:

Ensure that your device is powered on.

## Connecting a device to the WF-4000:

- 1. Scan for wireless networks with your device.
- 2. Select the Winegard Connect Network listed on the label on the back of the WF-4000 shown



Once selected, the WF-4000 will ask for a Password. Enter the Default Password on the back of the WF-4000

Now that the device is connected to the WF-4000, open an internet browser and enter

#### 10.11.12.1

into the address bar.

Default password set! Please change the password on this router. This message will persist until changed.	
Winegard Connect : Login	
USERNAME admin	
PASSWORD	
CONTINUE RESET	

## Log in using

User Name : admin
 Password : admin


## **Scanning for available internet:**

Navigate to home screen.

Select "Scan for available internet."





The WF-4000 will scan for available networks and display a list sorted by signal strength.



Select the desired network and click continue.

Enter the network password if needed. Some networks will display a "Splash Page" when connecting. Once the WF-4000 connects, open a fresh browser and the network will display this page.






Once "Internet Status" shows Connected to the chosen network, (this could take up as long as two minutes) the system is ready to browse.

# 4G/LTE Set up:

To use the 4G connection click the bullet for 4G/LTE in the Internet Access section and click select. There may be a three minute delay as the WF-4000 connects. Once Internet Status shows "Connected" this set up is complete.



#### **FCC Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following methods:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and devices.
- Connect the equipment into an electrical outlet on a circuit different from that which the radio receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **FCC Caution**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Only channel 1~11 can be operated. Selection of other channels is not possible.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 25cm between the radiator and your body.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter except in accordance with FCC multi-transmitter product procedures.