



**Tait Orca 5000 Handportable Radios
Service Manual**

**Issue 03
April 2001**

IPN: 449-51000-03

Contents

Part A: Introduction

Servicing Tait Orca 5000 handportables	A-3
WWW technical support	A-3
What does this manual contain?	A-3
What is included in the calibration service kit?	A-3
Programming kit	A-4
Conventions	A-4
The Tait Orca 5000 series of handportables	A-5
Product codes	A-5
The Tait Orca Product Naming Convention	A-5
Operating Instructions	A-6
Accessories	A-6
Important information	A-11
Basic servicing precautions	A-11
Programming	A-11
Calibrating	A-11
Test facilities	A-11

Part B: Radio specifications and circuit descriptions

Radio specifications	B-3
General specifications	B-3
Receiver performance	B-3
Transmitter performance	B-4
Tait Orca 5000 66-88MHz. Conventional and Trunked Radio Specifications	B-5
Tait Orca 5000 136-174MHz. Conventional and Trunked Radio Specifications	B-6
Tait Orca 5000 174-225MHz. Conventional and Trunked Radio Specifications	B-7
Tait Orca 5000 336-400MHz. Conventional and Trunked Radio Specifications	B-8
Tait Orca 5000 400-470MHz. Conventional and Trunked Radio Specifications	B-9
Tait Orca 5000 450-530MHz. Conventional and Trunked Radio Specifications	B-10
Tait Orca 5000 806-870MHz. Conventional and Trunked Radio Specifications	B-11
Tait Orca 5000 896-941MHz. Conventional and Trunked Radio Specifications	B-12
Circuit descriptions	B-14
Transmitter	B-14
Transmit (Tx) audio	B-14

Receiver	B-14
Receive (Rx) audio	B-15
Synthesiser and VCO	B-15
Power supplies	B-15
Accessory connector interface	B-16
Implications of universal band versus wideband IF filtering	B-16

Part C: Diagnostics and fault finding

Test facilities	C-3
Error codes	C-3
Test commands.....	C-5
Calculating the parameters required for test command 101.....	C-7
Fault finding charts	C-8
Fault finding – Radio cannot be switched on	C-9
Fault finding – Cannot change channel	C-10
Fault finding – No serial communication	C-11
Fault finding – Receive faults	C-12
Fault finding – Cannot transmit	C-13
Fault finding – No transmit audio	C-14

Part D: Servicing the radio

Servicing the radio	D-3
Screw head types	D-3
Disassembling the radio	D-4
Removing the front panel from the chassis	D-4
Removing the shield sub-assembly from the chassis	D-5
Removing the PCB from the chassis	D-6
Removing the rear panel	D-7
Replacing key mechanical and ancillary devices	D-8
Replacing the lens (Orca 5020, Orca 5035 and Orca 5040)	D-8
Replacing the PTT keypad	D-8
Replacing the speaker	D-9
Replacing the LCD display (Orca 5020, Orca 5035 and Orca 5040)	D-9
Replacing the shield, user interface PCB assembly and polyester dome (Orca 5020, Orca 5035 and Orca 5040)	D-12
Replacing the antenna connector, channel selector switch and volume control switch	D-12
Replacing the microphone	D-12

Replacing the battery and speaker contacts	D-12
Replacing the tact switch	D-12
Reassembling the radio	D-13
Rear panel reassembly and replacing the auxiliary flexible PCB	D-13
Fitting the PCB to the chassis and replacing the RF out assembly	D-14
Fitting the shield to the chassis	D-14
Fitting the front panel to the chassis	D-15
Spares kits	D-16
Orca 5010/5030 spares kit (TOPA-SP-401)	D-17
Orca 5035 spares kit (TOPA-SP-402)	D-18
Orca 5020/5040 spares kit (TOPA-SP-403)	D-19
Orca 5010/5030 Re-skinning kit (TOPA-SP-404)	D-20
Orca 5035 Re-skinning kit (TOPA-SP-405)	D-20
Orca 5020/5040 Re-skinning kit (TOPA-SP-406)	D-20
Orca 5020/5035/5040 User Interface PCB and Shield (TOPA-SP-407)	D-20

Part E: Battery packs and chargers

Battery packs	E-3
Battery shift life	E-3
Disposing of used nickel-cadmium batteries	E-4
Battery chargers	E-5
Desktop fast charger	E-6
Fast charger operation	E-6
Using the fast charger	E-9
Repairing the fast charger	E-11
Desktop trickle charger	E-13
Trickle charger operation	E-13
Using the trickle charger	E-14
Repairing the trickle charger	E-14
Troubleshooting	E-15
Basic Maintenance	E-16
General Care	E-16
Troubleshooting	E-16
Multi-charger	E-17
Multi-charger operation	E-17
Repairing the multi-charger	E-17

Fuse replacement	E-18
------------------------	------

Part F: Accessories

Tait Orca 5000 Accessory Connector	F-3
Connecting an Accessory	F-3
Connecting a Headset	F-5
Accessory Connector Signal Descriptions	F-6
7.5 mm Accessory Adaptor	F-8
Tait Orca Vehicle Kit	F-10
Product Codes	F-10
Installing a Vehicle Kit	F-10
Vehicle Kit Operation	F-10
Vehicle Kit Specifications	F-12
Servicing the Vehicle Kit	F-13
Spares Kits	F-14
Vehicle kit spares kit (TOPA-SP-301).....	F-15
Vehicle kit reskinning kit (TOPA-SP-302).....	F-16
Custom Modifications	F-17
Vehicle Kit Circuit Descriptions	F-19

Part G: Additional information

Glossary	G-3
Tait Electronics Limited	
Software Licence Agreement	G-7