

# **Model: RH787TB, RH787TBG**

## **INSTRUCTIONS FOR OPERATION**

### **SETTING THE OPERATING CONTROLS**

**1. This unit operates on a 12 volts battery (not included).**

To prevent possible damage if the battery should leak , be sure to remove the battery when the unit is not use .

**2. Store the controller away from excess heat or humidity .**

**3. This remote control unit is required with 16 code combinations. To prevent possible interference from or to other remote units such as garage door openers, car alarm or security system . If you find that your fan and light kit go on and off without using your control , simply change the combination code in your transmitter and receiver .**

**4. Operation buttons on the panel of transmitter .**

**VI key – For fan Maximum speed .**

**V key – For fan high speed .**

**IV key – For fan Medium speed .**

**III key – For fan Low speed .**

**II key – For fan Lower speed .**

**I key – For fan Minimum speed .**

**OFF key – For fan speed off .**

**UPPER LIGHT key – For UP light brightness and ON/OFF control .**

**REV key – For fan speed Reverse .**

**BOTTOM LIGHT CONTROL key – For DONW light brightness and ON/OFF control .**

**SET key – For learn**

**5. Start the fan :**

Press the selected speed button to run the fan at the desired .

**6. Turn off the fan :**

Press the OFF button .

**7. Light control :**

Turn the light on or off by only touching the LIGHT CONTROL button .

Keep pressing the button in excess of 0.7 second it becomes a dimmer , the light varies cyclically in 0.8 second .

One of the important feature of this control is AUTO-RESUME . After power on , it allows the light return to where it was off .

## **GENERAL INFORMATION :**

**This REMOTE controller is designed to separately control your ceiling fan speed and light brightness . The Light ON/OFF button will control the light brightness ON/OFF . The LED indicator on the transmitter will light when the button is pressed .**

## **INSTRUCTIONS FOR INSTALLATION AND OPERATION OF FAN SPEED CONTROLLER**

### **1. Setting the code on your new transmitter .**

**Within 60 seconds of turning the AC power on, press and hold the OFF/STOP button for 5 seconds. The receiver will then lock in the chosen frequency. If your fan has a light it will blink twice for fans without lights check operation using the transmitter**

## **FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT**

**This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/ TV technician for help.**

## **CAUTION:**

**Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.**

**This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

**Canada,IndustryCanada(IC)Notices**

**This device complies with Canada licence-exempt RSS standard(s).**

**Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.**

**Canada,avisd'IndustryCanada(IC)**

**Cet appareil est conforme avec Industrie Canada exemptes de licence RSS standard(s).**

**Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.**