

## CHAPTER 1 – INTRODUCTION

<b>Before You Begin</b>	1-1
<b>Model 195Es Overview</b>	1-1
<b>Model 195Es Configuration Modes</b>	1-1
Access Point Modes	1-2
Access Point Repeater	1-3
Self-Healing Mesh Network	1-3
Station Modes	1-3
Serial Applications	1-4

## CHAPTER 2 – CONFIGURATION DIAGRAMS

<b>Model 195Es Access Point Configurations</b>	2-1
Figure 1: Single Access Point Bridge Diagram	2-1
Figure 2: Multiple Access Point Bridge Diagram	2-1
Figure 3: Access Point Router Diagram	2-2
Figure 4: Access Point Masquerade Diagram	2-2
<b>Model 195Es Access Point Repeater with Clients Configurations</b>	2-3
Figure 5: Access Point Bridge Repeater with Clients Diagram	2-3
Figure 6: Access Point Router Repeater with Clients Diagram	2-3
Figure 7: Access Point Masquerade Repeater with Clients Diag.	2-4
<b>Model 195Es Building to Building Configurations</b>	2-4
Figure 8: Building to Building Configuration Diagram	2-4
Figure 9: Building to Building with Repeater Diagram	2-5
Figure 10: Building to Building Router Diagram	2-5
<b>Model 195Es Complete Wireless Solutions</b>	2-6
Figure 11: Complete Bridge Network Solutions Diagram	2-6
Figure 12: Complete Router Network Solutions Diagram	2-7
<b>Model 195Es Serial Network Configurations</b>	2-8
Figure 13: Point to Point Serial Diagram	2-8
Figure 14: Point to Point with Repeater Serial Diagram	2-8
Figure 15: Multi-point Serial Diagram	2-9
Figure 16: Ethernet and Serial Diagram	2-9

## CHAPTER 3 – STARTING OUT

<b>Overview</b>	3-1
Quick Start Guide	3-1
<b>Model 195Es Hardware Layout</b>	3-1
Required Hardware	3-1
Front Panel Overlay Diagram	3-2
Antenna Port Overview	3-2
Antenna Configuration	3-3
Hardware Configuration Diagram	3-3

<b>ESTeem Discovery Utility</b>	3-5
Installation	3-5
Operation	3-6
Configuring the IP Address	3-6
<b>Using The RS-232 Interface</b>	3-7
Installing ESTeem Utility Program	3-7
Programming Using the RS-232 Port	3-7
<b>CHAPTER 4 – WEB CONFIGURATION</b>	
<b>Logging Into Web Configuration Manager</b>	4-1
<b>Web Configuration Manager</b>	4-2
Top Menu	4-2
Setting ModemID Field	4-2
Status Menu	4-3
System Log Screen	4-5
Setup Screen	4-5
Advanced Configuration Screen	4-6
Backup Screen	4-6
Restore Screen	4-7
Software Update	4-8
System Reboot	4-8
<b>CHAPTER 5 – EXAMPLE CONFIGURATIONS</b>	
<b>Programming Example</b>	5-1
Programming Example #1 Diagram	5-1
Programming Example #2 Diagram	5-2
Table 1: Example System Configuration Table	5-2
<b>Example 1 – Plant Network (Access Point Router Repeater)</b>	5-3
<b>Example 2 –Repeater (Access Point Bridge Repeater)</b>	5-13
<b>Example 3 – Remote Building (Access Point Bridge Repeater)</b>	5-18
<b>Example 4 – EtherStation Mode</b>	5-19
<b>Example 5 – Station Router Mode</b>	5-21
<b>Example 6 – Station Masquerade Mode</b>	5-25
<b>CHAPTER 6 – SERIAL APPLICATIONS</b>	
<b>Serial Overview</b>	6-1
<b>Serial Connections</b>	6-1
Second Ethernet Port	6-1
<b>Serial Configuration</b>	6-1

## CHAPTER 7 – REPEATING FEATURES

<b>Overview</b>	7-1
<b>ESTeem Mesh Network</b>	7-1
Configuration	7-1
<b>Spanning Tree Protocol (STP)</b>	7-2
Overview	7-2
Phases	7-3
Priority and Path Cost	7-4
Root Bridge	7-4
<b>Redundant Backup</b>	7-5

## CHAPTER 8 – ANTENNA SETUPS

<b>Antenna and Cable Configurations</b>	8-1
<b>Antenna Diversity</b>	8-2
<b>Antenna Port Selection</b>	8-2
<b>Coaxial Cable Attenuation</b>	8-3
<b>Assembling the AA195PM Outdoor Pole Mounting Kit</b>	8-4
<b>Model 195Es Series with Direct Mount Dual Diversity Antennas</b>	8-9
<b>Model 195Es Direct Mount Antennas with Surge Protection</b>	8-10
<b>Model 195Es Series with External Mount Antenna</b>	8-11
<b>Model 195Es External Mount Antenna with Surge Protection</b>	8-12
<b>Fresnel Zone</b>	8-13

## APPENDIX A – FCC INFORMATION

## APPENDIX B – SPECIFICATIONS

195Eg Specifications	B-1
Case Diagram	B-2
Antenna Specifications	B-3

## APPENDIX C – INTERFACE PORTS

Ethernet Interface	C-1
Setting DHCP Server	C-1
RS-232 Programming Port Pin-Out	C-2
RS-232 Data Port Pin-Out	C-2

## APPENDIX E – SECURITY

## APPENDIX F – TROUBLESHOOTING

Testing Communication Link	-----	F-1
Viewing RF Data Rates	-----	F-2
Signal Strength vs Data Rates	-----	F-4
EtherStation Status Program	-----	F-4