

# WLS909NB

## Wireless Key




### OPERATING INSTRUCTIONS

The WLS909NB wireless key allows you to arm and disarm your alarm system, as well as perform other keypad functions, from a unit small enough to keep in your pocket. Together with your installer, you can decide which functions you wish to have accessible from your portable key.

To activate any one of the four selected functions, press and hold the appropriate button for two seconds. Your installer will indicate each function by applying a circular label beside each of the four buttons.

**! Signals will not be received if the key is not within the range of the wireless receiver.**



WLS909NB

Some of the most commonly used functions are as follows:

 **Stay Arming**

Press this button to arm your system in the Stay mode. All perimeter zones will be armed, such as all window and door contacts, but the interior zones will remain inactive, allowing you to stay on the premises without setting off an alarm.

 **Away Arming\***

Press this button to arm your system in the Away mode. Both the interior and exterior zones will be armed, allowing you to exit the premises.

 **Disarm\***

Press this button to disarm your system. You do not have to enter your access code when you use the key to disarm the system.

 **Fire**

Press this button to notify your central monitoring station of a fire condition.

 **Auxiliary**

Press this button to notify your central monitoring station of a non-medical emergency. Please discuss the functionality of this button with your installer.

 **Panic**


Press this button to notify your central monitoring station of a situation requiring the police, such as a break-in.

Other options are available. Please discuss all WLS909NB options with your installer in order to program the best possible combination to suit your needs.

**\*NOTE: In the UK some restrictions may apply. Please contact your installer for details.**

---

## Replacing WLS909NB Key Batteries



To replace the batteries, remove the screw on the back of the key and carefully separate the two sides of the key's plastic casing. Remove the old batteries from between the two metal clips. Insert the new batteries according to the diagram at right and reattach the two sides of the key's plastic casing. The WLS909NB requires three batteries of type LR44.

**NOTE: The polarity of the batteries must be observed.**

### LIMITED WARRANTY

Digital Security Controls Ltd. warrants that for a period of twelve months from the date of purchase, the product shall be free of defect in materials and workmanship under normal use and that in fulfillment of any breach of such warranty, Digital Security Controls Ltd. shall, at its option, repair or replace the defective equipment upon return of the equipment to its repair depot. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of Digital Security Controls Ltd. such as lightning, excessive voltage, mechanical shock, water damage, or damage arising out of abuse, alteration or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or liabilities on the part of Digital Security Controls Ltd. This warranty contains the entire warranty. Digital Security Controls Ltd. neither assumes, nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, nor to assume for it any other warranty or liability concerning this product.

In no event shall Digital Security Controls Ltd. be liable for any direct, indirect or consequential damages, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

**WARNING: Digital Security Controls Ltd. recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.**