

CIRCUIT EXPLANATION

BASE MAIN □ □ □ □ □ □

The signal which inputed in TEL-LINE is DC coupled at TR and transformed Analog into Digital at U100.

DATA which is transformed into Digital signal is mixed with PN code at U100 (by spread spectrum) and transmitted to RF part.

Spreading signal which inputed to RF part is mixed with Carrier supplied to VCO at U1 and create TX frequency of using channel and then is transmitted to ANTENNA through U3 by TX control of D1,D2.

The signal received to antenna is transmitted to U1 by RX/TX control time.

The signal inputed at U1 is mixed Carrier of VCO and got to direct conversion and create Base band signal.

And then, create I and Q signal by demodulation (QPSK : Quadrature Phase Shift Keying method is phase- shifted by 90°)

I and Q signal (Two signal phase is 90°) is transmitted to U100 and remixed with PN code and generated Digital signal. Digital signal is transformed into Analog at U100.

This audio signal is passed through U100 and transmitted to TEL-LINE.

ID setting : when handset is placed on baseunit , charge data is transmitted to handset by CT2 of baseunit.

The handset is received ID and transmitted ACK signal to RF PART.

Y100 is X-tal generating RF - reference signal and should be adjusted by C2 accurately.

Q101,Q102,Q103,Q104 is charge circuitry.

They are used to prevent OVER CURRENT and to CHARGE DETECTOR(Q104).

HAND MAIN □ □ □ □ □ □

The signal which is inputted to MIC is transformed Analog into Digital at U100.

DATA which is transformed into Digital signal is mixed with PN code at u100
(by spread spectrum) and transmitted to RF part.

Spreading signal which inputted to RF part is mixed with Carrier supplied to VCO
at U1 and create TX

frequency of using channel and then is transmitted to ANTENNA through U3 by TX control of D1,D2

The signal received to antenna is transmitted to U100 by RX/TX control time.

The signal inputted at U1 is mixed Carrier of VCO and got to direct conversion and
create Base band signal.

And then, create I and Q signal by demodulation (QPSK : Quadrature Phase Shift
Keying method is phase- shifted by 90°)

I and Q signal (Two signal phase is 90°) is transmitted to U100 and remixed with PN
code and generated Digital signal.

Digital signal is transformed into Analog at U100.

This audio signal is passed through RECEIVER and transmitted.

When the handset is low voltage

R105,R106,C110 make 77pin of U100 change HIGH to LOW and indicate low voltage.

Y101 is X-tal generating RF - reference signal and should be adjusted by C23 accurately.

U102 is parts for stabilization to voltage of CODEC part.