

# **Wireless Mouse**

## **User's Manual**

**AKM10**



## **Federal Communications Commission Statement**

### **Notice 1**

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

### **Notice 2**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

## **Introduction**

This manual is designed to assist you in installing and using the Wireless Keypad. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice.

## **System Requirements**

- Microsoft® Windows® 2000/XP/Vista
- One USB v. 1.1 or 2.0 Compliant Port

## **Installation**

### **Connection with Windows 2000/XP/Vista**

1. Plug the USB receiver connector to your PC.
2. The Found New Hardware Wizard appears and the OS will install the driver automatically. No other steps are necessary.

**You are now ready to begin using your wireless keypad**

**ID setting**

When plug in USB host or PC power on, the keypad and the mouse will start to work. It's already paired.

**Device not works:**

Plug the receiver into your notebook's USB port, then pressing the ID button on the back of the keypad and mouse.

**Power Switch:**

There is a power switch at back of the keypad and mouse. If you don't use the keypad and mouse, you can switch it to OFF to save the battery.

**Keypad feature description:**

Normally, when users input numbers from a USB keypad, the notebook's Num Lock function will be enabled as well. Users have to disable Num Lock function before inputting characters from a notebook. The enable and disable process will always showing every time when users input numbers from a keypad and it is cumbersome for all the users. If users want to solve this problem, they need to install driver. But our new keypad has no synchronized problem; users can use the keypad and inputting characters from a notebook at the same time. Especially, it doesn't need any drivers and support Plug & Play. Users just need to plug it into the USB port, and then users can use it smoothly.


**Keys description:**

<b>Key location</b>	<b>Usage</b>
1 End	Num Lock ON: Keypad 1 Num Lock OFF: End
2 ↓	Num Lock ON: Keypad 2 Num Lock OFF: ↓
3 PgDn	Num Lock ON: Keypad 3 Num Lock OFF: PgDn
4 ←	Num Lock ON: Keypad 4 Num Lock OFF:←
5	Num Lock ON: Keypad 5 Num Lock OFF: No function
6 →	Num Lock ON: Keypad 6 Num Lock OFF: →
7 Home	Num Lock ON: Keypad 7 Num Lock OFF: Home
8 ↑	Num Lock ON: Keypad 8 Num Lock OFF: ↑
9 PgUp	Num Lock ON: Keypad 9 Num Lock OFF: Pg Up
0 Ins	Num Lock ON: Keypad 0 Num Lock OFF: Ins
00	Num Lock ON: Keypad 0*2 Num Lock OFF: ,







. Del	Num Lock ON: Keypad . Num Lock OFF: Del
/	Num Lock ON & OFF: Keypad /
*	Num Lock ON & OFF: Keypad *
-	Num Lock ON & OFF: Keypad -
+	Num Lock ON: Keypad + Num Lock OFF: =
Enter	Keyboard Return
Bk Sp ←	Keyboard Back Space
Num Lock	Keypad Num Lock








### Hotkey Function

Use the mode key to switch mode

Internet Mode		Function Description
Function Name		
	Back	Goes back to a previous item that was already viewed in programs that support the "Back" command, such as a Web browser



	Favorite	Opens the Internet Explorer Favorites pane
	Forward	Goes to the next item—if it was previously viewed in the same session, in programs that support the “Forward” command, such as a Web browser.
	www	Starts the default Web browser and goes to the home page.
	Email	Starts the default e-mail program.
	Refresh	Updates the information on an active Web page or the contents of certain windows.
	Stop	Stops loading or refreshing a Web page or the contents of certain windows.

<b>Media Mode</b>		
<b>Function Name</b>		<b>Function Description</b>
	Pre-track	Switches to the previous media track. Press once for each preceding media track.
	Play/Pause	Once Pause is pressed, pressing this button again resumes play.
	Next track	Switches to the next media track. Press once for each subsequent media track.
	V+	Increases the computer's sound volume.
	V-	Decreases the computer's sound volume.
	Stop	Stops playing the media.
	Mute	Mutes the computer's sound volume. Press it again to turn the system volume back on.

## Specification of AKM10

### Keypad:

Operation Force	55±15gm
Total Travel	2.2 mm
Operation Frequency	2.4 GHz/ 10M distance
Battery type	1 *AA Alkaline battery
Dimension: L×W×H	155 x 92 x 26.3 mm
Receiver Connector	USB
Switch Life	3 million cycles
Keycaps type	Low profile

### Mouse:

Weight	80 gm
Operation Frequency	2.4 GHz/10M distance
Battery type	2 * AAA Alkaline battery
Dimension: L×W×H	98×60×33.5mm
Receiver Connector	USB
Resolution	800 dpi
Agency Approvals	FCC, CE

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the installation. , May cause harmful interference to radio communication. However, there is no guarantee that interference Will not occur in a particular installation. if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

-Consult the dealer or an experienced radio / TV technician for help You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment. This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation

FCC RF radiation exposure statement:

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.