# **Remote Controller (RC-16)**

The Remote Controller is used to arm the system in home or away mode, disarm the system and send a panic signal.

## Identifying the parts

#### 1. A BUTTON

Press this button to arm the system in away mode.

## 2. BUTTON

Press this button to disarm the system. When alarm is activated, press the button to stop alarm

# 3. 1 BUTTON

Pressing this button will arm the system in home mode.

## 4. BUTTON

Press and hold this button for 3 seconds to send a panic signal regardless of system mode



Panic alarm cannot be stopped after activation by pressing disarm button on Remote Controller.

### 5. LED INDICATOR (Red & Green)

Red Flash: Transmitting signal

Green Flash: Receive acknowledgement and mode change success confirmation from panel

Red Quick Flash 8 Times: Receive acknowledgement and mode change fault from panel

Red ON for 5 seconds: Receive acknowledgement but no mode change confirmation/fault from panel

Red Flash 6 times: Failed to receive any acknowledgement from panel

### **6. BATTERY COMPARTMENT**


The Remote Controller uses one **CR2032** 3V mAh Lithium battery as its power source. The low battery status will be sent to the Control Panel along with regular signal transmission, and, the Control Panel will display the status accordingly.

<NOTE>

- When changing battery, after removing the old battery, press any button twice to fully discharge before inserting new battery.
- When a low voltage battery is inserted, the LED will flash 3 times to indicate low battery.

#### Getting Started

- Remove the battery cover.
- Insert the battery with the unmarked side (negative) of the battery facing down.
- Secure the cover.
- Put the Control Panel into learning mode, refer to Control Panel manual for detail.
- Press any buttons on the Remote Controller.
- If the Control Panel receives the Remote Controller signal successfully, it will display the information accordingly.
- Please refer to your Control Panel manual to complete the learning process.



#### **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution**: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

### FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 0.5 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 0.5 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.