


Get to know your device

GizmoWatch™

Para la versión en español, visite
verizonwireless.com/support.

verizon✓

About your watch




Setting up your watch

Charging your watch

Before you start, charge your watch completely.

1. Line up the gold pins on the charging cord with the gold contacts on the back of the watch.
2. Connect the watch and cord by inserting the post on the cord through the first hole on the wristband to secure it.



3. Plug the other end of the cord into the charging adapter and plug the adapter into an electrical outlet.


WARNING: Use only approved chargers with your device. Incompatible chargers or tampering with the charging contacts could damage your device and void the warranty.


Preparing your phone

Download the GizmoHub app from the Google Play Store or the Apple App Store.


The GizmoHub app lets you set up, call, message, find and control your child's GizmoWatch.

Turning your watch on and off

To turn your watch on, press and hold the **Power**  button until the screen lights up.

To turn it off, press and hold the **Power**  button until you see “Do you want to turn me off?” on the screen.

Then tap  to turn off your watch.



Setting up your watch

Follow the instructions in the app and on your GizmoWatch to complete setup.

Wearing your watch

1. Wrap the wristband around your child's wrist making sure that the ◀ and ○ buttons are at the bottom of the screen.
2. Slide the wristband through the buckle and adjust for comfort.
3. Insert the pin on the underside of the buckle into one of the holes on the wristband (A). Then insert the other post on the buckle through a different hole (B).



4. Insert the post at the end of the wristband into a hole to secure the band in place (C).



NOTE: The watch should fit snugly, but not too tightly, around your child's wrist.



Using your watch

Adjusting the volume


Swipe to the left from the watch screen until you see the Settings screen.


Tap  to go to the Volume screen. Then drag the  icon to adjust the volume level.




NOTE: To turn off the sound temporarily, tap . To turn it back on, tap .

Making a call

1. From the watch screen, swipe left to open the Contact List. Then select the contact you want to call.
2. Tap  to make a call.





To end the call, tap .


NOTE: Your GizmoWatch can only make and receive calls from phone numbers on your child's Contact List. These numbers may be for mobile phones, landlines, and other Gizmo devices. You can manage the Contact List in the GizmoHub app.


Receiving a call

When someone calls the GizmoWatch, it will ring and the caller name will be shown on the screen.

- To answer the call, tap .
- To reject the call, tap .



- To end the call, tap .


TIP: To adjust the volume during the call, tap .







NOTE: Making and receiving calls and messages requires a network connection.

Sending a message


1. From the watch screen, swipe left to open the Contact List. Then select the contact you want to message.




2. Tap  to create a new message. Then:
 - To choose from a list of pre-written messages, tap .
 - To choose an emoji, tap .
 - To create a voice message, tap .



Receiving a message

When the GizmoWatch receives a new message, it will appear on the Home screen. To reply, tap .



NOTE: Your GizmoWatch can only receive messages from contacts with the GizmoHub app or from other Gizmo devices if the sender is a GizmoBuddy. It can't receive messages from non-Gizmo devices.

Support & more



GizmoHub app

Open the GizmoHub app on your phone and go to **More > Help** to learn more about using your watch.



My Verizon Mobile

Use the My Verizon Mobile app on your phone to manage your account, track your usage, and more.



Get help online or download a User Guide visit:
verizonwireless.com/Support



Customer service

Call **800.922.0204**.
Twitter **@VZWSupport**

Additional information

Your wireless device and third-party services

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.

