

# MPCI-101 WIRELESS LAN CARD

## **Federal Communication Commission Interference Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party :Campbell Kan

Acer America Corporation

2641 Orchard Parkway, San Jose, CA 95134

Telephone No :1-408-432-6200

## Drivers Installation

### Before You Start the Installation

Before you start the installation, you are advised to keep the Windows CD-ROM or software diskettes close at hand. If your computer came with a factory-installed Windows operating system, these files will be stored on your computer's hard disk, in the form of cabinet (\*.cab) files.

### What You Need to Know

Installing a Mini-PCI Card requires the same level of expertise that you would need to install a standard Ethernet network adapter card. It is assumed that you have a working knowledge of standard Windows 95/98/2000/ME operations and of installing network adapter cards. Refer to the Windows Help when necessary (on the Windows task bar, press the **Start** button and select **Help**).

### Driver Installation for Windows 95/98/2000/ME /2000/Millennium

Windows 95/98/2000/ME operating systems support "Plug & Play" for Mini-PCI Cards. Once you insert the Mini-PCI Card into your computer, these operating systems will automatically:

- Detect the card, and enable the Driver, or
- Start the **Add New Hardware** wizard and prompt you to install the driver, when the operating system cannot find the required driver. This would typically occur when inserting the Mini-PCI Card into your computer for the very first time.

To install the driver proceed as follows:

1. If Windows starts the **Add New Hardware** wizard follow the instructions of the **New Hardware Found** wizard to install the drivers.

■ When you are prompted to locate the driver installation files:

— Select the CD-ROM that was included with your Mini-PCI Card kit and.

Windows 95:D:\Drivers\Win\_95

Windows 98:D:\Drivers\Win\_98

Windows 2000:D:\Drivers\Win\_2000

Windows Millennium:D:\Drivers\Win\_98

When finished installing the drivers, Windows automatically opens the **Add/Edit Configuration Profile** window.

2. Continue with setting the basic parameters

## Windows Network Properties

If this is the very first time that Networking support is installed onto your computer, the Windows operating system will prompt you to enter a computer and workgroup name. These names will be used to identify your computer on the Microsoft Network Neighborhood.

1. The window will pop-up automatically.
2. In the **Computer Name** field, enter a unique name for your computer.
3. In the **Workgroup** field, enter the name of your workgroup.
4. (Optional) Provide a description of the computer in the **Computer Description** field.

For more information about setting your Windows Network Properties, consult your Windows documentation or the Windows on-line help information.

## Set Basic Parameters

After installing the drivers, Windows will open the Add/Edit Configuration Profile window for your Mini-PCI Card.

The Add/Edit Configuration Profile window enables you to specify one or more network connection profiles.

For example you can setup profiles for:

- **Office**, to connect to an Enterprise Network via an Access Point.
- **Workgroup Computing**, to share files with colleagues or friends in small Peer-to-Peer workgroups without access point.
- **Home**, to connect to a Residential Gateway (RG) that provides access to the Internet or your home printers.

To connect your computer to a wireless network you will need to:

1. Assign a name to the network connection profile
2. Use the pull-down menu on the right to select how you wish to connect to the wireless network.
3. Click the **Edit Profile** button to view/modify the parameters for the selected profile.

For first-time installations, you are advised to setup the single profile using only the Basic Settings.

### NOTE:

The number and type of parameters you need to specify may differ according to the selected connection type.

For information about various option press the key **F1** or click the **Help** button.

## Basic Settings for Residential Gateway

If you wish to connect to a Home Network via a Residential Gateway, use the Add/Edit Configuration Profile window to:

- Select to connect to a **Residential Gateway**.
- Set the correct **Network Name** and **Encryption Key**.

1. In the field **Network Name** enter the 6-character RG ID to define the same of the wireless network to which you want to connect. The **Network Name** has to match the unique RG ID (which can be found on the device).
2. In the **Encryption Key** field enter the last 5 digits of the RG ID (default).

### **NOTE:**

If you changed the default Encryption Key on the Residential Gateway (RG) you will need to enter the new value here as well.

3. Click **OK** to confirm and return to the Add/Edit Configuration Profile window.
4. Click **OK** again to finish the installation.

## **Basic Settings for Peer-to-Peer**

### **Workgroups**

If you wish to connect to a Peer-to-Peer workgroup, use the Add/Edit Configuration Profile window to:

- Select to connect to a **Peer-to-Peer Workgroup**.
- Set the correct **Network Name** and **Encryption Key**.

1. In the field **Network Name** define the name of the wireless network to which you want to connect.  
The Network Name can be any alphanumeric string in the range of “a” to “z”, “A” to “Z” and “0” to “9” with a maximum of 32 characters (case-sensitive).
  - If there is already a Peer-to-Peer group with this name available your computer will automatically connect to this workgroup.
  - If there is not yet such a group available, your computer will automatically start one with this name.
2. Click **OK** to confirm and return to the Add/Edit Configuration Profile window.
3. Click **OK** again to proceed with the installation.

## **Finish the Installation**

When you have finished “Set Basic Parameters”, click the **OK** button to close the Add/Edit Configuration window and to proceed with the installation process. Windows will finish building the driver configuration database and copy some files to your computer’s hard disk.

■ If the Windows operating system prompts you to identify the location of the Windows files, specify the drive and directory of the Windows Installation CD-ROM or diskettes. When you had a Mini-PCI Card installed on your computer before, most of these files are already available on your hard disk drive. If you do not have the Windows CD-ROM available, you may try replacing the proposed path in the Copy Files From dialog box with: "C:\Windows\System" or "C:\Windows\"

■ If the Windows operating system prompts you to identify the location of the driver files (typically file names starting with the characters wv\*.v) specify the drive and directory of the Software:

— if installing from the CD-ROM specify the drive in one of the following directories on the Software CD-ROM.

Windows 95:D:\Drivers\Win\_95

Windows 98:D:\Drivers\Win\_98

Windows 2000:D:\Drivers\Win\_2000

Windows Millennium:D:\Drivers\Win\_98

— if installing files that you downloaded from the Internet, point to the disk drive or directory where you saved the downloaded files.

When Windows has finished the copying of files, it will prompt you to restart your computer. Click the **OK** button to restart your computer.

## After Restarting Your Computer

After you have restarted your computer, the Windows operating system will detect the Mini-PCI Card. Load the driver, in a dialog box enter a Windows user name and password. The password you enter here will be the one used to login to the Windows Network Neighborhood.

The transmitter and the antenna is permanently installed inside the notebook, and is specific for this model, not for each model. The antenna of this device is installed on the bottom corner of the LCD display. It should be operated with separation distance of 20 cm or more between the antenna and persons (it normally is). The antenna should not be operated next to a person's body.

## Mini-PCI Card Hardware Specification

### 1. Operating and Storage Environment

The Network Interface Card shall be capable to pass the environmental tests as specified in "Mini PCI Specification, October 1999 [Ref. 16], Section 5.6 Thermal Guidelines".

Operating temperature range: 0°C to 60°C ambient temperature.

.Relative humidity when operational: 95% maximum (non condensing).  
Storage temperature range: -20°C to 75°C ambient temperature.  
Relative humidity during storage: 95% maximum (non condensing).

## 2. Power supply

The Network Interface Card shall be capable to operate from 3.3V +/- 0.2V Host supply voltage. Refer to *chapter 11.1. Host interface* for configuration of card type and supply voltage. The current consumption averaged over 1s is defined for the following operational modes:

Doze mode: 30mA  
Receive mode: 230mA  
Transmit mode: 330mA

A 120mV peak-peak ripple on the supply voltage with a fundamental frequency not greater than 150kHz and not less than 60Hz shall not degrade the Network Interface performance.

The total load capacitance of the supply voltage shall not exceed 150µF in order to meet the inrush current requirement.

## 3. PERFORMANCE REQUIREMENTS

### 3.1. General

Receiver input levels and transmitter output levels are specified at the antenna connector.

#### 3.1.1. Antenna port impedance

The nominal antenna port impedance is 50W.

The Network Interface Card shall not be damaged for any Voltage Standing Wave Ratio (VSWR)  $1 \leq \text{VSWR} \leq \infty$ .

#### 3.1.2. Power-on start-up time

The Network Interface Card shall be operational within 600ms after switching the power supply on. This includes a delay of max 500 ms for the Flash ROM power up sequence.

#### 3.1.3. Doze to receive mode start-up time

The Network Interface Card shall be operational within 0.75ms after switching from Doze mode to Receive mode. This includes lock-in and stabilization of the synthesizers. Transmissions are not allowed during this period.

#### **3.1.4. Receive to transmit turnaround time**

The time from transition of the TXE control line (transmit enable control line from WMAC to DSP) from inactive state to active state until the RF section is in transmit mode shall be not more than 5 $\mu$ s. The NIC is said to be in transmit mode at the moment the RF output power level is within 90% of its final value.

#### **3.1.5. Transmit to receive turnaround time**

The time from transition of the TXE control line (transmit enable control line from WMAC to DSP) from active state to inactive state until the NIC is in receive mode shall be not more than 10 $\mu$ s.

#### **3.1.6. RF center frequency**

The RF function provides programming of the RF center frequency from 2400MHz to 2500MHz in steps of 1MHz. The RF center frequency for transmission and reception shall be stable within 25kHz of its final value, 0.75ms after reprogramming or switching from doze mode to receive mode.

#### **3.1.7. RF center frequency and clock accuracy**

The master clock frequency and the RF center frequency shall be within +/-25ppm of the nominal value.

The carrier jitter is within 25kHz of its final value 40 $\mu$ s after switching between RX and TX mode.

### **3.2. Transmitter**

#### **3.2.1. Transmit power-on and power-down ramp**

The transmit power-on ramp from 10% to 90% of the maximum power shall not take longer than 2 $\mu$ s. The transmit power-down ramp from 90% to 10% of the maximum power shall not take longer than 2 $\mu$ s. The transmit power ramp shall be constructed such that the emissions comply with the radio regulations.

#### **3.2.2. Transmitted power level**

The nominal transmitted power shall be 15 dBm +/- 2dB at full operational temperature range. This range complies with the IEEE802.11 PHY standard and the radio regulations. The power density shall not exceed 10dBm/MHz EIRP.

#### **3.2.3. Transmitted output spectrum**

The transmitted spectral products shall be less than -30dBc (dB relative to the sin(x)/x peak) for frequencies between 11MHz and 22MHz from the center frequency and -50dBc for frequencies more than 22MHz from the center frequency. The measurement shall be made at the antenna port using 100kHz resolution bandwidth.

#### **3.2.4. RF carrier suppression**

The RF carrier suppression measured at the channel center frequency shall be at least 15dB below the peak sin(x)/x power spectrum.



### 3.3. Receiver

#### 3.3.1. Medium busy

The DSP reports to the WMAC the presence of a spread-spectrum signal on the medium by the MBUSY signal.

#### 3.3.2. Minimum input level sensitivity

For all channels, the Frame-Error Rate (FER) shall be less than  $8 \times 10^{-2}$  at a frame length of 1024 bytes for:

- an input level of -91dBm at 25°C or -89dBm at full operational temperature range, measured at the antenna connector using 1Mbit/s DBPSK modulation
- an input level of -88dBm at 25°C or -86dBm at full operational temperature range, measured at the antenna connector using 2Mbit/s DQPSK modulation
- an input level of -85dBm at 25°C or -83dBm at full operational temperature range, measured at the antenna connector using 5.5Mbit/s CCK modulation.
- an input level of -82dBm at 25°C or -80dBm at full operational temperature range, measured at the antenna connector using 11Mbit/s CCK modulation.

The test for the minimum input level sensitivity shall be conducted with the *Carrier Detect threshold* set less than -95dBm.

#### 3.3.3. Maximum input level

The FER shall be less than  $8 \times 10^{-2}$  (1024 byte frames) for a maximum input level of -4Bm measured at the antenna connector. This applies to all modulation types and data rates.

#### 3.3.4. Over-voltage protection

The receiver shall not be damaged by over-driving levels up to +17dBm at the antenna connector. No DC voltage shall be exposed to the antenna connector.

#### 3.3.5. Out-of-band signal rejection

A Mini-PCI board signal is applied together with two Continuous Wave (CW) interference signals at the receiver antenna input. The level of the Mini-PCI board signal is -55dBm. The CW interference signals have equal level and 1.2MHz frequency distance. The maximum level of each of the two interfering CW signals for a FER better than  $8 \times 10^{-2}$  (1024 byte frames) is shown in Table 1 as a function of the average frequency of both interfering frequencies.

Average frequency of interferers	max. level of each interferer,
<1.0GHz	-6dBm
1.0-2.0 GHz	-10dBm
2.0-2.35 GHz	-26dBm
2.55-2.9 GHz	-26dBm
>2.9 GHz	-10dBm

Table 1. Out of band maximum interference levels.

### 3.3.6. Irreducible Frame Error Ratio

The Irreducible FER (1024 byte frames) in an RF-clean environment (anechoic chamber) at nominal temperature between two Network Interfaces one meter apart using 2Mbit/s DQPSK will be better than  $1 \times 10^{-8}$ .

## 4. RF channel frequencies

The Network Interface in the 2.4-2.5GHz ISM band uses the channel center frequencies as defined by the IEEE802.11 PHY standard for DSSS. These channel frequencies and the countries of application are listed in Table below. Note: the mini PCI card uses subset channel 1 through 11, which allows usage across the world.

Channel ID	FCC Channel Frequencies (MHZ)	ETS Channel Frequencies (MHZ)	Japan Channel Frequencies (MHZ)	France Channel Frequencies (MHZ)
1	2412	2412	-	-
2	2417	2417	-	-
3	2422	2422	-	-
4	2427	2427	-	-
5	2432	2432	-	-
6	2437	2437	-	-
7	2442	2442	-	-
8	2447	2447	-	-
9	2452	2452	-	-
10	2457	2457	-	-
11	2462	2462	-	-

## 13. RASUI

The MTBF is 150,000 hours based on a workload of 2040 hours/year. This assumes the card does not exceed its ambient temperature ceiling of 60 degrees C.

