


# AXM-105

## User's Guide



The first time you take out this mouse and receiver from the packing, Factory Preset ID enables Plug and Play function.

Plug the Receiver into PC USB Port. Under Win2000 or higher, wait for the OS to detect the RF device. Under Win98 or lower, installation of driver for the device is necessary.

Insert the batteries into the mouse and move it for a while, then it starts working.

### 2. Inserting Batteries:

A. Push the battery cover compartment backwards and open it.



B. Insert 2 AAA batteries into compartment with correct orientation.  
C. Slide the battery cover into the compartment and close the cover.



### 3. To change the wireless connection channel:

When Factory ID has been changed or wish to be changed, link ID as below:

A. Press the ID button on the top of the receiver and the led on it starts blinking

B. Press the ID button on the bottom of the mouse. If blinking of that led turns faster, ID Link is OK.



**Warning!** ID linking should be completed within 10 seconds or connection would be failed.

### 4. Low Battery Alert:

When batteries power drops down to 2V, the alert Led on the left side of the mouse starts flashing. Please charge batteries for four hours and not exceed 24 hours.



### 5. Charge Batteries:

A. Plug 1.3mm DC jack into Receiver DC socket.



B. Plug 1.0mm DC Jack to Mouse DC socket. Batteries charge begins and the alert Led of the mouse lightens constantly.



C. When Alert Led fades out, charge is full and be sure to disconnect the charge cable.

### Note :

- Charge the batteries to full the first time you insert new batteries for use. 8 hours battery charging is recommended.
- Don't charge if no batteries are loaded.
- Be sure DC Jack plugged into correct socket. Any other incompatible facilities should not be connected with Receiver socket.
- Only Ni-MH 600mAh 1.2V AAA batteries authorized should be used.
- DC Jack cable should not be used to charge other devices.

### 6. Power Saving Mode:

A. Suspend Mode:  
Keep mouse stationary for 10 minutes, mouse will be automatically set to Suspend Mode. Press left button to wake up the mouse again.

B. Power Off Mode:  
When you wish to set the mouse to power off mode, press mouse ID for 3 seconds.

The Optical Led will flash once And then fade out showing Mouse power is already off. Press ID switch for waking up again.

### 7. Dual Mode:

The unique feature of Dual Mode is allowed for you to use mouse even the battery is low power. The goal of this design is to make mouse always running. When the low battery alert is shown, you just plug the charged wire that is included in the package to mouse and receiver. The wireless mouse is able to keep operating as a wire mouse without any interruption.

Besides, the regular Nokia mobile phone DC adapter (battery charger), e.g. ACP-7, ACP-8, ACP-9, LCH-9, DCH-9, etc., also can be used to charge the NiMH battery too. The recommended DC adapter is DC voltage output is 5V and current output is 500mA.

**Warning!** Any improper charging operation may damage the mouse and would be dangerous. Please read the details of paragraph of "Charge Batteries" in his manual and Hold a mobile DC adapter user manual.

### 8. Trouble Shooting:

- When mouse doesn't respond, check the battery power status, and link ID again.
- Be sure the two DC Jacks be connected to the right respective mouse or receiver DC sockets
- Check the battery pole if the optical Led is still off after inserting batteries.
- Please do use the accessories (DC Jack cable) attached, if DC Jack cable is defective, then Nokia charger (5.03V/500mA regulated voltage function) can be used.
- Check the DC Jack cable if it is well connected when Low Battery Alert Led never fades out.
- Ask for maintenance solution from your retailer and engineer. Personally taking apart is prohibited after trouble happened.

### FCC NOTE

This equipment has been tested and comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The antennas used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

