# Meet your phone.






# Have questions about your Prepaid phone? You're in the right place.

Find out how to set up and use your phone, access special features, get help and lots more. We're here to help.



# **About your phone**




NOTE: Devices and software are constantly evolving – the screen images and icon you see here are for reference only.

# Setting up your phone

Your phone already has a SIM card installed.

#### Step 1. Remove the back cover

Place your fingernail in the notch at the bottom coner of the back cover and pry off the cover.



Optional: Insert the microSD card

If you have a microSD card, slide the microSD card into the microSD card slot with the gold contacts facing down.



NOTE: The microSD card is sold separately.

# Step 2. Insert the battery

Insert the battery, making sure the gold contacts line up. Press down gently to secure.



# Step 3. Charge the phone

Before turning on your phone, charge it fully.
Insert the small end of the USB cable into the phone.
Insert the larger end into the charger and plug it into an outlet.



WARNING: Only use approved chargers with your device. Incompatible chargers or tampering with the charger port could damage your device and void the warranty.

# Step 4. Turning your phone on/off

To turn your phone on, press and hold the Power/Lock button.



NOTE: The first time your turn on your phone you will need to activate it. See the **Activate your phone** guide included with your phone.

To turn your phone off, press and hold the Power/Lock button.

#### Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then swipe up on the screen to unlock it.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button.

# **Using your phone**

#### **Touch screen tips**

Use touch gestures to move around the screen, open menus, select items, zoom in and out of web pages and more.

There are several touch gestures recognized by your phone:

- · Swipe Swipe by quickly sliding your finger in any direction.
- Drag Drag by touching an item and moving it to a new position.
- Double tap Double tap to zoom in/out on a web page or picture.
- Multi-touch Pinch or spread your thumb and index finger to zoom in or out.
- Control with one touch Lock, unlock, and navigate your phone with just one touch. To find Lock/Unlock settings, swipe up ^ > Settings > Security & Location > Fingerprint.



#### Verizon Cloud

Verizon Cloud offers secure online storage to back up your contacts and sync them with your other Cloud-connected devices.

To learn more go to vzw.com/Cloud.

# Making a call

- 1. From the Home Screen, tap the **Phone** icon ...
- Enter the number you want to call or search the first letters of the contact's name and select the contact.
- 3. Tap the Call icon ( to place the call.

# Receiving a call

When the phone is locked, tap the **Answer** icon **9** and swipe up to answer an incoming call.

When the phone is unlocked, tap **ANSWER** or **IGNORE** on the notification bar.



# **Setting up Voice Mail**

- 1. Dial \*86 and press Send.
- 2. When you hear a greeting, press # to interrupt.
- 3. Follow the setup instructions.

# Checking Voice Mail

From your phone:

- 1. Dial \*86 and press Send.
- 2. Follow the instructions.

From other phones:

- 1. Dial your wireless number.
- 2. When you hear the greeting, press # to interrupt.
- 3. Follow the instructions.

NOTE: Voice mailboxes not set up within 45 days will be cancelled. Your voice mailbox is not password protected until you create a password by following the setup tutorial. Voice Mail may not be available in some areas. Follow the setup instructions to password-protect your Verizon Wireless Voice Mailbox. Airtime and other charges are incurred when using voice mail from your wireless phone. Mobile to Mobile Calling minutes do not apply to voice mail retrievals; you will be charged to maintain your connection to Voice Mail. Verizon Wireless is not responsible for missed messages or deletions of messages from your Voice Mailbox, even if you have saved them.

# Services and features

# **Calling features**

- Domestic Long Distance
- Domestic Roaming
- 411 Search
- Caller ID
- Caller ID Blocking
- · Call Waiting
- 3-Way Calling
- Call Forwarding

# Text messaging\*

- From the Home screen, tap the Message+ icon ...
- 2. Enter the recipient's information and compose the text message.
- 3. Tap the **Send** icon >.

NOTE: Messages to participating networks in Mexico, Canada and Puerto Rico are charged at domestic rates.

\*Additional and Unlimited Texting applies when sending and receiving (i) Instant Messages, Text Alerts and Picture Messaging Portal Messages; (ii) messages with non-Verizon Wireless customers in the U.S. or participating networks in Mexico, Canada and Puerto Rico; or (iii) via email. Unlimited Texting also includes Mobile to Mobile Messages with Verizon Wireless customers. For Additional Texts, overage messaging rates default to those of your Calling Plan. Premium Messaging programs, International Messaging and International Roaming not included. Compatible device required for text, picture and/or video messaging. Data charges will apply for sending and receiving picture and video messages.

# Picture and video messaging\*

Take pictures or videos and send them to almost any email address, or to other phones.

- 1. From the Home screen, tap the **Camera** icon <sup>3</sup> to start the camera or video recorder.
- 2. Capture the picture or video.
- 3. Using the appropriate keys, Save or Send the picture or video.

For pricing details please visit verizonwireless.com.

# Apps and more

Play it up with music, ringtones, wallpapers, apps and games. Keep up with Twitter™ and Facebook. We've got apps that help you do it all. Data charges may apply.

#### Installing apps

From the Home screen, tap Play Store

# Web browsing

From the Home Screen, tap Chrome



# International services

Your phone is enabled to call or text internationally. For additional details including rates visit **vzw.com/prepaidglobal**.

#### Location based services

This phone can determine its location, which is useful for services such as navigation, shopping and weather. For your safety, it's defaulted to acquire your location only when you dial 911. To use Location based services, from the Home screen, swipe up  $\land$  > Settings > Security & Location.

Locations and rates subject to change without notice. While roaming internationally, you may be prompted to dial the phone number you are calling twice. Unlimited Calling, Text Bundles and Unlimited Night, Weekend, Mobile to Mobile and Anytime Minutes do not apply to International Services. International Roaming Coverage only available on participating networks and is not guaranteed. Data Services and features not available when roaming.



# **VZ Navigator®**

Select the app or download it from the Google Play™ Store. Go to **verizonwireless.com/navigator** for more details and pricing.

Your wireless device can determine its (and your) physical. geographical location ("Location Information") and can associate Location Information with other data. Additionally, certain applications. services and programs are capable of accessing, collecting, storing and using Location Information and disclosing Location Information to others. You should use caution when determining whether or not Location Information should be made available to others and you should review any applicable third-party policies before providing access. To limit potential unauthorized access to your Location Information, Verizon Wireless offers various mechanisms and settings to manage access to location data. By enabling location settings, you are permitting third-party access to Location Information through software, widgets or peripheral components you choose to download. add or attach to your wireless device or through web access, messaging capabilities or other means and you are authorizing Verizon Wireless to collect, use and disclose your Location Information as appropriate to provide you with any location services that you enabled.

# **Support and more**



The Help app gives you tips, videos and other information on how to use your phone, including:

- 🌑 Making calls
- O Voice mail
- Sending texts
- Getting apps
- Taking photos

Accessibility settings: From the Home screen swipe up ^ > Settings > Accessibility.



From your computer, visit verizonwireless.com/support.



Customer service
Call 800.922.0204
Twitter @VZWSupport



Download a User Guide from verizonwireless.com/support.

# **Important customer information**

The services described in this brochure are only for your personal use. They are subject to the Customer Agreement, your Calling Plan, the Verizon Wireless Privacy Principles and Internet Privacy Policy (both of which can be viewed at verizonwireless.com and the following terms and conditions, as applicable. You agree to comply with all applicable laws, rules, regulations and policies when using these services. In addition to your rights under the Customer Agreement, we may terminate or modify all services upon notice. Verizon Wireless is not responsible for thirdparty content you encounter using these services, including any possible defamation, obscenity or profanity. Content, content pricing, service functionality and menu order may change without notice. Unless otherwise indicated, data sessions will terminate after 30 seconds of inactivity.

# Device recycling program

Recycle your used device with Verizon Wireless. You can receive a Verizon Wireless Virtual Gift Card if your device qualifies, or you can donate it to HopeLine® from Verizon, a program that provides support to victims and survivors of domestic violence. For more information visit verizonwireless. com/device-recycle.

# Warranty replacements

If you're having a problem with your wireless device, just contact Verizon Wireless toll-free at 866.406.5154 from another phone.



# Using TTY and TDD networks

TTY (Text Telephony) and TDD (Telecommunications Device for the Deaf) allow individuals who are deaf, hard of hearing, or have speech or language disabilities to communicate by telephone.

When a user types his or her conversation on a TTY keyboard, it is transmitted as tones through the telephone. Tones are received by the other person's TTY, translated into text and displayed on the screen.

In order to use the TTY network, you must have a TTY-compatible phone and be in the TTY mode to place or receive calls. Note that most digital wireless devices are TTY-compatible.

# Data charges and location-based services

Verizon Wireless charges you for all data and content sent or received using our network (including any network overhead and/or Internet Protocol overhead associated with content sent or received), as well as resolution of Internet Protocol addresses from domain names Sending or receiving data using a virtual private network (VPN) involves additional VPN overhead for which you will be charged. Please note that certain applications or widgets periodically send and receive data in the background, without any action by the user, and you will be billed for such data use.

Many services and applications offered through your device may be provided by third parties. Before you use, link to or download a service provided by a third party, or an application such as a non-Verizon Wireless location-based GPS-type service, chat room, marketplace or social network from your device, you should review the terms of such service or application and applicable privacy policy. Personal information you submit may be read, collected or used by the service or application provider and/ or other users of those forums.

Verizon Wireless is not responsible for any information, content or services you access, download or use from the internet. You are responsible for maintaining virus and other internet security protections when accessing service.

For additional information, visit the Verizon Content Policy at responsibility.verizon.com/contentpolicy.

Your Verizon Wireless customer agreement terms and conditions and certain other specifically identified terms govern your use of any Verizon Wireless products and services.

# Prepaid calling plans

If you want to change from prepaid service to postpay service, any remaining funds in your account will be credited to your postpay account. We can't give you any credit for transaction taxes you may have paid when depositing funds into your account, so you could end up paying the same taxes twice.

Your balance may not exceed \$1,000 and you may be prevented from making payments to your account if it reaches \$1.000. Cash applied to your account through Verizon Wireless' Bill Payment Kiosks will have taxes deducted from the total amount entered at the applicable rate. Minimum payment is \$10; maximum payment is \$600. When paying with a credit card, maximum is \$250. You may replenish up to 10 times or \$600 in a rolling 30-day period. Transaction fees may apply for some methods of payment.



# Verizon Wireless prepaid

If you are on a Prepaid Monthly Plan, you must have a sufficient account balance at the time of renewal to cover the Monthly Access in order to receive your plan benefits. Monthly Access will be charged on the same date each month, unless you have insufficient funds to cover the Monthly Access.

Some Verizon Wireless Services and Features, including Verizon (Video and Mobile TV), Extended Warranty, Wireless Phone Protection, Total Equipment Coverage, Roadside Assistance, Detailed Billing and Premium and Visual Voice Mail are not available with the Prepaid Calling Plans.

411 Search: When outside the Verizon Wireless Prepaid Rate and Coverage Area, 411 Search rates, automatic connection and enhanced services may vary. For connected calls, the part of the call that occurs prior to connection may be billed at a different rate than the part of the call that occurs after connection. Additional toll and long distance charges may apply.

# Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

# **Additional Information**

Where is my legal, safety and regulatory information?

In order to provide you with better access to this important information, we've made the materials accessible from the phone's settings menu and on the web. Review these materials prior to using your device. To access the materials from a connected phone, go to Settings > System > Legal information, and select a topic. To access the materials on the web, visit www.motorola.com/device-legal.

**Battery Safety** 

Before assembling, charging or using your mobile device for the first time, please read the important product safety and legal information provided with your product.

If your mobile device becomes unresponsive, try a reboot – press and hold the Power button until the screen goes dark and your device restarts. Your mobile device uses a removable battery. Only use Motorola Original batteries for safety and best performance.

Warning:

Don't use tools, sharp objects, or excessive force to insert or remove the battery. This may damage the battery and could cause burning and injury. Don't try to take apart or fix your battery. This may damage the battery and could cause burning and injury.

Don't crush, bend, or expose your battery or mobile device to heat or liquid. This may damage the battery and could cause burning and injury. Don't try to dry your mobile device using a microwave oven, conventional oven, or dryer.

Warning about Hign Volume Usage

To prevent possible hearing damage, do not listen at high volume levels for long periods.



Disposal & Recycling

Help do your part! Please don't dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. For details on approved national recycling schemes and Motorola recycling activities, go to: www.motorola.com/recycling.

#### Usage

This phone supports apps and services that could use a lot of data, so make sure your data plan meets your needs. Contact your service provider for details. Certain apps and features may not be available in all countries.

# **Regulatory Information**

To view the Regulatory ID (such as FCC ID) for this device, on the phone, go to Settings > System > Legal information > Regulatory information, or visit www.motorola.com/device-legal.

# Warranty

This product is covered by Motorola's limited warranty. To review the warranty on your phone, go to **Settings > System > Legal information > Warranty**, or visit www.motorola.com/device-legal. You may also obtain a copy of the warranty by contacting Motorola at: Motorola Mobility LLC, Attention Customer Service--Warranty Request, 222 West Merchandise Mart Plaza, Suite 1800, Chicago, IL 60654.

#### **Arbitration & opt-out**

Except where prohibited by law, any controversy or claim arising out of or relating to any Motorola product will be resolved by binding arbitration, instead of in court, unless you opt-out. To opt-out, send a written rejection notice within 30 days of purchase that includes your name, address, phone number, device, and device serial number, and tells Motorola that you are rejecting this Arbitration provision to: Motorola Mobility LLC, 222 West Merchandise Mart Plaza, Suite 1800, Attn: Arbitration Provision Opt-Out, Chicago, IL 60654 or arbitrat@motorola.com. For more information on this arbitration provision, on your phone, go to Settings > System > Legal information > Arbitration and opt-out, or visit www.motorola.com/device-legal.

# **Legal Disclaimers**

Certain features, services and applications are network dependent and might not be available in all areas; additional terms, conditions and/or charges might apply. Contact your service provider for details. All features, functionality, and other product specifications, as well as the information contained in this guide, are based upon the latest available information and believed to be accurate at the time of printing. Motorola reserves the right to correct, change or modify any information or specifications without notice or obligation.

# Copyright & Trademarks

MOTOROLA, the stylized M logo, MOTO, and the MOTO family of marks are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. LENOVO is a trademark of Lenovo. Google, Android, Google Play and other marks are trademarks of Google Inc. microSD Logo is a trademark of SD-3C, LLC. All other product or service names are the property of their respective owners.

© 2018 Motorola Mobility LLC. All rights reserved.

Product ID: moto e5 play (Model XT1921-6)

Manual Number: 711608018801

Motorola Mobility LLC

222 W. Merchandise Mart Plaza

Chicago, IL 60654

www.motorola.com



This product meets the applicable national or international RF exposure guidance (SAR guideline) when used normally against your head or, when worn or carried, at a distance of 5 mm from the body. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons, requardless of age and health.